ALLIMITY CRMC-A764JBEZ

User Manual

Allimity CRMC-A764JBEZ Replacement Remote Control

Model: CRMC-A764JBEZ | Brand: ALLIMITY

Product Overview

The Allimity CRMC-A764JBEZ is a replacement remote control designed for use with Sharp AC Air Conditioners. This remote is pre-programmed and requires no setup or programming, making it ready for use immediately after battery installation.





Image: Front view of the Allimity CRMC-A764JBEZ remote control. It features a rectangular display screen at the top, with buttons for MODE, TEMP, FAN, TIMER, DISPLAY, MODE, FAN, SWING, and CANCEL. A large yellow circular button is prominent on the left side.

Setup

To begin using your Allimity CRMC-A764JBEZ remote control, follow these simple steps for battery installation:

1. **Open the Battery Compartment:** Locate the battery cover on the back of the remote control. Gently slide or lift the cover to open the compartment.
2. **Insert Batteries:** Insert two (2) AAA alkaline batteries into the compartment. Ensure that the positive (+) and negative (-) terminals of the batteries align correctly with the markings inside the compartment.
3. **Close the Battery Compartment:** Replace the battery cover by sliding or pressing it back into place until it clicks securely.

No additional setup or programming is required. The remote control is ready for immediate use with compatible Sharp AC Air Conditioners once batteries are installed.



Image: Back view of the Allimity CRMC-A764JBEZ remote control. The battery cover is shown detached, revealing the compartment designed for two AAA batteries. A label on the back indicates "REMOTE CONTROL CRMC-A764JBEZ" and "BATTERY SIZE: R03(AAA)X2Pcs".

Operating Instructions

This remote control provides intuitive access to various functions of your Sharp AC Air Conditioner. Point the remote directly at the air conditioner's receiver when operating.

- **Power On/Off:** Use the main power button (often labeled with a circle or power symbol) to turn the air conditioner on

or off.

- **Mode Selection:** Press the **MODE** button to cycle through operating modes such as Cool, Heat, Fan, Dry, or Auto. The current mode will typically be displayed on the remote's screen.
- **Temperature Adjustment:** Use the **TEMP** up (▲) and down (▼) buttons to set your desired temperature.
- **Fan Speed Control:** Press the **FAN** button to adjust the fan speed (e.g., Low, Medium, High, Auto).
- **Timer Function:** The **TIMER** button allows you to set a specific time for the air conditioner to turn on or off. Refer to your air conditioner's manual for detailed timer programming.
- **Swing Function:** The **SWING** button controls the louver movement for air distribution.
- **Display Button:** The **DISPLAY** button may control the air conditioner's display lights or provide additional information.
- **Cancel Button:** Use the **CANCEL** button to exit or cancel current settings.

For specific functions and their detailed operation, please refer to the original user manual of your Sharp AC Air Conditioner model.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or the display fades. Always replace both batteries simultaneously with new AAA alkaline batteries.
- **Cleaning:** Wipe the remote control with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the remote. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use for extended periods, remove the batteries to prevent leakage, which can damage the remote. Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops and Impacts:** The remote control is made of durable ABS materials, but excessive force or dropping can cause damage. Handle with care.

Troubleshooting

If you encounter issues with your remote control, try the following troubleshooting steps:

- **Remote Not Responding:**
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Ensure there are no obstructions between the remote control and the air conditioner's receiver.
  - Make sure you are within the effective operating range of the air conditioner.
- **Intermittent Operation:** This could indicate low battery power. Replace the batteries.
- **Buttons Not Working:** Ensure the remote is clean and free of debris around the buttons. If specific buttons are unresponsive after battery replacement, the remote may be damaged.

If these steps do not resolve the issue, please contact customer support for further assistance.

Specifications

Model Number	CRMC-A764JBEZ
Compatible Devices	Sharp AC Air Conditioners (e.g., KKG9A-C1, KKG9B-C2)

Battery Type	2 x AAA Alkaline Batteries (not included)
Product Dimensions	6 x 2 x 0.6 inches
Item Weight	2.33 ounces
Color	White and Gray
Material	ABS Materials
Manufacturer	YUDAXINFACTORY
Country of Origin	China

Customer Support

If you have any questions regarding the Allimity CRMC-A764JBEZ replacement remote control, or if you require further assistance, please do not hesitate to contact our customer support team.

We are committed to providing timely support and aim to reply to all inquiries within 24 hours.

Please refer to your purchase platform or product packaging for specific contact details.

© 2024 ALLIMITY. All rights reserved.