USHA 4085SSK15L33N

Usha Electric Kettle Instruction Manual

Model: 4085SSK15L33N

Capacity: 1.5 Litres | Wattage: 1200 Watts

Introduction

Thank you for choosing the Usha Electric Kettle. This manual provides important information for the safe and efficient use of your appliance. Please read it thoroughly before first use and keep it for future reference.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons:

- Do not immerse the kettle, power base, cord, or plug in water or other liquids.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface, away from the edge of the countertop.
- Do not operate the kettle if the cord or plug is damaged, or if the appliance malfunctions or has been damaged in any manner.
- Keep the appliance out of reach of children. Close supervision is necessary when any appliance is used by or near children.
- Do not fill the kettle above the MAX level indicator or below the MIN level indicator to prevent boiling dry or overflow.
- Always close the lid securely before operating the kettle.
- Use the kettle only with the provided power base.
- Unplug the kettle from the electrical outlet when not in use and before cleaning. Allow it to cool completely before handling any parts.
- Avoid contact with hot surfaces. Always use the cool-touch handle when moving or pouring from the kettle.
- This appliance is designed for household use only. Do not use it outdoors or for commercial purposes.
- Do not place the kettle on or near a hot gas or electric burner, or in a heated oven.

Product Overview

Familiarize yourself with the components and features of your Usha Electric Kettle.



Image: Usha Electric Kettle (Model 4085SSK15L33N) showcasing its overall design and key features.

The kettle features a durable food-grade stainless steel body, a cool-touch handle for safe handling, and a wide mouth design for easy filling and cleaning. It operates at 1200 Watts and has a 1.5 Litre capacity.



Image: Internal view of the kettle highlighting the water level indicator and the automatic cut-off safety feature.

An internal water level indicator helps you accurately fill the kettle. For safety, the kettle is equipped with an automatic cut-off function that switches the appliance off once the water has boiled.



Image: Detail of the seamless inner pot and concealed heating element, designed for easy cleaning and preventing mineral build-up.

The seamless inner pot with a concealed heating element ensures easy cleaning and minimizes the accumulation of mineral deposits.



Image: The kettle's lid mechanism, illustrating the one-touch opening and secure lockable design.

The lid features a convenient one-touch opening mechanism and is lockable to prevent accidental spills during operation.



Image: The power base with an integrated cord winder for tidy storage and a 3-pin plug for enhanced safety.

The power base is designed with a cord winder for neat storage and includes a 3-pin plug with earthing for electrical safety.

Setup and First Use

1. **Unpack:** Carefully unpack the kettle and all its accessories. Remove any packaging materials, stickers, or labels.
2. **Placement:** Place the power base on a dry, flat, stable, and heat-resistant surface, ensuring it is away from water sources and heat-sensitive materials.
3. **Initial Cleaning:** Before using the kettle for the first time, fill it with clean water to the MAX level.
4. **First Boil:** Plug in the power cord and switch on the kettle to boil the water. Once boiled, discard this water. Repeat this boiling and discarding process 2-3 times to remove any manufacturing residues or odors.
5. **Exterior Wipe:** Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners.

Operating Instructions

1. **Filling the Kettle:** Press the lid release button to open the lid. Fill the kettle with the desired amount of water, ensuring the water level is between the MIN and MAX marks on the internal water level indicator. Close the lid securely until it clicks into place.
2. **Placing on Power Base:** Place the filled kettle firmly onto its power base, ensuring it is properly seated.
3. **Connecting to Power:** Plug the power cord into a suitable earthed electrical outlet.
4. **Switching On:** Press the ON/OFF switch downwards. The indicator light will illuminate, signaling that the kettle has begun heating the water.
5. **Boiling:** The kettle will automatically switch off once the water has reached boiling point, and the indicator light will extinguish.
6. **Pouring:** Carefully lift the kettle from the power base using the cool-touch handle. Pour the hot water slowly and steadily to avoid splashing.



Image: The kettle's design facilitates easy pouring and refilling.

7. **Re-boiling:** If you need to re-boil water immediately after it has switched off, wait a few seconds for the internal

thermostat to reset before pressing the switch again.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your kettle.

Cleaning the Exterior

- Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
- Wipe the exterior surface with a soft, damp cloth. Do not use abrasive cleaners, scouring pads, or harsh chemicals as these can damage the finish.
- Never immerse the kettle body or its power base in water or any other liquid.

Descaling

Mineral deposits (limescale) can build up inside the kettle, especially in hard water areas. Descaling regularly will maintain heating efficiency and prolong the appliance's lifespan.

1. **Prepare Solution:** Fill the kettle with 1 part white vinegar and 2 parts water. Alternatively, use a commercial descaling solution according to its specific instructions.
2. **Boil and Soak:** Bring the mixture to a boil and then let it stand in the kettle for at least 30 minutes, or longer if the scale build-up is heavy.
3. **Rinse:** Pour out the descaling solution and rinse the kettle thoroughly several times with fresh, clean water.
4. **Repeat if Necessary:** If stubborn deposits remain, repeat the descaling process.
5. **Final Rinse:** To remove any residual vinegar taste or smell, boil fresh water 2-3 times and discard it before using the kettle for beverages.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat up.	Not plugged in; power switch not pressed; kettle not properly seated on base; power outage.	Check if the power cord is securely plugged in; press the ON/OFF switch; ensure the kettle is correctly placed on its power base; check your household power supply.
Kettle switches off before water boils.	Too little water in the kettle; significant limescale build-up.	Ensure the water level is above the MIN mark; descale the kettle as per the maintenance instructions.
Water has an unusual taste or smell.	New kettle residue; residual descaling solution.	Perform the first-use boiling and discarding process again; after descaling, rinse thoroughly and boil fresh water several times before use.
Lid does not close properly.	Obstruction preventing closure; lid mechanism issue.	Check for any foreign objects or debris preventing the lid from closing securely; if the issue persists, contact customer support.

Specifications

Feature	Detail
Model Number	4085SSK15L33N
Capacity	1.5 Liters
Wattage	1200 Watts
Voltage	230 Volts (AC)
Material	Food-grade Stainless Steel
Color	Silver & Black
Product Dimensions (L x W x H)	21.5L x 15.6W x 20.2H Centimeters
Item Weight	690 Grams
Special Features	Automatic Shut-Off, Indicator Light, Cool-touch handle, Wide mouth design, Concealed heating element
Included Components	Electric Kettle, Instruction Manual



Image: Dimensional overview of the Usha Electric Kettle.

Warranty and Support

Warranty Information

This Usha Electric Kettle comes with a**1-year warranty** on the product from the date of purchase. Please retain your purchase receipt or invoice as proof of purchase for any warranty claims.

The warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, accident, alteration, neglect, improper installation, or unauthorized repair.

Customer Support

For any queries, service requests, or warranty claims, please contact Usha Customer Service:

- **Manufacturer:** Usha International Limited
- **Address:** Plot No.15, Institution area, Sector -32, Gurugram, Haryana-122 001, India

- **Telephone:** +91-124-4583106
- You can also visit the official USHA Store on Amazon for more information and product updates.

Video Guide

Watch this official video for a visual overview of the Usha Electric Kettle's features and operation.

Your browser does not support the video tag.

Video: An overview of the Usha Electric Kettle's design, key features, and basic usage. (Note: Actual video URL not provided in data, using placeholder.)

© 2026 USHA International Limited. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question