Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Allimity W550023U2

Allimity Replacement Remote Control User Manual

For Models: W550023U2, W550032DT, 32HD19WSTV, INTV-32L, S330, XTV-4090, EAS-ELECTRIC E32SL702, S55U4K19, S55U4K20, S3220V, 50S201B, and other compatible models.

Introduction

This manual provides essential information for the setup, operation, and maintenance of your Allimity Replacement Remote Control. This remote is designed to function as a direct replacement for various TV models, requiring no complex programming. Simply insert batteries, and it is ready for use.

1. Setup

1.1 Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two new AAA alkaline batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

1.2 Initial Use

This replacement remote control requires no programming. Once batteries are correctly installed, it is ready to operate your compatible television. Point the remote directly at your TV's infrared receiver.

1.3 Compatible Models

This remote control is compatible with the following television models:

- W550023U2
- W550032DT
- 32HD19WSTV
- INTV-32L

- S330
- XTV-4090
- EAS-ELECTRIC E32SL702
- S55U4K19
- S55U4K20
- S3220V
- 50S201B
- ODL32850FV-TIB
- ODL32750FV-TIB
- ODL32750FV-TIW
- ODL55750UV-TIB
- ODL65750UV-TIB
- ODL40691F-TIB
- ODL40690UV-TIB



Figure 1: Top-down view of the Allimity Replacement Remote Control. This image shows the layout of the buttons, including the numeric keypad, volume and channel controls, navigation pad, and dedicated app buttons for Netflix, YouTube, and Prime Video.

2. Operating Instructions

The remote control functions identically to your original TV remote. Ensure a clear line of sight between the remote and your television's infrared receiver for optimal performance.

2.1 Basic Functions

- **Power Button ( ):** Turns the TV on or off.
- **Numeric Keypad (0-9):** Selects channels directly.
- **Volume Up/Down (V+/V-):** Adjusts the sound level.
- **Channel Up/Down (P+/P-):** Changes TV channels sequentially.
- **Mute Button ( ):** Mutes or unmutes the TV sound.
- **Input/Source Button ( ):** Cycles through available input sources (HDMI, AV, etc.).

2.2 Navigation and Menu Controls

- **Directional Pad (Up, Down, Left, Right):** Navigates through menus and options.
- **OK Button:** Confirms selections or opens menus.
- **Back Button:** Returns to the previous screen or menu.
- **Exit Button:** Closes the current menu or application.
- **Info Button (i):** Displays information about the current program or input.

2.3 Dedicated App Buttons

The remote includes dedicated buttons for quick access to popular streaming services:

- **Netflix Button:** Launches the Netflix application.
- **YouTube Button:** Launches the YouTube application.
- **Prime Video Button:** Launches the Amazon Prime Video application.



Figure 2: Angled view of the Allimity Replacement Remote Control. This perspective highlights the ergonomic design and the placement of the dedicated streaming service buttons at the bottom.

3. Maintenance

3.1 Cleaning

To clean your remote control, gently wipe it with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the remote's surface or internal components.

3.2 Battery Replacement

Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries. Do not mix old and new batteries, or different types of batteries.

3.3 Storage

Store the remote control in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage.

4. Troubleshooting

4.1 Remote Not Responding

- **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace with fresh AAA alkaline batteries.
- **Line of Sight:** Make sure there is a clear path between the remote's infrared emitter and the TV's IR receiver. Obstructions can block the signal.
- **Distance:** Operate the remote within its effective range (up to 10 meters).
- **TV Compatibility:** Verify that your TV model is listed as compatible in Section 1.3.

4.2 Specific Buttons Not Working

- **Clean Buttons:** Ensure no dirt or debris is lodged around the unresponsive buttons.
- **Battery Check:** Low batteries can sometimes cause intermittent button functionality. Replace them.

4.3 Limited Range

- **Battery Strength:** Weak batteries are a common cause of reduced range. Replace them.
- **Interference:** Bright lights, especially fluorescent or LED lighting, can sometimes interfere with IR signals. Try operating the remote in different lighting conditions.

5. Specifications

Feature	Detail
Brand	Allimity
Model Name	W550023U2
Product Dimensions	4 x 12 x 0.3 cm
Item Weight	90 grams
Connectivity Technology	Infrared (IR)
Special Feature	Infrared
Color	Black/White
Number of Buttons	18
Maximum Range	10 meters
Power Source	2 x AAA Alkaline Batteries (not included)

6. Warranty and Support

6.1 Warranty Information

Specific warranty details for this product are not provided in the available information. Please refer to the retailer or manufacturer's website for current warranty terms and conditions.

6.2 Customer Support

If you encounter issues not covered in this manual or require further assistance, please contact the retailer where you purchased the product or visit the Allimity official website for customer support options.

© 2023 Allimity. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHM2H6Y8

More documents and user manuals: **https://manuals.plus/**