Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEYOND HEAT BH-1500W

BEYOND HEAT 1500W Convection Baseboard Heater User Manual

Model: BH-1500W

1. Introduction

Thank you for choosing the BEYOND HEAT 1500W Convection Baseboard Heater. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new heater. Please read all instructions carefully before use and retain this manual for future reference.
This electric baseboard heater is designed to provide supplemental heat for indoor spaces, offering silent operation and an adjustable thermostat for personalized comfort.

2. Important Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, read and understand all instructions before using this heater.

- **ETL Approved:** This heater is ETL approved for use in the US, ensuring it meets recognized safety standards.
- **Overheat Protection:** The heater is equipped with an automatic overheat protection system that will shut off the unit if it reaches an unsafe temperature. If this occurs, unplug the heater, allow it to cool, and then plug it back in.
- **Tip-Over Protection:** A safety tip-over switch automatically turns off the heater if it is accidentally knocked over. Ensure the heater is placed on a stable, level surface.
- **Surface Temperature:** The top air outlet and certain surfaces of the heater can become hot during operation. Avoid direct contact with hot surfaces to prevent burns. Keep children and pets away from the heater.
- **Placement:** For optimal safety and performance, place the heater on a hard, non-combustible surface such as tile or concrete floors. Do not place on carpet or rugs. Maintain adequate clearance from walls, furniture, drapes, and other combustible materials (minimum 3 feet from the front and sides).
- **Power Supply:** Ensure the electrical outlet and wiring are suitable for the heater's power requirements (110V, 12.5 Amps). Do not overload circuits.
- **Ventilation:** Do not block air inlets or outlets. Ensure proper airflow around the heater.
- **Moisture:** Do not use the heater in wet or damp locations, such as bathrooms or laundry areas.

3. Product Features

- **Adjustable Thermostat:** Features two heat settings (750W/1500W) and an adjustable thermostat to customize warmth.
- **Overheat & Tip-over Protection:** Includes a stay-cool body with dent-proof end panels, a safety tip-over switch, and an overheat protection system for enhanced safety.
- **Quiet Operation:** Utilizes convection heating technology for silent operation, suitable for bedrooms, offices, and other quiet indoor spaces.
- **Compact & Portable:** With dimensions of 29.25"D x 5.25"W x 9.25"H, this portable heater fits easily into various rooms and provides efficient heating for small to medium-sized areas.
- **Safe & Reliable:** ETL approved for the US market, ensuring high standards of safety and reliability.

4. Setup and Placement

1. **Unpack:** Carefully remove the heater from its packaging. Retain packaging for off-season storage.
2. **Inspect:** Check the heater for any signs of damage. Do not operate a damaged heater.
3. **Placement:**
    - Place the heater on a firm, level surface.
    - Ensure there is at least 3 feet (0.9 meters) of clearance from any walls, furniture, curtains, or other combustible materials.
    - Avoid placing the heater in high-traffic areas where it could be easily tripped over.
    - Do not place the heater directly under a power outlet.
4. **Power Connection:** Plug the heater directly into a 110V AC, 60Hz electrical outlet. Do not use extension cords or power strips.



Front view of the BEYOND HEAT 1500W Convection Baseboard Heater, showcasing its sleek white design and manual control knobs for thermostat and heat settings.



Visual representation of the heater's dimensions: approximately 30 inches (76.2 cm) in length, 10.62 inches (26.97 cm) in height, and 6.6 inches (16.76 cm) in depth, highlighting its compact design.

5. Operating Instructions

Your BEYOND HEAT baseboard heater features intuitive controls for easy operation.

5.1 Manual Controls

- **Power Control Dial:** Located on the right side of the unit. Turn the dial to select between 750W (Low) and 1500W (High) heat settings.
- **Thermostat Control:** Adjust the thermostat dial to your desired temperature. The heater will cycle on and off to maintain the set temperature.

5.2 Remote Control (if applicable)

The heater may come with a remote control for convenient adjustment of settings from a distance. Functions typically include:

- **ON/OFF:** Power the unit on or off.
- **MODE:** Cycle through heat settings (e.g., 750W, 1500W).
- **TEMP UP/DOWN:** Adjust the desired temperature.
- **TIMER:** Set an operating timer (refer to remote control instructions for specific timer functions).
- **FLAME:** Activate or deactivate the flame effect (if available on your model). The flame effect can often be used independently of the heating function.



An illustration demonstrating the convection heating technology of the baseboard heater, effectively warming a room up to 200 sq ft with 1500W power.



An illustration highlighting the silent operation and convection heating technology, distributing warmth evenly and quietly throughout the room, ideal for bedrooms and offices.



Detailed graphic explaining the heater's controls, including the power control dial for 750W and 1500W settings, the thermostat control, and the power outlet location.

6. Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or allow water to drip into the interior of the heater.
- **Storage:** When not in use, store the heater in a cool, dry place, preferably in its original packaging.
- **No User-Serviceable Parts:** Do not attempt to open or repair the heater yourself. Refer all servicing to qualified personnel.

7. Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit. Tip-over switch activated. Overheat protection activated. Thermostat set too low.	Check power cord connection and wall outlet. Ensure heater is on a stable, level surface. Unplug, allow to cool, then plug back in. Increase thermostat setting.
Heater not producing enough heat.	Heat setting too low. Room size too large for heater capacity. Drafts or poor insulation.	Select 1500W (High) setting. Ensure heater is appropriate for the room size (up to 150 sq ft primary, 750 sq ft secondary). Seal windows/doors, improve insulation.
Heater cycles on and off frequently.	Thermostat setting is close to ambient room temperature.	This is normal operation. Adjust thermostat to a slightly higher or lower setting if desired.

8. Specifications

Feature	Specification
Brand	BEYOND HEAT
Model Number	BH-1500W
Power Output	750W / 1500W
Voltage	110 Volts
Amperage	12.5 Amps
Product Dimensions	29.25"D x 5.25"W x 9.25"H
Item Weight	6.19 pounds
Heating Coverage	150 ft² Primary, 750 ft² Secondary
Special Features	Overheat Protection, Portable, Tip-Over Protection, Adjustable Thermostat, Silent Operation
Fuel Type	Electric
Indoor/Outdoor Usage	Indoor
Mounting Type	Floor Mount

9. Warranty and Support

No specific warranty information is provided within this manual. For details regarding warranty coverage, product support, or replacement parts, please contact BEYOND HEAT customer service directly or refer to the product packaging and official website.

© 2025 BEYOND HEAT. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CHMK5K2G

More documents and user manuals: **https://manuals.plus/**