Azwok RC311 FMI3

Azwok RC311 FMI3 Remote Control User Manual

For TCL 4K 3D LED LCD Smart TVs

Introduction

This manual provides instructions for the Azwok RC311 FMI3 replacement remote control. This remote is designed to function with various TCL 4K 3D LED LCD Smart TV models without requiring any programming. It offers a direct replacement for your original remote, ensuring seamless control over your television's functions.

Compatible TV Models

The RC311 FMI3 remote control is compatible with the following TCL TV models:

- L43P1US, L50P1US, L50C1US, L55P1US, L43P2US, L49P2US, L55P2US, L65P2US
- LED49D2930US, L32S4690S, L40S4690FS, L50S5610FS, L50S5600FS
- L55S4690FS, 49D2100, LED49D2100, SMART-LED55D21, 55D2100
- SV-LED55D21S, FT-LED55S21D, L55SD22, DO-1616005, DO-1616356
- 55LED700FRST2, HY55D2100, L55D2100, OR-55SD21, 55D2400
- L43D2100, 43D2100, VGO43LEDT01S, LED43D2100(S), DO-1606977
- DO-1607635, 43XT510, CG-43D2102S, 43E4200

Product Overview

Remote Control Layout

The following image illustrates the layout of the Azwok RC311 FMI3 remote control and its primary buttons.




4 GHI
5 JKL
6 MNO
7 PQRS
8 TUV
9 WXYZ
SOURCE
0 SPACE
HISTORY
VOL
CH
APP
EPG
OK
EXIT
ZOOM-
ZOOM+
TEXT
SLEEP
PRE-CH
FAV
LIST
CC/LANG
REC
SUBTITLE
RC311 FMI3

A full view of the black Azwok RC311 FMI3 remote control. It features a standard layout with number keys, navigation buttons, volume and channel controls, and dedicated buttons for smart TV functions like APP, Home, and EPG, along with media playback controls.

Button Functions

- **Power (Red Circle with Line)**: Turns the TV on or off.
- **3D**: Activates or deactivates 3D mode (if supported by TV).
- **TV**: Switches to TV input mode.
- **Number Buttons (0-9)**: Direct channel selection or inputting numbers.
- **SOURCE**: Selects input sources (HDMI, AV, etc.).
- **HISTORY**: Accesses recently viewed channels or content.
- **VOL +/-**: Adjusts the volume level.
- **Mute (Speaker with X)**: Mutes or unmutes the TV audio.
- **CH +/-**: Changes channels up or down.
- **Info (i)**: Displays program information.
- **APP**: Launches the Smart TV application menu.
- **Home (House icon)**: Returns to the Smart TV home screen.
- **EPG**: Displays the Electronic Program Guide.
- **Navigation Arrows (Up, Down, Left, Right)**: Navigates through menus and options.
- **OK**: Confirms selections.
- **Back (Curved Arrow)**: Returns to the previous menu or screen.
- **Menu (Three Horizontal Lines)**: Opens the main menu.
- **EXIT**: Exits the current menu or application.
- **ZOOM-** / **ZOOM+**: Adjusts screen zoom.
- **TEXT**: Accesses Teletext (if available).
- **SLEEP**: Sets the sleep timer.
- **PRE-CH**: Returns to the previous channel.
- **FAV**: Accesses favorite channels.
- **LIST**: Displays a list of channels or content.
- **Color Buttons (Red, Green, Yellow, Blue)**: Functions vary by context or application.
- **ODLANG**: Selects audio language.
- **REC**: Starts recording (if supported by TV and external storage).
- **SUBTITLE**: Toggles subtitles on or off.
- **Media Playback Controls (Rewind, Play/Pause, Fast Forward, Stop)**: Controls media playback.

Setup

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover downwards or in the direction indicated by an arrow to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery cover by sliding it back into position until it clicks securely.

Initial Use

The Azwok RC311 FMI3 remote control is designed for immediate use with compatible TCL TVs. No programming or pairing is required. Once batteries are correctly installed, the remote is ready to operate your television.

Operating Instructions

Basic Operation

Point the remote control directly at the infrared receiver on your TCL TV. Ensure there are no obstructions between the remote and the TV.

- **Power On/Off**: Press the **Power** button.
- **Channel Selection**: Use the **CH +/-** buttons to cycle through channels, or enter a channel number directly using the **Number Buttons**.
- **Volume Adjustment**: Use the **VOL +/-** buttons to increase or decrease the volume.
- **Input Source**: Press the **SOURCE** button to cycle through available input sources (e.g., HDMI 1, AV, TV).
- **Smart TV Functions**: Use the **APP** or **Home** buttons to access your TV's smart features and applications.

Maintenance

Cleaning

To clean the remote control, gently wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive materials, or chemical solvents, as these may damage the remote's surface or internal components.

Battery Care

- Replace batteries when the remote's response becomes sluggish or inconsistent.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote control will not be used for an extended period to prevent leakage.
- Dispose of used batteries according to local regulations.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries.	Check battery orientation. Replace with fresh batteries.
Remote range is poor.	Obstruction between remote and TV.	Ensure a clear line of sight to the TV's infrared sensor.
Specific buttons not working.	Button stuck or internal issue.	Gently press the button multiple times. If issue persists, contact support.
TV not turning on/off.	TV's power cord unplugged.	Verify the TV is plugged into a working power outlet.

Specifications

Product Specifications

- **Model**: RC311 FMI3
- **Brand**: Azwok
- **Connectivity Technology**: Infrared (IR)
- **Special Feature**: No Programming Required
- **Compatible Devices**: TCL 4K 3D LED LCD Smart TVs (Specific models listed in Introduction)
- **Power Source**: 2 x AAA Batteries (not included)

Warranty and Support

Warranty Information

This Azwok RC311 FMI3 remote control comes with a 12-month warranty from the date of purchase. This warranty covers manufacturing defects under normal use.

Customer Support

If you encounter any issues with your remote control, cannot find your specific TV model in the compatibility list, or require further assistance, please contact Azwok customer support. We are available to help you choose the correct remote or troubleshoot any problems.

Please refer to your purchase documentation for specific contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question