DG11J1-91

Instruction Manual for DG11J1-91 Replacement Remote Control

For Hisense, Garrison, NOMA, Comfort Star, Kelon, Ljvetech Portable Air Conditioners

Introduction

This manual provides instructions for the use and maintenance of your new DG11J1-91 replacement remote control. This remote is designed to operate various portable air conditioner models from brands such as Hisense, Garrison, NOMA, Comfort Star, Kelon, and Ljvetech. Please note that as a replacement unit, some functions may differ or not be fully compatible with your original air conditioner's features.

Product Overview



Figure 1: Front view of the DG11J1-91 remote control, displaying the LCD screen and all operational buttons including ON/OFF, Mode, Fan, Swing, Sleep, Super, Smart, IFeel, Dimmer, Timer On, Timer Off, and Clock, along with temperature adjustment arrows.



Figure 2: Back view of the DG11J1-91 remote control, clearly showing the model number "DG11J1-91" printed on the casing, along with the battery compartment cover.

Setup

1. Battery Installation

1. Locate the battery compartment on the back of the remote control. Refer to Figure 2.
2. Slide the battery compartment cover downwards to open it.
3. Insert two (2) AAA batteries, ensuring the positive (+) and negative (-) ends align with the markings inside the compartment.
4. Close the battery compartment cover by sliding it back into place until it clicks securely.

2. Initial Use

This remote control is pre-programmed for compatibility with the specified air conditioner models. No complex pairing or setup is typically required. Simply install the batteries and point the remote towards your air conditioner's receiver to begin operation.

Operating Instructions

Ensure there is a clear line of sight between the remote control and the air conditioner's receiver for optimal performance.

Button Functions:

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Fan, Dry, Heat - depending on AC unit features).
- **FAN:** Adjusts fan speed (e.g., Auto, Low, Medium, High).
- **SWING:** Activates or deactivates the louver swing function.
- **SLEEP:** Engages sleep mode for quiet operation and energy saving.
- **SUPER:** Activates rapid cooling or heating (turbo mode).
- **SMART:** Automatically selects the optimal operating mode based on room temperature.
- **IFEEL:** Activates the "I Feel" function, which senses the temperature at the remote's location.
- **DIMMER:** Adjusts the brightness of the air conditioner's display.
- **TIMER ON:** Sets a timer for the air conditioner to turn on automatically.
- **TIMER OFF:** Sets a timer for the air conditioner to turn off automatically.
- **CLOCK:** Sets the current time on the remote's display.
- **Temperature Up/Down Arrows (▲ / ▼):** Adjusts the desired temperature setting.

Basic Operation:

1. **Turning On/Off:** Press the **ON/OFF** button.
2. **Adjusting Temperature:** Use the ▲ (Up) or ▼ (Down) arrows to set your desired temperature.
3. **Changing Mode:** Press the **MODE** button repeatedly to cycle through available operating modes.
4. **Adjusting Fan Speed:** Press the **FAN** button repeatedly to select the desired fan speed.

Maintenance

Battery Replacement:

Replace batteries when the remote's display becomes dim or the remote becomes unresponsive. Always replace both batteries simultaneously with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

Cleaning:

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

Storage:

If the remote control will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Remote not responding.	Dead or incorrectly installed batteries. Obstruction between remote and AC unit. Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Move closer to the AC unit.
Some functions do not work.	The remote is a replacement and may not support all original AC unit functions.	This is expected for a replacement remote. Verify if the function is supported by your specific AC model and this replacement remote.
Display is dim or blank.	Low battery power.	Replace batteries.

Specifications

- **Model:** DG11J1-91
- **Material:** ABS Plastic
- **Color:** Black or White (color may vary)
- **Power Source:** 2 x AAA Batteries (not included)
- **Compatibility:** Designed for various Hisense, Garrison, NOMA, Comfort Star, Kelon, Ljvetech Portable Air Conditioners that originally used a DG11J1-91 series remote.
- **Special Feature:** Ergonomic design

Warranty and Support

Specific warranty information for this replacement remote control is not provided in this manual. For details regarding warranty coverage, returns, or technical support, please contact the seller or the point of purchase directly. It is recommended to retain your purchase receipt for any warranty claims.

© 2023 Generic. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question