Earto Earto Galaxy Tab Keyboard Case

Earto Samsung Galaxy Tab Keyboard Case User Manual

For Galaxy Tab S9 11-inch (Models: SM-X710 / X716B / X718U)

Introduction

Thank you for choosing the Earto Samsung Galaxy Tab Keyboard Case. This manual provides detailed instructions to help you set up, operate, and maintain your keyboard case, ensuring optimal performance and longevity. Please read this manual thoroughly before use.

Compatibility

This Earto Keyboard Case is specifically designed for the**Samsung Galaxy Tab S9 11-inch 2023** models. It is compatible with the following model numbers:

- SM-X710
- SM-X716B
- SM-X718U

Please verify your tablet's model number to ensure compatibility.



Image: Compatibility chart for Earto Keyboard Case. This image illustrates that the keyboard case is exclusively compatible with the Galaxy Tab S9 11-inch (SM-X710 / X716B / X718U) and not with other tablet models like Galaxy Tab S8 11-inch or Galaxy Tab S7 11-inch.

Setup Instructions

1. **Attaching the Tablet:**
   Carefully place your Samsung Galaxy Tab S9 11-inch into the protective case. Ensure all ports and buttons align correctly with the case's cutouts. The case is designed for a snug fit to protect your device.
2. **Attaching the Keyboard:**

The keyboard is magnetic and detachable. Align the keyboard with the magnetic strip at the bottom edge of the case. It will snap into place securely. This allows for easy attachment and removal for transport or storage.



Image: Detachable Magnetic Keyboard. This image shows the keyboard being magnetically attached to the tablet case, highlighting its portability and ease of storage.

3. **Charging the Keyboard:**
   Before first use, fully charge the keyboard. Connect the provided Type-C charging cable to the keyboard's charging port and a suitable USB power adapter. A full charge takes approximately 2-3 hours and provides up to 70 hours of continuous use.

4. **Bluetooth Pairing:**

To connect the keyboard to your tablet:

- Turn on the keyboard using the power switch.
- On your Galaxy Tab S9, go to **Settings** > **Connected devices** > **Bluetooth** and turn Bluetooth on.
- The keyboard will appear as an available device (e.g., "Bluetooth Keyboard"). Tap on it to pair.
- If prompted, enter the pairing code displayed on your tablet using the keyboard and press **Enter**.
- The keyboard supports **2 Bluetooth channels**. Press **Fn+Q** or **Fn+W** to switch between paired devices quickly.

5. **S Pen Charging:**
   The case features a dedicated slot on the back for your S Pen. This slot allows for magnetic attachment and wireless charging of the S Pen while it is stored.



Image: S Pen Charging Support. This image demonstrates the magnetic attachment and wireless charging capability for the S Pen on the back of the keyboard case.

6. **Adjusting Viewing Angles:**
   The premium case design includes 3 different horizontal stand angle grooves. Adjust the tablet's position to achieve a comfortable viewing angle for typing, watching, or drawing.



Image: Multiple Viewing Angles. This image illustrates the three adjustable stand angles (110°, 120°, 130°) provided by the case for comfortable use.

Operating Instructions

Keyboard Functions

- **Shortcut Keys:** The keyboard is equipped with universal shortcut keys for quick access to functions such as volume control, screen brightness adjustment, and music track navigation. These keys are typically located on the top row of the keyboard.

- **Enlarged Keycaps:** The keyboard features enlarged keycaps for a comfortable and precise typing experience during daily use.
- **Multi-Device Switching:** Use **Fn+Q** or **Fn+W** to quickly switch between two paired Bluetooth devices.

Touchpad Functions

The integrated touchpad allows for multi-gesture control, enhancing navigation on your tablet. The touchpad supports Android gestures for improved usability.

- **Activating/Deactivating Touchpad:** To enable or disable the touchpad function, press**Fn + Spacebar** simultaneously.
- **Multi-Gesture Control:** Utilize standard Android touchpad gestures for scrolling, zooming, and other navigation tasks.



Image: Multifunctional Touchpad. This image shows a user operating the keyboard case with its integrated touchpad, illustrating its functionality for improved work efficiency.



Image: Touchpad Activation. This close-up image of the keyboard highlights the 'Fn' key and 'Spacebar', indicating their use to activate or deactivate the touchpad function.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the keyboard and case. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- **Battery Care:** To prolong battery life, avoid fully discharging the keyboard battery frequently. Charge the keyboard

regularly, even if not in constant use. Store the keyboard in a cool, dry place when not in use for extended periods.

- **Storage:** When not in use, keep the keyboard case closed to protect both the tablet and the keyboard from dust and scratches.

Troubleshooting

- **Keyboard Not Pairing:**
  - Ensure the keyboard is turned on and fully charged.
  - Make sure Bluetooth is enabled on your tablet.
  - Forget the device from your tablet's Bluetooth settings and attempt to pair again.
  - Restart both the keyboard and your tablet.
- **Keyboard Not Typing:**
  - Check if the keyboard is successfully paired via Bluetooth.
  - Ensure the keyboard battery is not depleted.
  - Verify that the touchpad is not accidentally activated if it interferes with typing (press **Fn + Spacebar**).
- **Touchpad Not Responding:**
  - Ensure the touchpad is activated (press **Fn + Spacebar**).
  - Check Bluetooth connection.
  - Clean the touchpad surface for any obstructions.
- **Battery Not Charging:**
  - Verify the charging cable is securely connected to both the keyboard and the power source.
  - Try a different Type-C charging cable or USB power adapter.
  - Ensure the power source is functional.

Specifications

Brand	Earto
Compatible Devices	Samsung Galaxy Tab S9 11-inch (SM-X710/X716B/X718U)
Connectivity Technology	Bluetooth
Keyboard Layout	QWERTZ
Number of Keys	78
Special Features	Integrated Smart Touchpad, Detachable Magnetic Keyboard, S Pen Holder with Wireless Charging, Multi-Angle Stand, Shortcut Keys
Material	Acrylonitrile Butadiene Styrene (ABS), Polyurethane (PU)
Product Dimensions	27 x 18.5 x 2.5 cm

Item Weight	790 g
Battery Type	1 Lithium Polymer battery (included)
Battery Energy Content	0.96 Watt Hours
Charging Time	2-3 hours
Continuous Working Time	Up to 70 hours
Operating System	Android

Warranty Information

Earto products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Earto website. Keep your proof of purchase for any warranty claims.

Customer Support

If you encounter any issues or have questions regarding your Earto Samsung Galaxy Tab Keyboard Case that are not covered in this manual, please contact Earto customer support. Contact details can typically be found on the product packaging or the official Earto website.
For online resources and frequently asked questions, please visit the Earto support page.

© 2023 Earto. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question