Trundlia TD-AF0032

Trundlia Air Fryer 6.3 Quart

Model: TD-AF0032

User Manual

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for assistance.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Ensure the appliance is placed on a stable, level, heat-resistant surface.
- Provide adequate space around the appliance for proper ventilation.
- Do not block any ventilation openings.

Product Overview

The Trundlia 6.3 Quart Air Fryer utilizes 360° circulating hot air technology to cook food with little to no oil, resulting in crispy textures and reduced fat content. It features an all-metal design, a large LCD touch control panel, and a nonstick basket for easy use and cleaning.

Components

- Main Unit (Housing)
- Control Panel (LCD Touch Screen)
- Air Inlet
- Air Outlet Vents
- Removable Frying Basket
- Crisper Plate (inside basket)
- Handle



Image: Trundlia 6.3 Quart Air Fryer. This image displays the main unit of the air fryer with its digital control panel and the frying basket partially pulled out, containing cooked french fries.

Key Features

- **Capacity:** 6.3 Quarts (approximately 6.3 liters) for cooking larger meals.
- **Power:** 1500 Watts for efficient heating.
- **Temperature Range:** 175℉-400℉ (80℃-200℃).

- **Control:** Large LCD touch screen for intuitive operation.
- **Presets:** 8 pre-programmed cooking options for common dishes.
- **Nonstick Basket:** ETL-certified, PFOA-free, and BPA-free for safe and easy cleaning.
- **Circulation:** 360° hot air technology for even cooking and crispy results.



Image: 6.3-Quart Basket Capacity. This image highlights the large capacity of the air fryer basket, illustrating it can hold a 4-lb whole chicken, 2-lb/18 chicken wings, or an 8-inch pizza.

Before First Use

1. **Unpack:** Carefully remove all packaging materials, including any stickers or labels.
2. **Clean Components:** Wash the frying basket and crisper plate thoroughly with warm, soapy water. Rinse and dry completely. The basket and crisper plate are dishwasher safe.
3. **Wipe Main Unit:** Wipe the exterior of the air fryer with a damp cloth. Do not immerse the main unit in water.
4. **Initial Run (Optional):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 350°F (175°C) to eliminate any manufacturing odors. Ensure the room is well-ventilated during this process.

Setup

1. **Placement:** Place the air fryer on a stable, level, heat-resistant surface. Ensure there is at least 6 inches (15 cm) of clear space around the back and sides of the appliance for proper air circulation.
2. **Insert Crisper Plate:** Place the crisper plate inside the frying basket.
3. **Insert Basket:** Slide the assembled frying basket back into the main unit until it clicks securely into place.
4. **Power Connection:** Plug the power cord into a grounded wall outlet. The air fryer will enter standby mode, and the display will illuminate.

Operating Instructions

Control Panel Overview

The Trundlia Air Fryer features an intuitive LCD touch control panel. The display shows temperature, time, and various preset icons.

- **Power Button:** Turns the unit on/off and starts/pauses cooking.
- **Temperature Control (+/-):** Adjusts cooking temperature.
- **Time Control (+/-):** Adjusts cooking time.
- **Preset Icons:** Selects pre-programmed cooking modes.



Image: 8 Preset Cooking Options. This image shows the air fryer's control panel with icons representing the 8 preset cooking functions: cake, fish, chicken, shrimp, chicken thigh, pizza, steak, and fries.

Basic Operation

1. **Prepare Food:** Place ingredients into the frying basket, ensuring not to overfill. For best results, food should be in a single layer or shaken frequently.
2. **Power On:** Press the Power button to turn on the air fryer.
3. **Set Temperature and Time:**
    - Use the Temperature (+/-) buttons to set the desired cooking temperature (175℉-400℉).
    - Use the Time (+/-) buttons to set the desired cooking time.
4. **Start Cooking:** Press the Power button again to start the cooking process. The fan and heating element will activate.
5. **Shake/Flip Food (Optional):** For even cooking, especially with smaller items like fries or chicken wings, pull out the basket halfway through the cooking time and shake or flip the food. The air fryer will pause automatically when the basket is removed and resume when reinserted.

6. **End of Cooking:** The air fryer will beep when the cooking time is complete and automatically shut off. Carefully pull out the basket and remove the cooked food.

Using Presets

The air fryer includes 8 convenient presets for common dishes. To use a preset:

1. **Power On:** Press the Power button.
2. **Select Preset:** Tap the desired preset icon (e.g., Fries, Chicken) on the control panel. The air fryer will automatically set the recommended temperature and time for that food type.
3. **Adjust (Optional):** You can adjust the preset temperature and time using the Temperature (+/-) and Time (+/-) buttons if needed.
4. **Start Cooking:** Press the Power button to begin cooking.

Cooking Guide

The following table provides general guidelines for cooking various foods. Cooking times and temperatures may vary based on food quantity, size, and desired crispiness. Always ensure food is cooked to a safe internal temperature.

Food Item	Temperature	Time	Notes
French Fries (frozen)	400°F (200°C)	15-20 min	Shake halfway
Chicken Wings	380°F (195°C)	20-25 min	Flip halfway
Steak (1 inch thick)	375°F (190°C)	10-15 min	Flip halfway
Fish Fillets	350°F (175°C)	12-18 min	
Pizza (frozen, 8-inch)	375°F (190°C)	8-12 min	
Vegetables (broccoli, asparagus)	375°F (190°C)	10-15 min	Toss with a little oil

Tips for Best Results:

- **Preheating:** For optimal results, preheat the air fryer for 3-5 minutes before adding food.
- **Oil Usage:** While air frying requires little to no oil, a light spray or toss with oil can enhance crispiness and flavor for some foods.
- **Do Not Overfill:** Avoid overcrowding the basket, as this can prevent even cooking and crisping. Cook in batches if necessary.
- **Shake/Flip:** Regularly shake or flip food items during cooking to ensure all sides are exposed to the hot air.

Cleaning and Maintenance

Regular cleaning of your air fryer will ensure optimal performance and extend its lifespan. Always unplug the appliance and allow it to cool completely before cleaning.

Cleaning the Frying Basket and Crisper Plate

- The frying basket and crisper plate are made with a nonstick coating and are dishwasher safe.
- Alternatively, wash them with warm, soapy water and a non-abrasive sponge.
- For stubborn food residue, soak the basket and plate in warm, soapy water for about 10-15 minutes before cleaning.
- Rinse thoroughly and dry completely before reassembling or storing.



Image: Easy to Cleanup. This image shows the air fryer's nonstick basket and crisper plate placed inside a dishwasher, indicating they are dishwasher safe for convenient cleaning.

Cleaning the Main Unit

- Wipe the exterior of the air fryer with a damp cloth. Do not use abrasive cleaners or scouring pads.
- Clean the interior of the appliance with a damp cloth and mild detergent if necessary. Ensure no water enters the air inlet or outlet vents.
- For the heating element, gently wipe with a damp cloth to remove any food residue. Do not scrub or use harsh chemicals.
- Ensure all parts are completely dry before plugging in or storing the appliance.

Troubleshooting

If you encounter any issues with your Trundlia Air Fryer, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; unit not assembled correctly.	Ensure the power cord is securely plugged into a grounded outlet. Check if the outlet is working. Ensure the frying basket is fully inserted.
Food is not cooked evenly.	Basket is overcrowded; food not shaken/flipped.	Cook food in smaller batches. Shake or flip food halfway through cooking.
Food is not crispy.	Too much moisture; not enough oil (for some foods); temperature too low.	Pat food dry before cooking. Lightly spray or toss with oil. Increase temperature or cooking time slightly.
White smoke coming from the appliance.	Grease residue from previous use; fatty food cooking; basket overfilled.	Clean the basket and crisper plate thoroughly. Remove excess fat from food. Do not overfill the basket.
Appliance smells like plastic.	First few uses.	This is normal for the first few uses and will dissipate. Ensure good ventilation.

Specifications

- **Model:** TD-AF0032
- **Capacity:** 6.3 Quarts / 6.3 Liters
- **Power:** 1500 Watts
- **Voltage:** 12.5 Volts (AC) *(Note: This value is provided in the source data. Standard household voltage for a 1500W appliance is typically 120V or 240V.)*
- **Temperature Range:** 175℉-400℉ (80℃-200℃)
- **Control Method:** Touch
- **Outer Material:** Metal
- **Nonstick Coating:** Yes (ETL-certified, PFOA-free, BPA-Free)
- **Dishwasher Safe Parts:** Basket, Crisper Plate
- **Product Dimensions:** 7 x 6 x 7 inches
- **Item Weight:** 10.98 pounds
- **UPC:** 741421602373

Warranty and Support

Trundlia products are manufactured with quality and reliability in mind. For warranty information, technical support, or any questions regarding your Trundlia Air Fryer, please contact our customer service team.

Please have your model number (TD-AF0032) and purchase information ready when contacting support.

Contact information (e.g., website, email, phone number) would typically be provided here by the manufacturer.

© 2024 Trundlia. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question