Whirlpool W2I HD526 A

Whirlpool W2I HD526 A Fully Integrated Dishwasher

User Instruction Manual

1. Introduction

Thank you for choosing a Whirlpool appliance. This user manual provides essential information for the safe and efficient operation, installation, and maintenance of your new Whirlpool W2I HD526 A fully integrated dishwasher. Please read these instructions carefully before using the appliance and keep them for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- **General Safety:** This appliance is intended for household use only. Do not allow children to play with the appliance. Supervise children when the dishwasher is in operation.
- **Electrical Safety:** Ensure the voltage and frequency match the ratings on the appliance's rating plate. The appliance must be properly grounded. Do not use extension cords or multiple adapters.
- **Water Safety:** The dishwasher can be connected to both cold and hot water supplies (maximum 60°C). Ensure all water connections are secure to prevent leaks. This model does not feature an Aquastop safety system, but it does have an overflow protection system.
- **Installation Safety:** Installation must be performed by a qualified technician. Ensure the appliance is stable and level using the adjustable feet.

3. Product Overview

The Whirlpool W2I HD526 A is a fully integrated dishwasher designed for seamless integration into your kitchen cabinetry. It offers excellent cleaning and drying performance for up to 14 place settings.



This image displays the Whirlpool W2I HD526 A fully integrated dishwasher with its door open, revealing the upper and lower racks designed for dishes and cutlery. The control panel is visible along the top edge of the door.

Key Features:

- Fully integrated design
- 14 place settings capacity
- Energy efficiency class E
- Adjustable feet for stability
- Integrated display and button controls
- Self-cleaning program
- Delayed start function (up to 12 hours)
- Half-load option
- Salt indicator

4. Installation

Your Whirlpool W2I HD526 A dishwasher is designed for full integration. Professional installation is recommended to ensure proper functioning and safety.

- **Dimensions:** The appliance measures 55 cm (L) x 60 cm (W) x 85 cm (H). Ensure your cabinet opening accommodates these dimensions.
- **Leveling:** Use the adjustable feet to ensure the dishwasher is perfectly level, which is crucial for proper door alignment and operation.
- **Water Connection:** Connect the inlet hose (1.55 m length) to a cold or hot water supply (max 60°C). Connect the drain hose (1.5 m length) to a suitable drain.
- **Electrical Connection:** The power cable is 1.3 m long. Connect the appliance to a grounded 230 Volt power supply.

5. Operating Instructions

Operating your dishwasher is straightforward with its integrated display and button controls.

1. **Loading the Dishwasher:** Load dishes into the upper and lower baskets. The cutlery basket is located in the lower basket. Ensure spray arms are not obstructed.
2. **Adding Detergent and Rinse Aid:** Fill the detergent dispenser with the appropriate amount of dishwasher detergent. Check the salt indicator and refill the salt reservoir if necessary. Fill the rinse aid dispenser as needed.
3. **Selecting a Program:** Use the control buttons to navigate through the available wash programs on the integrated display.
4. **Starting a Program:** Press the Start button to begin the selected wash cycle.
5. **Delayed Start:** To delay the start of a program, select the desired delay time (up to 12 hours) before pressing Start.
6. **Half Load:** If you have fewer dishes, select the half-load option to save water and energy.

6. Wash Programs

Your dishwasher offers 9 different wash programs to suit various needs. The maximum wash temperature is 65°C.

Program Name	Description	Approx. Duration
Daily 50°C	Standard program for daily soiled dishes.	Varies
Eco 50°C	Energy-efficient program for normally soiled dishes.	215 min
Hygiene	High-temperature wash for enhanced hygiene.	Varies
Intensive 65°C	For heavily soiled dishes and pots.	Varies
Pre-wash	Short rinse cycle for dishes that will be washed later.	Varies
Rapid	Quick wash for lightly soiled dishes.	Varies

Program Name	Description	Approx. Duration
Self-Clean 65°C	Program for cleaning the dishwasher itself.	Varies
Silent 50°C	Quiet program for normal soil, ideal for night use.	Varies

7. Maintenance and Cleaning

Regular maintenance ensures optimal performance and longevity of your dishwasher.

- **Self-Cleaning Program:** Use the dedicated 'Self-Clean 65°C' program regularly to clean the interior of the dishwasher and remove grease and limescale buildup.
- **Filter Cleaning:** Periodically check and clean the filters located at the bottom of the dishwasher. Refer to the detailed instructions in your appliance's full manual for filter removal and cleaning.
- **Spray Arms:** Ensure the holes in the spray arms are not clogged. Clean them if necessary.
- **Exterior Cleaning:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners.

8. Troubleshooting

Before contacting service, check the following common issues:

- **Dishwasher Not Starting:** Ensure the door is fully closed, the power cord is plugged in, and the circuit breaker has not tripped.
- **Poor Cleaning Results:** Check if dishes are loaded correctly, spray arms are not blocked, detergent dispenser is filled, and filters are clean. Ensure the correct program is selected for the soil level.
- **Water Not Draining:** Check the drain hose for kinks or blockages. Clean the filters.
- **Water Leaks:** Check hose connections. The appliance has an overflow protection system to prevent major leaks.
- **Salt Indicator On:** Refill the salt reservoir.

If the problem persists after checking these points, please contact customer support.

9. Specifications

Feature	Specification
Model Number	W2I HD526 A
Installation Type	Fully Integrated
Dimensions (L x W x H)	55 x 60 x 85 cm
Weight	37.5 Kilograms
Place Settings	14
Number of Wash Programs	9
Noise Level	46 dB

Feature	Specification
Energy Efficiency Class	E
Voltage	230 Volts
Internal Material	Stainless Steel
Control Type	Push-button
Special Features	Self-cleaning, Delayed Start
Water Fill	Cold, Hot (Max 60°C)
Cable Length	1.3 m
Inlet Hose Length	1.55 m
Drain Hose Length	1.5 m

10. Warranty and Support

For warranty information, please refer to the warranty card included with your appliance or contact your retailer. Information regarding the availability of spare parts for this model is currently unavailable.
For technical support or service inquiries, please contact Whirlpool customer service or your authorized service provider. Always provide the model number (W2I HD526 A) when contacting support.