Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

hisonic BS-SUN-690

Hisonic Bluetooth Children's Headphones User Manual

Model: BS-SUN-690

Introduction

This manual provides comprehensive instructions for the safe and effective use of your Hisonic Bluetooth Children's Headphones. Please read this manual thoroughly before using the product and retain it for future reference.



Image: Hisonic Bluetooth Children's Headphones, featuring a black design with illuminated blue LED lights on the earcups.

Important Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- **Volume Limit:** The headphones feature an integrated volume limit of 85/94dB to protect children's hearing. Avoid prolonged listening at maximum volume.
- **Choking Hazard:** Keep small parts away from young children.
- **Water Resistance:** This product is not water-resistant. Avoid exposure to liquids.
- **Charging:** Use only the provided Type-C charging cable. Do not attempt to charge with damaged cables or chargers.
- **Temperature:** Do not expose the headphones to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- **Cleaning:** Clean only with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- **Disassembly:** Do not attempt to disassemble or modify the headphones. This will void the warranty and may cause damage.



Image: Side of the product packaging displaying a warning in German, advising against prolonged use to protect hearing.

Package Contents

Please check the package for the following items:

- Hisonic Bluetooth Children's Headphones (Model: BS-SUN-690)
- Type-C Charging Cable
- User Manual (this document)
- Audio Cable (3.5mm jack, detachable)



Image: Front of the product box featuring a child wearing the headphones, indicating the target user.

Product Overview

Familiarize yourself with the various parts of your Hisonic headphones:

1. Adjustable Headband
2. Soft Over-Ear Pads
3. Power/Multi-function Button
4. Volume Up / Next Track Button
5. Volume Down / Previous Track Button
6. LED Light Panel (7-colour flashing inverter LEDs)
7. Built-in Microphone
8. Type-C Charging Port
9. 3.5mm Audio Jack
10. Micro SD/TF Card Slot



Image: Front view of the Hisonic headphones, highlighting the location of buttons and ports on the earcup.



Image: A graphic illustrating the comfort features of the headphones, including adjustable headband, soft headband padding, over-ear soft pads, and colorful LED lights.

Setup

1. Charging the Headphones

Before first use, fully charge the headphones. A full charge takes approximately 1.5-2 hours.

- Connect the provided Type-C charging cable to the charging port on the headphones.
- Connect the other end of the cable to a USB power source (e.g., computer USB port, USB wall adapter).
- The LED indicator will show charging status (e.g., red for charging, off or blue for fully charged).

2. Bluetooth Pairing

To connect your headphones wirelessly:

1. Ensure the headphones are charged and powered off.
2. Press and hold the Power/Multi-function button until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "Hisonic BS-SUN-690" (or similar) from the list of devices.

5. Once paired, the LED indicator will flash blue slowly or remain solid blue.

The headphones will automatically attempt to reconnect to the last paired device when powered on.



Image: A graphic highlighting Bluetooth 5.3 technology for stable connections and a connection distance of up to 34 feet.

3. Wired Connection (3.5mm Audio Cable)

For non-Bluetooth devices or when the battery is depleted:

- Connect one end of the 3.5mm audio cable to the audio jack on the headphones.
- Connect the other end to the 3.5mm audio output of your device.
- The headphones will operate in wired mode, and Bluetooth functionality will be disabled.

4. Micro SD/TF Card Playback

To play music directly from a memory card:

- Insert a Micro SD or TF card (with music files) into the designated card slot on the headphones.
- The headphones will automatically switch to Micro SD/TF card playback mode.
- Use the playback controls on the headphones to manage your music.



Image: A graphic demonstrating the wide compatibility of the headphones with various devices, including laptops, tablets, smartphones, and dedicated kids' tablets.

Operating Instructions

Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for approximately 3 seconds until the LED indicator lights up.
- **Power Off:** Press and hold the Power/Multi-function button for approximately 3 seconds until the LED indicator turns off.

Music Playback (Bluetooth/Micro SD/TF Card)

- **Play/Pause:** Short press the Power/Multi-function button.
- **Volume Up:** Short press the "Volume Up / Next Track" button.
- **Volume Down:** Short press the "Volume Down / Previous Track" button.
- **Next Track:** Long press the "Volume Up / Next Track" button.
- **Previous Track:** Long press the "Volume Down / Previous Track" button.

Call Functions (Bluetooth Mode)

When connected via Bluetooth, the built-in microphone allows for hands-free calls.

- **Answer/End Call:** Short press the Power/Multi-function button.
- **Reject Call:** Long press the Power/Multi-function button.
- **Redial Last Number:** Double-press the Power/Multi-function button.



Image: Two children engaged with a laptop while wearing the headphones, emphasizing the high-definition stereo microphone for voice calls and online classes.

LED Light Control

The headphones feature 7-colour flashing inverter LEDs on both sides.

- **Note:** The operation for controlling the LED lights may vary. Please refer to the quick start guide or product packaging for specific instructions on activating or deactivating the colorful LED lights.



Image: A graphic showcasing the headphones with different colorful LED light patterns on the earcups.



Image: A child resting with the headphones, illustrating the subtle glow of the colorful LED lights in a low-light environment.

Maintenance

- **Cleaning:** Wipe the headphones with a soft, dry, lint-free cloth. Do not use liquid cleaners, sprays, or solvents.
- **Storage:** When not in use, store the headphones in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the headphones regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.
Cannot pair via Bluetooth.	• Ensure headphones are in pairing mode (LED flashing blue/red). • Make sure Bluetooth is enabled on your device. • Move headphones closer to your device (within 33 ft/10m). • Forget the device from your phone's Bluetooth list and try pairing again. • Restart both the headphones and your device.
No sound or low volume.	• Check the volume levels on both the headphones and your connected device. • Ensure the headphones are properly paired or the 3.5mm cable is fully inserted. • If using Micro SD/TF card, ensure music files are present and not corrupted.
LED lights are not working.	Ensure the headphones are powered on. If there's a specific control for LEDs, ensure it's activated.

Problem	Possible Solution
Microphone not working.	• Ensure headphones are connected via Bluetooth (microphone does not work in wired mode). • Check microphone settings on your connected device.

Specifications

Feature	Detail
Model	BS-SUN-690
Bluetooth Version	V5.3
Supported Profiles	A2DP, AVRCP, HSP, HFP
Speaker Diameter	40 mm
Speaker Impedance	32 ohm
Frequency Range	24 Hz - 2.4 GHz
RF Range	33 ft (10 meters) without obstacles
Sensitivity	85-94 dB
Volume Limit	85/94 dB
Battery Type	Lithium-ion battery
Battery Capacity	400 mAh
Music Playback Time	Up to 15 hours
Charging Time	1.5-2 hours
Charging Port	Type-C
Weight	186 g
Dimensions	18 x 8.5 x 18 cm
Material	Plastic
Microphone	Built-in, Stereo
Compatibility	Micro SD & TF card, Smartphones, tablets, laptops, car audio systems, devices with 3.5 mm audio jack
Special Features	Foldable design, 7-colour flashing inverter LEDs

Warranty and Support

Hisonic products are designed for reliability and performance. For warranty information or technical support, please contact your retailer or visit the official Hisonic website. Keep your purchase receipt as proof of purchase.

Manufacturer: Shenzhen Hisonic Audio Products Co., Ltd.

Contact Email (as per packaging): pmdhenrich@gmail.com

© 2025 Hisonic. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJ2J8B4N

More documents and user manuals: **https://manuals.plus/**