Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

YOSIMIKA YDK3

YOSIMIKA Keyless Entry Door Lock User Manual

Model: YDK3 | Brand: YOSIMIKA

1. Introduction

Thank you for choosing the YOSIMIKA Keyless Entry Door Lock. This smart deadbolt lock, combined with a mating door knob, offers advanced security and convenience for your home. It features multiple unlocking methods, including keypad passcodes and physical keys, along with smart functions like auto-locking and anti-peeping password protection. This manual provides detailed instructions for installation, operation, maintenance, and troubleshooting to ensure optimal performance and security.



Image 1.1: Overview of the YOSIMIKA Keyless Entry Door Lock highlighting its multi-function and security features such as one-touch locking, 20 user codes, auto-lock, IP54 waterproof rating, and one-time password capability.

2. Product Overview & Components

The YOSIMIKA Keyless Entry Door Lock system includes all necessary components for a complete installation. Please verify that all parts are present before beginning the installation process.

- Smart Deadbolt Lock
- Door Knobs (2)
- Backup Keys (2)
- Accessories (screws, plates, etc.)
- User Manual (this document)



Image 2.1: The YOSIMIKA Keyless Entry Door Lock and accompanying door knob in a satin nickel finish, as installed on a typical interior door.

3. Setup & Installation

The YOSIMIKA Keyless Entry Door Lock is designed for easy installation, typically requiring only a Philips screwdriver. No extra drilling or wiring is needed for most standard door replacements. It is suitable for both left and right-handed doors and accommodates door thicknesses ranging from 1 3/8 inches to 2 3/16 inches (35mm-55mm).

3.1 Before You Begin

- Ensure your door thickness is within the supported range.
- Verify all components are present as listed in Section 2.
- Gather necessary tools: Philips head screwdriver.

- Prepare 4 AA batteries (not included).

3.2 Installation Steps

1. Remove your existing deadbolt and door knob.
2. Install the new latch and strike plate into the door frame.
3. Mount the exterior keypad assembly, ensuring the cable passes through the door.
4. Install the interior mounting plate.
5. Connect the cable from the exterior assembly to the interior assembly.
6. Secure the interior assembly to the mounting plate.
7. Install the door knob assembly.
8. Insert 4 AA batteries into the battery compartment.
9. Perform the door handing process (refer to the specific instructions in the included quick start guide for your model).

4. Operating Instructions

The YOSIMIKA Keyless Entry Door Lock offers multiple convenient ways to secure and access your home.

4.1 Unlocking the Door

- **Passcode Entry:** Enter your 4-10 digit user passcode on the keypad, then press the 'Lock' button (or checkmark/enter button, depending on model). The lock will retract, allowing you to open the door. The lock supports up to 20 user passcodes.
- **Physical Key:** Insert one of the two provided backup keys into the keyhole and turn to unlock.
- **One-Time Passcode:** For temporary visitors, a one-time passcode can be generated. This code becomes invalid after a single use, enhancing security for deliveries or short-term access.



Image 4.1: The lock supports various access methods including up to 20 user passwords, one-time passcodes, and two physical backup keys.



Image 4.2: Illustration of the one-time password feature, allowing temporary access for guests or service providers.

4.2 Locking the Door

- **Auto Lock:** The lock can be programmed to automatically lock after a set period (10-99 seconds) once the door is closed. This feature ensures your door is always secured.
- **One-Touch Locking:** Simply press any button on the keypad for 2 seconds to manually lock the door from the outside.



Image 4.3: Demonstrates the convenience of auto-lock and one-touch locking features, ideal for busy individuals.

4.3 Advanced Security Features

- **Anti-Peeping Password:** To prevent others from guessing your passcode, you can enter random digits before or after your correct passcode. The lock will still recognize the correct sequence within the longer string.
- **Wrong Code Entry Limit:** The lock will temporarily disable the keypad after multiple incorrect passcode attempts, preventing unauthorized access.
- **Low Battery Alert:** The lock will provide an audible or visual alert when the batteries are running low, prompting you to replace them before the lock loses power.
- **Mute Mode:** For quiet operation, the keypad sounds can be silenced.
- **Vacation Mode:** A special mode that disables all user codes for enhanced security when you are away for an extended period.



Image 4.4: Explanation of the anti-peeping password feature, allowing users to input random digits before or after the actual code for privacy.

5. Maintenance

Proper maintenance ensures the longevity and reliable operation of your YOSIMIKA Keyless Entry Door Lock.

- **Battery Replacement:** When the low battery alert activates, replace all four AA batteries promptly. Use high-quality alkaline batteries for best performance.
- **Cleaning:** Clean the keypad and lock body with a soft, dry cloth. Avoid abrasive cleaners, solvents, or harsh chemicals, as these can damage the finish and electronic components.
- **Environmental Protection:** While the lock has an IP54 waterproof rating, protecting it from prolonged direct exposure to extreme weather conditions (heavy rain, snow, direct sunlight) can extend its lifespan.

6. Troubleshooting

If you encounter issues with your YOSIMIKA Keyless Entry Door Lock, please refer to the following common solutions:

- **Lock not responding to keypad:** Check if the batteries are dead or low. Replace them if necessary. Ensure the keypad is clean and free of debris.
- **Lock not locking/unlocking:** Verify that the deadbolt is not obstructed by the door frame. Check if the door is properly aligned. Re-enter the passcode carefully.
- **Passcode not working:** Double-check the passcode. Ensure you are not in vacation mode. Try resetting the lock to factory settings and reprogramming the passcodes (refer to the specific instructions in your quick start guide for reset procedures).
- **Low battery alert persists after battery change:** Ensure new batteries are inserted correctly with the correct polarity.
- **Keypad backlight not working:** Check battery level. If the issue persists, contact customer support.

For more complex issues or if troubleshooting steps do not resolve the problem, please contact YOSIMIKA customer support.

7. Specifications

Detailed technical specifications for the YOSIMIKA Keyless Entry Door Lock (Model: YDK3).

Feature	Specification
Brand	YOSIMIKA
Model Name	YDK3
Lock Type	Keypad Deadbolt
Material	Aluminum
Color	Satin Nickel
Item Dimensions (L x W x H)	10 x 3 x 6 inches
Item Weight	2.77 pounds
Power Source	Batteries (4x AA, not included)
Special Features	Auto-Lock, Back-Lit Keypad, Anti-Peeping Code, One-Time Passcode, Low Battery Alert, Mute Mode, Vacation Mode
Door Thickness Range	1 3/8 inch to 2 3/16 inch (35mm-55mm)
Included Components	Smart Deadbolt Lock, Door Knobs, 2 Backup Keys, Accessories, User Manual
Connectivity Protocol	Keypad
IP Rating	IP54 Waterproof

8. Warranty & Support

YOSIMIKA is committed to providing high-quality products and customer satisfaction. For information regarding product warranty, please refer to the warranty card included with your purchase or visit the official YOSIMIKA website.

If you require technical assistance, have questions about installation, or need to report a defect, please contact YOSIMIKA customer support through the contact information provided on the product packaging or the official website. Please have your model number (YDK3) and purchase details ready when contacting support.

© 2024 YOSIMIKA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJ6JL9F6

More documents and user manuals: **https://manuals.plus/**