ABOFA H008

ABOFA H008 Cordless Vacuum Cleaner User Manual

Model: H008

Introduction

Thank you for choosing the ABOFA H008 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new vacuum cleaner. Please read it thoroughly before first use and retain it for future reference.

Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, please observe the following safety precautions:

- Read all instructions before using this appliance.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material, such as chlorine bleach, ammonia, or drain cleaner.

- Do not use without dust cup and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up hard or sharp objects such as glass, nails, screws, coins, etc.

Package Contents

Please check the package contents upon unboxing. If any items are missing or damaged, contact customer support.

- Main Motor Unit
- Extension Wand
- Motorized LED Floor Brush
- Crevice Tool
- 2-in-1 Dusting Brush
- Wall Mount Bracket
- Power Adapter/Charger
- User Manual



Image: The ABOFA H008 Cordless Vacuum Cleaner shown with its main unit, extension wand, floor brush, crevice tool, and dusting brush, illustrating its various configurations.

Setup and Assembly

Follow these steps to assemble your vacuum cleaner:

1. **Attach the Extension Wand:** Insert the top end of the extension wand into the main motor unit until it clicks securely.
2. **Attach the Floor Brush:** Insert the motorized LED floor brush onto the bottom end of the extension wand until it clicks securely.
3. **Charging the Battery:** Before first use, fully charge the vacuum cleaner for approximately 4-5 hours. Connect the power adapter to the charging port on the main unit or directly to the battery if removable. The charging indicator

light will show the charging status.



Image: A diagram illustrating the assembly process of the vacuum cleaner, showing how the main unit, extension wand, and floor brush connect.

Wall Mount Installation

The wall mount bracket allows for convenient storage and charging.

1. Choose a suitable location near a power outlet.
2. Mark the drilling points for the wall mount bracket.
3. Drill holes and insert wall anchors (if necessary).
4. Secure the wall mount bracket with screws.
5. Hang the vacuum cleaner on the bracket for storage and charging.



Image: Various storage and charging methods for the ABOFA H008 vacuum cleaner, including wall-mounted charging, direct battery charging, and upright storage.

Operating Instructions

Power On/Off and Speed Adjustment

- Press the power button to turn the vacuum cleaner on.
- Press the speed adjustment button to cycle through the 3 available suction speeds (Low, Medium, High).
- Press the power button again to turn the vacuum cleaner off.

Using Attachments

The ABOFA H008 can be configured for various cleaning tasks:

- **Standard Stick Vacuum:** Use with the extension wand and motorized floor brush for cleaning carpets and hard floors. The LED lights on the floor brush illuminate dark areas.

- **Handheld Vacuum:** Detach the extension wand and floor brush to use the main unit with attachments like the crevice tool or 2-in-1 dusting brush for cleaning furniture, car interiors, or tight spaces.
- **Crevice Tool:** Ideal for narrow gaps, corners, and edges.
- **2-in-1 Dusting Brush:** Use the brush mode for delicate surfaces like curtains or keyboards, and the nozzle mode for upholstery or car seats.



Image: The vacuum cleaner being used in different configurations: as a stick vacuum for gaps, a handheld for stairs, a handheld with a brush for sofas, and a handheld for car interiors.

Battery Life

The 2200 mAh battery provides approximately 30-45 minutes of runtime in standard mode and 15-20 minutes in maximum mode. Actual runtime may vary based on suction speed, floor type, and attachment used.



Image: An illustration highlighting the 7x2200mAh high-capacity battery, indicating its long battery life.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Emptying the Dust Cup

- The 1.2L dust collector cup should be emptied when the dust collection light flashes or when it appears full.
- Press the dust cup release button to detach the dust cup from the main unit.
- Hold the dust cup over a trash bin and press the bottom release button to open the flap and empty the contents.
- Reattach the dust cup securely.

Cleaning Filters

The vacuum cleaner uses a HEPA filter system. Filters should be cleaned regularly to maintain suction power.

1. Turn off and unplug the vacuum cleaner.
2. Remove the dust cup.
3. Locate and remove the HEPA filter and mesh filter from inside the dust cup.
4. Tap the filters gently to remove loose dust. For a deeper clean, rinse the filters under cold running water.
5. Allow filters to air dry completely for at least 24 hours before reinserting them. Do not use the vacuum cleaner with wet filters.
6. Reassemble the filters and dust cup.

Cleaning the Motorized Floor Brush

- Regularly check the brush roll for tangled hair or debris.
- Turn off the vacuum cleaner and detach the floor brush.
- Use scissors or a brush to carefully remove any hair or fibers wrapped around the brush roll.
- Ensure the brush roll spins freely before reattaching.

Troubleshooting

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Vacuum cleaner does not turn on.	Battery is not charged.	Charge the battery fully.
	Power button not pressed correctly.	Ensure the power button is pressed firmly.
Low suction power.	Dust cup is full.	Empty the dust cup.
	Filters are dirty or clogged.	Clean or replace the filters. Ensure they are completely dry before reinserting.
	Obstruction in the nozzle, wand, or hose.	Turn off the vacuum and remove any blockages.
Brush roll not spinning.	Hair or debris tangled in the brush roll.	Clean the brush roll.
	Floor brush not properly attached.	Ensure the floor brush is securely connected to the extension wand.
Battery not charging.	Charger not properly connected.	Check all connections.
	Faulty power outlet.	Try a different power outlet.

Specifications

Feature	Detail
Model Number	A-KB-H008

Feature	Detail
Brand	ABOFA
Motor Power	200 W
Suction Power	Up to 25,000 Pa
Number of Speeds	3
Battery Capacity	2200 mAh
Voltage	22.2 Volts
Runtime	30-45 minutes (Standard Mode), 15-20 minutes (Max Mode)
Dust Cup Capacity	1.2 Liters
Filter Type	HEPA Filter
Noise Level	70 Decibels
Item Weight	3.4 kg
Special Features	Cordless, HEPA, Headlight, Lightweight, Wheels
Recommended Surfaces	All floors (carpet, hard floor)

Warranty and Support

ABOFA provides a 12-month customer service warranty for this product. For any questions, concerns, or technical assistance, please contact our customer service team. We offer 24-hour online customer service.
Please retain your proof of purchase for warranty claims.

© 2025 ABOFA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I get a diagram for the main motor of the ABOFA H008 Cordless Vacuum Cleaner, as the floor roller works but the suction motor doesn't run?

The provided user manual for the ABOFA H008 Cordless Vacuum Cleaner does not include detailed diagrams of internal components like the main suction motor. It primarily focuses on assembly, operation, maintenance, and troubleshooting of...

Read full answer