FAKJANK F415

FAKJANK F415 Brushless Motor Drone User Manual

Model: F415 | Brand: FAKJANK

1. Introduction

This manual provides essential information for the safe operation and maintenance of your FAKJANK F415 Brushless Motor Drone. Please read it thoroughly before operating the drone to ensure proper usage and to prevent damage or injury.

2. Safety Guidelines

- Operate the drone in open areas, away from people, animals, buildings, and obstacles.
- Maintain a safe distance from the drone during flight.
- Do not operate in strong winds (rated for Level 4 wind resistance, but caution is advised).
- Ensure batteries are fully charged and properly installed before each flight.
- Avoid flying near airports or restricted airspace.
- Supervise children during operation.
- Regularly inspect the drone for any damage to propellers, motors, or body.

3. Package Contents



Image: Contents of the FAKJANK F415 drone package, including the drone, remote control, two batteries, four propellers, a screwdriver, a USB cable, and a carrying case.

- FAKJANK F415 Drone x 1
- Remote Control x 1
- Modular Batteries x 2
- Spare Propellers x 4
- Screwdriver x 1
- USB Charging Cable x 1
- Carrying Case x 1
- User Manual (this document) x 1

4. Product Overview

The FAKJANK F415 is a compact, foldable drone designed for ease of use and portability. It features a brushless motor for stable flight, a 4K HD camera for aerial photography and videography, and 5GHz WiFi FPV for real-time transmission to your mobile device.



Image: The FAKJANK F415 drone in its unfolded state, showcasing its four propellers and front-facing camera.

Your browser does not support the video tag.

Video: An official FAKJANK product video demonstrating the F415 drone's features, including portability, modular batteries, one-key take-off, optical positioning, speed, waterproof design, adjustable camera, and gesture controls.

Key Features:

- **Brushless Motors:** Provides efficient power and enhanced wind resistance (Level 4).
- **Dual HD Cameras:** Equipped with a main 4K camera and a bottom optical flow camera for stable hovering. The main camera is electrically adjustable up to 90 degrees.
- **5GHz WiFi FPV:** Enables real-time video transmission to your smartphone for an immersive flight experience.
- **Modular Batteries:** Two included batteries offer extended flight time (up to 30 minutes total).
- **User-Friendly Functions:** One-key take-off/landing, headless mode, gesture control for photos/videos, custom path flight, and three-speed modes.
- **Portable Design:** Foldable arms for easy transport in the included carrying case.

5. Setup

5.1 Charging the Batteries

The drone comes with two modular lithium-ion batteries. Ensure both are fully charged before first use.

1. Connect the provided USB charging cable to the battery's micro-USB port.
2. Connect the other end of the USB cable to a standard USB power adapter (not included, typically a cell phone charger block).
3. The charging indicator on the battery will show its status (refer to battery specific indicators for full details). Charging typically takes approximately 2 hours per battery.
4. Disconnect the battery once fully charged.



Image: Two modular batteries for the FAKJANK F415 drone, one shown connected to a USB charging cable. The image highlights the ease of charging and the extended flight time provided by two batteries.

5.2 Installing Batteries and Unfolding the Drone

1. Gently unfold the drone arms until they lock into position.
2. Insert a charged modular battery into the designated compartment on the drone until it clicks securely into place.
3. Press the power button on the drone to turn it on.

5.3 Remote Control Setup

1. Install 3x AAA batteries (not included) into the remote control.
2. Extend the phone holder on the remote control and securely place your smartphone.
3. Power on the remote control.

5.4 App Installation and Connection

1. Download the official FAKJANK drone application from your smartphone's app store (search for "FAKJANK Drone" or scan the QR code in the quick start guide).
2. Turn on the drone and the remote control.
3. On your smartphone, go to Wi-Fi settings and connect to the drone's 5GHz Wi-Fi network (usually named "FAKJANK-F415-XXXX").
4. Open the FAKJANK drone app. The app should automatically connect to the drone, displaying the live camera feed.



Image: The FAKJANK F415 drone remote control with a smartphone mounted, displaying the FPV feed. This illustrates the 5GHz WiFi FPV capability.

6. Operating the Drone

6.1 Pre-Flight Checks and Calibration

- Ensure all drone arms are fully extended and locked.
- Verify propellers are securely attached and undamaged.
- Check battery levels on both drone and remote control.
- Place the drone on a flat, level surface for calibration.
- Follow the in-app instructions for compass and gyroscope calibration before the first flight or if flight stability issues occur.

6.2 Take-Off and Landing

- **One-Key Take-Off:** Press the dedicated one-key take-off button on the remote control or in the app. The drone will automatically ascend to a stable hovering height.
- **Manual Take-Off:** Push both joysticks down and outwards to start the motors. Then, slowly push the left joystick up to ascend.
- **One-Key Landing:** Press the dedicated one-key landing button. The drone will automatically descend and land.
- **Manual Landing:** Slowly pull the left joystick down to descend. Once landed, push both joysticks down and inwards to stop the motors.




Image: A hand launching the FAKJANK F415 drone, illustrating the one-key take-off feature.

6.3 Flight Controls and Features

- **Optical Flow Positioning:** The bottom camera assists in maintaining a stable hover at a fixed height, especially indoors or in areas with clear ground patterns.




Image: The FAKJANK F415 drone hovering indoors, demonstrating its optical flow positioning for stable flight.

- **3 Speed Modes:** Adjust the drone's speed according to your skill level and flight environment. Press the speed button on the remote to cycle through modes (Mode 1: Beginner, Mode 2: Intermediate, Mode 3: Advanced).



Image: Illustration of the FAKJANK F415 drone flying at three different speed modes (Mod1, Mod2, Mod3), indicating varying levels of speed and agility.

- **Headless Mode:** In headless mode, the drone's orientation is relative to the pilot, making it easier to control for beginners. Press the headless mode button to activate/deactivate.
- **Custom Path Flight:** Draw a flight path on your smartphone screen within the app, and the drone will automatically follow the designated route.



Image: An aerial view showing a drone following a custom-drawn path on a map, demonstrating the custom path flight feature.

- **3D Flips:** For advanced users, perform acrobatic flips by pressing the 3D flip button and moving the right joystick in the desired direction.

6.4 Camera Operation

- **4K HD Camera:** The main camera captures high-resolution photos and videos. Adjust the camera angle electrically via the remote control or app (up to 90 degrees).



Image: Close-up of the FAKJANK F415 drone's 4K camera, with an arrow indicating its 90-degree adjustable range. Below are comparison shots of 4K and 1080P video quality.

- **Gesture Control:** Use specific hand gestures in front of the camera to trigger photo or video recording. Refer to the app for specific gesture commands.




Image: Two people waving at the FAKJANK F415 drone, demonstrating the gesture control feature for taking photos or videos.

- **Recording:** Photos and videos are typically saved to your connected smartphone via the app.

7. Maintenance

- **Propeller Replacement:** If propellers are damaged, use the provided screwdriver to replace them with spare propellers. Ensure correct propeller (A or B) is installed on the corresponding motor.
- **Battery Care:** Store batteries in a cool, dry place. Do not overcharge or over-discharge. If not used for extended periods, charge them to about 50% capacity.
- **Cleaning:** Use a soft, dry cloth to clean the drone body and camera lens. Avoid using liquids or solvents.
- **Storage:** Fold the drone arms and store it in the carrying case when not in use to protect it from dust and damage.

8. Troubleshooting

Problem	Possible Cause	Solution
Drone does not power on.	Battery not installed correctly or discharged.	Ensure battery is fully charged and securely inserted.
Drone unstable during flight.	Improper calibration; strong wind; damaged propellers.	Perform calibration on a flat surface. Avoid strong winds. Replace damaged propellers.
No FPV video feed.	Not connected to drone's Wi-Fi; app not open; weak signal.	Verify Wi-Fi connection. Ensure app is running. Fly closer to the drone.
Drone loses connection to remote.	Out of range; interference; low remote battery.	Fly within the specified range (120 meters max). Check remote battery. Avoid areas with high interference.
Short flight time.	Battery not fully charged; old battery; aggressive flying.	Ensure batteries are fully charged. Battery capacity may decrease over time. Fly more conservatively.

9. Specifications

Feature	Detail
Brand	FAKJANK
Model Name	F415
Item Model Number	2023110703

Feature	Detail
Age Range (Description)	Adult (Suitable for beginners with supervision)
Color	Blue
Video Capture Resolution	4K (Main Camera), 1080p (Video Output)
Connectivity Technology	Wi-Fi (5GHz)
Skill Level	Beginner
Item Weight	138 Grams (approx. 4.9 ounces)
Video Capture Format	MP4
Remote Control Technology	Wi-Fi
Control Type	Remote Control
Maximum Range	120 Meters
Material	Nylon, Plastic
Battery Cell Composition	Lithium Ion
Rechargeable Battery Included	Yes (2 included)
Supported Image Format	JPEG
Optical Sensor Technology	Optical Flow
Product Dimensions	7"L x 2"W x 8"H (unfolded, approximate)

10. Warranty and Support

For warranty information, please refer to the product packaging or contact FAKJANK customer support directly. FAKJANK is committed to customer satisfaction and provides support for its products.

Contact Information:

Email: fakjank@gmail.com

Phone: +44 7419 298225




Image: A FAKJANK customer support representative assisting a customer, indicating available support channels.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question