**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**NEBULA Capsule 3**

# Anker Nebula Capsule 3 Portable Projector User Manual

Model: Capsule 3 (D2425)

## 1. Introduction

Thank you for purchasing the Anker Nebula Capsule 3 Portable Projector. This manual provides essential information for the safe and effective use of your device. Please read it thoroughly before operation and keep it for future reference.

## 2. Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the projector to rain or moisture.
- Do not place the projector near heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel.

## 3. Package Contents

Carefully unpack the box and ensure all items are present:

- Nebula Capsule 3 Projector (Main Unit)
- Remote Control (requires 2 AAA batteries, included)
- AC Adapter
- USB-C to USB-C Cable
- Quick Start Guide
- Customer Support Card




Image: Diagram showing the Nebula Capsule 3 projector, remote control, AC adapter, USB-C cable, and quick start guide.

## 4. Product Overview

### 4.1 Front and Top View




Image: Front view of the Nebula Capsule 3 projector, showing the lens and top controls.

The front features the projection lens. The top panel typically includes basic navigation and power buttons.

## 4.2 Rear and Side Ports




Image: Close-up of the rear ports on the Nebula Capsule 3, including USB-C, USB-A, HDMI, and AUX.

- **USB-C Port:** For power input (charging only).
- **USB-A Port:** For connecting USB storage devices.
- **HDMI Input Port:** For connecting external video sources (e.g., game consoles, laptops).
- **AUX Output Socket:** For connecting external audio devices.

## 4.3 Remote Control




Image: The remote control for the Nebula Capsule 3, showing various buttons for navigation, volume, and app shortcuts.

The remote control allows you to navigate the Google TV interface, adjust volume, access app shortcuts (e.g., Netflix, YouTube), and control playback.

# 5. Setup

## 5.1 Powering On/Off

1. Connect the projector to a power outlet using the AC adapter and USB-C cable.
2. Press and hold the power button on the projector or remote control to turn it on.
3. To turn off, press and hold the power button again, then select 'Power Off' on the screen.

## 5.2 Initial Setup and Firmware Update

Upon first use, the projector will guide you through the initial setup process. This includes connecting to Wi-Fi, logging into your Google account, and setting up Google TV.

**Note: The initial firmware update may take several tens of minutes to an hour. Ensure the projector remains**

**connected to power and Wi-Fi during this process.**

## 5.3 Automatic Image Correction

The Nebula Capsule 3 features advanced automatic correction functions:

- **Auto Focus:** The projector automatically adjusts the image clarity.
- **Auto Keystone Correction:** Corrects vertical and horizontal trapezoidal distortion.
- **Auto Obstacle Avoidance:** Detects and adjusts the projection to avoid objects in the projection path.
- **Auto Screen Fit:** Automatically adjusts the image size to fit the projection surface.







Image: Diagram illustrating the automatic obstacle avoidance, vertical/horizontal keystone correction, focus adjustment, and screen fit features.

# 6. Operating

## 6.1 Connecting External Devices

You can connect various devices to your Nebula Capsule 3:

- **HDMI:** Connect game consoles, Blu-ray players, laptops, or TV tuners.
- **USB-A:** Plug in USB flash drives for media playback.
- **Bluetooth:** Pair with Bluetooth speakers or headphones for audio output.
- **Wi-Fi:** Connect to your home network for internet access and streaming.

## 6.2 Using Google TV

The Nebula Capsule 3 comes with Google TV built-in, providing access to a vast library of streaming services and apps.

- **App Access:** Easily access popular apps like Netflix, YouTube, Amazon Prime Video, Disney+, and more.
- **Voice Control:** Use the Google Assistant button on your remote to search for content, control playback, and get information using your voice.
- **Chromecast Built-in:** Cast content directly from your smartphone, tablet, or computer to the projector.




Image: A person casting content from a smartphone to the Nebula Capsule 3 projector, illustrating the Chromecast built-in feature.

### 6.3 Audio Output

The projector features an 8W speaker with Dolby Digital Plus support for immersive sound. You can also connect external audio devices via the AUX port or Bluetooth.

## 7. Maintenance

### 7.1 Cleaning the Lens

Use a soft, lint-free cloth specifically designed for cleaning optical lenses. Do not use abrasive cleaners or solvents.

### 7.2 General Care

- Keep the projector in a clean, dry environment.
- Avoid extreme temperatures.
- Do not block the ventilation openings.

## 8. Troubleshooting

If you encounter issues, try the following solutions:

| Problem | Solution |
|---|---|
| No picture | Check power connection. Ensure input source is correctly selected (HDMI). Adjust focus. |
| No sound | Check volume level. Ensure external audio devices are connected correctly. Check audio output settings. |
| Remote control not working | Replace batteries. Ensure no obstacles between remote and projector. |
| Wi-Fi connection issues | Restart projector and router. Ensure correct Wi-Fi password. Move projector closer to router. |
| Image is blurry | Allow auto-focus to complete. Manually adjust focus if needed. |

## 9. Specifications

| Feature | Detail |
|---|---|
| Brand | NEBULA |
| Model Number | D2425 (AMZ-D2425) |
| Display Resolution | 1920 x 1080 (Full HD) |
| Brightness | 200 ANSI Lumens |
| Max Image Size | 120 inches |
| Min Image Size | 40 inches |
| HDR Technology | HDR10 |
| Speaker | 8W, Dolby Digital Plus |
| Connectivity | Wi-Fi, Bluetooth, HDMI, USB-A, USB-C (power), AUX |
| Operating System | Google TV |
| Weight | 850 grams |
| UPC | 194644173647 |
| ASIN | B0CJDV213W |

## 10. Warranty and Support

Anker provides a comprehensive warranty for the Nebula Capsule 3:

- **Standard Warranty:** 18 months from the date of purchase.
- **Extended Warranty:** An additional 6 months (total 24 months) is provided free for Anker members.

For technical support, warranty claims, or further assistance, please visit the official Anker support website or contact their customer service directly. Please have your product model and serial number ready.




Image: Graphic indicating 18 months standard warranty plus 6 months extended warranty for members, totaling 24 months.

© 2026 NEBULA. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0CJDV213W**

More documents and user manuals: **https://manuals.plus/**