Pemberly Row PR-4753-2442828

Pemberly Row Farmhouse Wood Corner Dining Nook Set

Model: PR-4753-2442828

Introduction Safety Information Setup Operating Instructions Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

This manual provides instructions for the assembly, operation, and maintenance of your Pemberly Row Farmhouse Wood Corner Dining Nook Set. This 4-piece set includes a dining table, a reversible corner bench, a straight bench, and a chair, designed to offer versatile seating and integrated storage solutions for your kitchen or dining area.



Figure 1.1: Complete Pemberly Row Farmhouse Wood Corner Dining Nook Set, showcasing the table, corner bench, straight bench, and chair in Tobacco Leaf finish.

2. Safety Information

Please read and understand all safety warnings and assembly instructions before beginning assembly or using this product. Failure to follow these instructions may result in injury or product damage.

- Keep all small parts and packaging materials away from children.
- Ensure all fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not stand on the table or benches.
- Distribute weight evenly on all seating surfaces.
- Avoid placing hot items directly on the wood surface without protection.
- Do not use abrasive cleaners or harsh chemicals on the finish.

3. Setup and Assembly

Assembly of the dining nook set is required. It is recommended that two adults perform the assembly. Ensure you have adequate space and all components before starting.

3.1 Unpacking

1. Carefully remove all components from the packaging.
2. Lay out all parts on a soft, clean surface to prevent scratching.
3. Verify that all hardware and components listed in the included parts list are present.

3.2 Assembly Steps

Refer to the detailed assembly diagrams and instructions provided in the separate assembly guide included with your product. General steps typically involve:

- Attaching legs to the dining table.
- Assembling the corner bench and straight bench sections.
- Connecting the bench sections to form the corner unit.
- Assembling the individual dining chair.
- Positioning the table and benches in your desired configuration.

Note: The corner bench is designed to be reversible, allowing you to configure the longer and shorter sides to suit your room layout. Follow the specific instructions in the assembly guide for reversible setup.

4. Operating Instructions

4.1 Reversible Design

The corner bench unit can be assembled with the longer section on either the left or right side, providing flexibility to fit various kitchen or dining room layouts. This feature is determined during the initial assembly process.

4.2 Hidden Storage

Both the corner bench and the straight bench feature integrated storage compartments. To access the storage:

1. Gently lift the seat panel of the bench. The panel is hinged for easy access.
2. Place or retrieve items from the compartment.
3. Carefully lower the seat panel until it rests securely in place.



Figure 4.1: View of the benches with their seat panels lifted, revealing the hidden storage compartments.

5. Maintenance

Proper care will help maintain the appearance and longevity of your dining nook set.

- **Cleaning:** Wipe surfaces with a dry, soft cloth. For spills, use a slightly damp cloth immediately and then dry thoroughly.
- **Protection:** Use placemats, coasters, and hot pads to protect the table surface from scratches, heat, and moisture.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or cracking of the wood finish.
- **Humidity Control:** Maintain a consistent humidity level in your home to prevent wood from expanding or contracting, which can lead to cracks or warping.
- **Periodic Inspection:** Periodically check all bolts and screws to ensure they remain tight. Re-tighten as needed.

6. Troubleshooting

This section addresses common issues you might encounter with your dining nook set.

6.1 Loose Joints

If any part of the furniture feels wobbly or loose, check all connecting bolts and screws. Use the appropriate tool (e.g., Allen wrench, screwdriver) to tighten them firmly. Do not overtighten.

6.2 Scratches or Dents

Minor scratches can sometimes be minimized with wood repair markers or furniture polish designed for your finish type. For deeper dents or damage, professional repair may be necessary.

6.3 Uneven Surfaces

If the table or benches appear uneven, check the floor for irregularities. Adjust furniture glides or place shims under the legs if necessary to stabilize the unit.

7. Specifications

Feature	Detail
Brand	Pemberly Row
Model Number	PR-4753-2442828
Color	Tobacco Leaf
Style	Farmhouse Nook with Chair
Material Type	Wood
Overall Dimensions (H x W x D)	36" x 75" x 56"
Item Weight	275 pounds
Included Components	Dining Table, Reversible Corner Bench, Straight Bench, Dining Chair
Special Features	Reversible Design, Hidden Storage Compartments
Product Care Instructions	Wipe with Dry Cloth

8. Warranty & Support

8.1 Manufacturer Warranty

For detailed information regarding the manufacturer's warranty, please refer to the product description on the original purchase platform or the official Pemberly Row store page. Warranty terms typically cover defects in materials and workmanship under normal use.

8.2 Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Pemberly Row customer service. Contact information can usually be found on the product packaging, the official brand website, or through your retailer's support channels.

© 2026 Pemberly Row. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question