Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia 105 Classic

Nokia 105 Classic User Manual

Model: Nokia 105 Classic (2024)

Introduction

The Nokia 105 Classic is a reliable dual SIM keypad phone designed for essential communication. It features built-in UPI payments for convenient transactions, a long-lasting battery for extended use, and a wireless FM radio for entertainment. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your device.



Image: Front view of the Nokia 105 Classic phone in charcoal, showing the display and keypad.

What's in the Box

Upon opening your Nokia 105 Classic package, you should find the following items:

- Nokia 105 Classic Phone
- Battery
- Charger
- User Guide (UG)



Image: Contents of the Nokia 105 Classic box, including the phone, battery, and charger.

Setup

1. Inserting the SIM Card(s) and Battery

1. Ensure the phone is powered off.
2. Remove the back cover by gently prying it open from the notch at the bottom.
3. If the battery is already inserted, remove it.
4. Locate the SIM card slots. This phone supports Dual SIM. Insert your SIM card(s) into the designated slots with the gold contacts facing down and the cut corner aligned as shown in the diagram (refer to the physical user guide for detailed diagram).
5. Insert the battery, aligning the gold contacts on the battery with the contacts in the phone.
6. Replace the back cover, pressing firmly until it clicks into place.

2. Charging the Battery

1. Connect the charger to a power outlet.
2. Plug the charger cable into the charging port on your phone.
3. The battery indicator on the screen will show the charging status.
4. Once fully charged, disconnect the charger from the phone and then from the power outlet.

Operating Instructions

Power On/Off

- To power on, press and hold the Power key (red key) until the phone vibrates and the screen lights up.
- To power off, press and hold the Power key until the power off options appear, then select "Power off".

Making Calls

- From the home screen, enter the phone number using the keypad.
- Press the Call key (green key) to initiate the call.
- To end a call, press the End key (red key).

Sending Messages

- Go to **Menu** > **Messages** > **Create message**.
- Type your message using the keypad.
- Select **Options** > **Send**.
- Enter the recipient's phone number or select from contacts.
- Select **OK**.

Wireless FM Radio

The Nokia 105 Classic features a wireless FM radio, allowing you to listen to your favorite stations without needing a headset connected as an antenna.

- Go to **Menu** > **Radio**.
- Use the navigation keys to tune to different stations.

Built-in UPI Payments

The phone comes with a built-in UPI app for sending and receiving payments. For detailed instructions on setting up and using UPI, please refer to the specific UPI application's guide within the phone's menu or contact your service provider.

Snake Game

Enjoy the classic Snake game pre-installed on your device. Navigate to the Games menu to start playing.

Your browser does not support the video tag.

Video: An overview of the Nokia 105 Classic's features, including its design, UPI payment capability, and long-lasting battery.

Maintenance

Battery Care

- Avoid exposing the battery to extreme temperatures.

- Do not puncture, damage, or disassemble the battery.
- Use only original Nokia chargers and batteries.

Cleaning the Device

- Wipe the phone with a soft, lint-free cloth.
- Do not use harsh chemicals or abrasive materials.
- Keep the charging port and audio jack free from dust and debris.

Storage

- Store the phone in a cool, dry place away from direct sunlight.
- If storing for an extended period, ensure the battery is partially charged (around 50%) to preserve its lifespan.

Troubleshooting

Problem	Possible Solution
Phone does not turn on	Ensure the battery is correctly inserted and charged. Connect the charger and try again.
No network signal	Check if your SIM card is properly inserted. Move to an area with better network coverage. Restart the phone.
Battery not charging	Check the charger and charging cable for damage. Ensure the charging port is clean. Try a different power outlet.
Keypad unresponsive	Restart the phone. Ensure no foreign objects are lodged under the keys.

Specifications

Feature	Detail
Operating System	S30+
RAM	0.03 GB
Product Dimensions	11.5 x 5 x 1.4 cm
Item Weight	73 g
Battery	1 Lithium Ion battery (included)
Battery Power Rating	800 mAh
Wireless Communication	Cellular

Feature	Detail
Connectivity Technologies	Bluetooth, USB
Special Features	Dual SIM, Wireless FM Radio, Built-in UPI Payments, Snake Game
Display Features	Wireless
Device Interface - Primary	Keypad
Resolution	720p (Display resolution, likely refers to video playback capability or internal processing, not screen resolution for a feature phone)
Audio Jack	3.5 mm
Form Factor	Bar
Colour	Charcoal (also available in Blue)
Country of Origin	India
Screen Size	2 Inches

Warranty and Support

Your Nokia 105 Classic comes with a standard brand warranty. For specific warranty terms and conditions, please refer to the warranty card included in your product packaging or visit the official Nokia website.
For warranty support or any product-related queries, you may contact Nokia customer service:

Customer Support Helpline: 1800 1028 169

Additional information can be found on the product detail page on Amazon.in.

© 2024 Nokia. All rights reserved. Nokia and the Nokia logo are trademarks of Nokia Corporation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJML9S4F

More documents and user manuals: **https://manuals.plus/**