Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Devoko DDVC-23B190-4

Devoko 9-Piece Outdoor Patio Dining Set Instruction Manual

Model: DDVC-23B190-4

1. Introduction

Thank you for choosing the Devoko 9-Piece Outdoor Patio Dining Set. This manual provides essential information for the proper assembly, use, and maintenance of your new dining set. Please read all instructions carefully before assembly and retain this manual for future reference.



Image: The complete Devoko 9-Piece Outdoor Patio Dining Set, featuring a rectangular table with an acacia wood top and eight grey wicker chairs, arranged on a lush green lawn in a backyard.

2. Package Contents

Your Devoko 9-Piece Outdoor Patio Dining Set is shipped in three separate boxes. Please ensure all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- 1 x Dining Table (Acacia Wood Top, Steel Frame, Wicker Edging)
- 8 x Dining Chairs (Wicker, Acacia Wood Armrests, Steel Frame)
- 8 x Seat Cushions (Removable, Cotton-filled)
- 1 x Installation Instruction Manual
- Assembly Tools (Allen wrench, etc.)

Note: Boxes may arrive at different times. Please be patient if you only receive part of the shipment initially.

3. Setup and Assembly

Assembly is required for this dining set. Detailed instructions and necessary tools are included in the package. It is recommended to have two people for assembly to ensure stability and ease of construction.

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the included parts list and diagrams to identify each component.
3. **Assemble Chairs:** Follow the step-by-step instructions for assembling each chair. Ensure all screws are loosely fitted initially.
4. **Assemble Table:** Attach the table legs to the tabletop frame. Again, keep screws loose until all parts are aligned.
5. **Tighten All Fasteners:** Once all components are correctly aligned and assembled, gradually tighten all screws and bolts. Avoid over-tightening to prevent damage.
6. **Attach Cushions:** Place the seat cushions onto the chairs.

Important: Do not fully tighten any fasteners until all parts are correctly in place and aligned. This prevents misalignment and potential damage during assembly.



Image: A diagram illustrating the dimensions of the dining table (59" x 35.5" x 29.5") and a single chair (34.5" x 25" x 23.5"), along with the chair's maximum load capacity of 350 lbs.

4. Operating Instructions

This dining set is designed for outdoor use, providing a comfortable and functional space for meals and gatherings.

- **Seating:** The set includes eight chairs, designed to comfortably accommodate eight individuals around the table.
- **Stability:** Ensure the dining set is placed on a flat, stable surface to prevent wobbling. The adjustable feet on the chairs can be twisted slightly to balance on uneven ground.
- **Weight Capacity:** The dining table has a weight capacity of 165 lbs. Each chair has a weight capacity of 350 lbs. Do not exceed these limits.
- **Armrests:** The widened acacia wood armrests provide additional comfort and support.



Image: A close-up view of a Devoko wicker dining chair, emphasizing its ergonomic curved backrest and acacia wood armrests, designed for comfort and support.

5. Maintenance

Proper maintenance will extend the life and appearance of your Devoko dining set.

- **General Cleaning:** Wipe the table and chairs with a dry cloth regularly to remove dust and debris. For deeper cleaning, use a mild soap solution and a soft cloth, then rinse thoroughly and dry.
- **Acacia Wood Care:** The acacia wood tabletop and armrests are durable but benefit from periodic treatment with wood oil to maintain their natural appearance and protect against weathering.
- **Cushion Care:** The removable seat cushion covers are machine-washable. Follow the care instructions on the label. Allow cushions to dry completely before re-attaching or storing.
- **Weather Protection:** While designed for outdoor use, covering the set during prolonged periods of harsh weather (heavy rain, snow, intense sun) or when not in use will help preserve its condition.
- **Storage:** During off-seasons or extended periods of non-use, store the cushions in a dry, protected area.



Image: A detailed view showcasing the machine-washable cushion with a zipper for easy removal and the naturally weather-resistant acacia wood tabletop.

6. Troubleshooting

Below are common issues and their potential solutions:

Issue	Possible Cause	Solution
Table/Chair Wobbles	Uneven surface; loose fasteners.	Adjust the leveling feet on the bottom of the legs. Check and tighten all assembly fasteners.
Parts do not align during assembly	Fasteners tightened too early; incorrect orientation of parts.	Loosen all fasteners, re-align parts according to the manual, then gradually tighten. Ensure parts are oriented correctly.

Issue	Possible Cause	Solution
Wicker appears faded or damaged	Prolonged exposure to harsh weather/UV.	Regularly clean and consider using a protective cover when not in use or during extreme weather.
Acacia wood appears dry or discolored	Lack of maintenance; exposure to elements.	Apply a suitable outdoor wood oil or sealant to restore and protect the wood.

7. Specifications

Feature	Detail
Model Number	DDVC-23B190-4
Material	Acacia Wood, Rattan (Wicker), Steel
Color	Grey (Wicker)
Dining Table Dimensions	59" L x 35.5" W x 29.5" H
Chair Dimensions	34.5" H x 25" W x 23.5" D
Cushion Thickness	2.5"
Dining Table Weight Capacity	165 lbs
Chair Weight Capacity	350 lbs
Total Item Weight	193 lbs
Product Care Instructions	Wipe with Dry Cloth
Assembly	Assembly required. Detailed instructions included.

8. Warranty and Support

For any questions, missing parts, or concerns regarding your Devoko Outdoor Patio Dining Set, please contact Devoko customer support directly. Refer to your purchase documentation for specific warranty details and contact information. You can also visit the official Devoko Store on Amazon for additional product information and support.Devoko Store

© 2026 Devoko. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CJQXYJH4

More documents and user manuals: **https://manuals.plus/**