HCDZ RC-F0301, RC-F0301E, HM-335, HM-535, HM-636, RXD-M35, RXD-M35SE, RXD-M55EH, RXD-M66H

HCDZ Replacement Remote Control User Manual

For Kenwood Micro Hi-Fi Component Stereo Audio Systems (Models: RC-F0301, RC-F0301E, HM-335, HM-535, HM-636, RXD-M35, RXD-M35SE, RXD-M55EH, RXD-M66H)

Introduction

This manual provides instructions for the HCDZ replacement remote control, designed for use with various Kenwood Micro Hi-Fi Component Stereo Audio Systems. This remote control functions as a direct replacement and requires no programming.

Please read these instructions carefully to ensure proper operation and longevity of your remote control.

Package Contents

- 1 x HCDZ Replacement Remote Control

Note: Batteries and additional instructions are not included in the package. This remote is designed to work immediately upon battery insertion.

Setup: Battery Installation

The remote control requires two (2) AA batteries for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the battery compartment.
3. Insert two (2) AA batteries, ensuring that the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.



Image: Rear view of the HCDZ replacement remote control with the battery cover removed, revealing the battery slots. This illustrates where to insert the two AA batteries.

Once batteries are installed, the remote control is ready for use with your compatible Kenwood Micro Hi-Fi system.

Operating Instructions

This replacement remote control is designed to function identically to the original Kenwood remote for the specified models. No programming is required. Simply point the remote control towards your Kenwood Micro Hi-Fi system and press the desired function button.



Image: Front view of the HCDZ replacement remote control, displaying its full button layout. This image helps users identify the various control buttons for their audio system.

Ensure there are no obstructions between the remote control's infrared (IR) emitter and the IR sensor on your Kenwood audio system for optimal performance.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent potential damage from battery leakage and corrosion.
- **Environment:** Do not expose the remote control to extremely hot or humid conditions, direct sunlight, or strong lighting apparatuses, as this may cause malfunction.

Troubleshooting

If the remote control is not functioning as expected, consider the following troubleshooting steps:

1. **Check Batteries:** Ensure batteries are inserted correctly with the correct polarity (+/-). Replace old batteries with new ones. Do not mix new and old batteries.
2. **Battery Terminals:** Inspect battery terminals inside the compartment for any corrosion or damage. Clean if necessary.
3. **Range and Obstructions:** Move closer to your Kenwood audio system. Ensure there are no physical obstructions (e.g., furniture, objects) between the remote control and the system's IR sensor.
4. **System Power:** Verify that your Kenwood audio system is plugged in and powered on.
5. **IR Sensor Interference:** Ensure the remote sensor on your audio system is not exposed to direct sunlight or other

strong light sources, which can interfere with the IR signal.

If the issue persists after performing these steps, the remote control may require replacement.

Specifications

Brand	HCDZ
Compatible Models	Kenwood RC-F0301, RC-F0301E, HM-335, HM-535, HM-636, RXD-M35, RXD-M35SE, RXD-M55EH, RXD-M66H
Controller Type	Infrared (IR) Button Control
Batteries Required	2 x AA (not included)
Special Feature	No Programming Required

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question