Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Juskys 300622

Juskys 30L Automatic Sensor Trash Can User Manual

Model: 300622

1. Introduction

Thank you for choosing the Juskys 30L Automatic Sensor Trash Can. This manual provides important information on the safe and efficient use of your new appliance. Please read it thoroughly before first use and keep it for future reference.

This automatic trash can is designed for convenient and hygienic waste disposal, featuring a motion sensor for hands-free operation and a robust design suitable for various indoor environments, especially kitchens.



Juskys Automatic Sensor Trash Can in a modern kitchen setting.

Key Features:

- **Contactless Operation:** Integrated motion sensor for automatic lid opening and closing.
- **Electric Lid:** Sensor-controlled lid can also be operated via a touch control panel.
- **30 Liter Capacity:** Ample space for household waste.
- **High-Quality Materials:** Durable stainless steel body and lightweight polystyrene lid.
- **Secure Waste Disposal:** Includes a clamping ring to securely hold trash bags.
- **Waterproof Lid:** Helps contain odors and maintain hygiene.



Diagram highlighting key features: waterproof lid, integrated sensor, touch control, clamping ring, large volume, robust material.

2. Safety Information

Please observe the following safety precautions to prevent injury or damage to the product:

- This appliance is for indoor use only. Do not expose it to direct sunlight, extreme temperatures, or high humidity.
- Do not immerse the lid unit in water or other liquids. Clean with a damp cloth only.
- Keep the sensor area clean and unobstructed for optimal performance.
- Use only the specified battery type and ensure correct polarity during installation.
- Keep batteries out of reach of children.
- Do not force the lid open or closed manually, as this may damage the motor.
- Do not place heavy objects on the lid.
- This product is not a toy. Keep away from children and pets.

3. Package Contents

Please check that all items are present and undamaged:

- 1 x Juskys 30L Automatic Sensor Trash Can (Body and Lid Unit)
- 1 x Clamping Ring for trash bags
- 1 x User Manual

Note: Batteries are not included and must be purchased separately (typically AA batteries, refer to battery compartment for exact type).

4. Setup

4.1. Battery Installation

1. Locate the battery compartment on the underside of the lid unit.
2. Open the battery compartment cover.
3. Insert the required batteries (e.g., 4x AA batteries) according to the polarity indicators (+/-).
4. Close the battery compartment cover securely.

4.2. Installing the Trash Bag

1. Remove the lid unit from the trash can body.
2. Place a suitable trash bag (30L capacity recommended) into the trash can body.
3. Fold the top edge of the trash bag over the rim of the can.
4. Place the clamping ring over the trash bag and the rim of the can to secure the bag in place. Ensure the bag is taut and does not slip.
5. Carefully place the lid unit back onto the trash can body, ensuring it is properly aligned.



Illustration of the clamping ring mechanism for securing trash bags.



Close-up of hands demonstrating how to use the clamping ring to secure a trash bag.

5. Operating Instructions

5.1. Automatic Sensor Mode

The trash can is equipped with an infrared motion sensor for hands-free operation.

1. Ensure the trash can is powered on (if there's a power switch, usually on the back or underside of the lid).
2. When an object (e.g., your hand) approaches the sensor area (usually on the front of the lid) within approximately 10-15 cm, the lid will automatically open.
3. The lid will remain open for a few seconds (typically 5-7 seconds) to allow for waste disposal.
4. After the object moves away or the set time elapses, the lid will close automatically and silently.



Sequence showing the lid opening automatically as a hand approaches the sensor.

5.2. Manual Operation (Touch Control)

For situations where you prefer to keep the lid open longer or operate it manually, use the touch control panel.

1. Press the 'OPEN' button (or equivalent icon) on the touch control panel to open the lid.
2. The lid will remain open until you press the 'CLOSE' button (or equivalent icon).
3. To return to automatic sensor mode, simply press the 'CLOSE' button or wait for the lid to close automatically if no manual 'OPEN' command was given.



Close-up of the sensor and touch control panel on the lid.



The automatic lid in its open position, revealing the interior.

6. Maintenance

6.1. Cleaning

- **Exterior:** Wipe the stainless steel body with a soft, damp cloth and mild detergent. Dry thoroughly to prevent water spots. Do not use abrasive cleaners or scouring pads.
- **Lid Unit:** Gently wipe the lid and sensor area with a soft, damp cloth. Ensure no water enters the battery compartment or electronic components. Do not rinse the lid under running water.
- **Interior:** If the interior of the can becomes dirty, remove the trash bag and wipe the inside with a damp cloth and mild detergent. Rinse and dry completely before inserting a new trash bag.

6.2. Battery Replacement

When the lid's operation becomes slow or inconsistent, it's time to replace the batteries.

1. Turn off the power switch on the lid unit, if available.
2. Open the battery compartment.
3. Remove the old batteries and dispose of them responsibly according to local regulations.
4. Insert new batteries of the correct type and polarity.
5. Close the battery compartment and turn the power switch back on.

7. Troubleshooting

Problem	Possible Cause	Solution
Lid does not open automatically.	1. Batteries are dead or incorrectly installed. 2. Sensor is dirty or obstructed. 3. Power switch is off.	1. Replace batteries, ensuring correct polarity. 2. Clean the sensor area with a soft, dry cloth. 3. Turn on the power switch.
Lid opens slowly or inconsistently.	Low battery power.	Replace batteries.

Problem	Possible Cause	Solution
Lid does not close.	1. Object is still in sensor range. 2. Sensor is dirty or obstructed. 3. Manual 'OPEN' button was pressed.	1. Remove any objects from the sensor range. 2. Clean the sensor area. 3. Press the 'CLOSE' button.
Lid makes unusual noises.	Mechanical obstruction or motor issue.	Ensure no debris is obstructing the lid mechanism. If the problem persists, contact customer support.

8. Specifications

Feature	Detail
Model Number	300622
Capacity	30 Liters
Dimensions (L x W x H)	31L x 31W x 52H cm
Weight	2.3 Kilograms
Color	Silver
Opening Mechanism	Motion Sensor
Material	Stainless Steel (body), Polystyrene (lid)
Special Features	Clamping ring for bag fixation, Rust-proof, Motion detector, Silent closing, Touch control panel
Recommended Use	Indoor, Kitchen



Diagram showing the dimensions of the 30L Juskys Automatic Sensor Trash Can.

9. Warranty and Support

For warranty information, please refer to the terms and conditions provided at the time of purchase or contact your retailer. If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact Juskys customer support or your point of purchase.

Please have your model number (300622) and purchase details ready when contacting support.

© 2026 Juskys. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CK4V2TKG

More documents and user manuals: **https://manuals.plus/**