Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool 859991662080

Whirlpool WF S7977 CPNE 77 cm Integrated Induction Cooktop User Manual

Model: WF S7977 CPNE (Reference: 859991662080)

1. Introduction

Thank you for choosing the Whirlpool WF S7977 CPNE 77 cm Integrated Induction Cooktop. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read these instructions carefully before using the cooktop and keep them for future reference.



Figure 1: Whirlpool WF S7977 CPNE Induction Cooktop, top view, showing the four cooking zones and touch controls.

2. Safety Information

Your safety and the safety of others are paramount. This manual provides important safety messages. Always read and obey all safety messages.

General Safety Precautions:

- **Electrical Safety:** Ensure the cooktop is properly grounded. Do not use extension cords. Disconnect power before servicing.
- **Heat Safety:** The cooking zones become hot during use. Avoid touching the hot surface. Use pot holders.
- **Proper Cookware:** Only use cookware suitable for induction cooking (ferromagnetic material).
- **Ventilation:** Ensure adequate ventilation around the appliance as per installation instructions.
- **Children:** Keep children away from the cooktop during and after use as surfaces can remain hot.
- **Flammable Materials:** Do not store flammable materials on or near the cooktop.

3. Setup and Installation

This section provides general guidelines for the installation of your induction cooktop. Installation must be performed by a qualified technician in accordance with local regulations and codes.

Installation Type:

- The Whirlpool WF S7977 CPNE is designed for **Drop-In** installation.

Dimensions and Clearances:

- **Product Dimensions (L x W x H):** 51 x 77 x 5.4 cm
- Refer to the detailed installation template provided with your appliance for precise cutout dimensions and minimum clearances from adjacent surfaces.

Electrical Connection:

- **Voltage:** 230 Volts (AC)
- **Power Source:** Electric cable
- Ensure the electrical supply meets the requirements specified on the appliance rating plate.



Figure 2: The cooktop seamlessly integrated into a kitchen countertop.

4. Operating Instructions

This section guides you through the basic operation of your Whirlpool induction cooktop.

Control Panel Overview:

The cooktop features an intuitive touch control panel with slider controls for each cooking zone.



Figure 3: Close-up of the cooktop's touch control panel.

Turning On/Off:

- To turn on the cooktop, press the main power button.

- To turn off, press the main power button again.

Selecting a Cooking Zone and Adjusting Power:

- Place suitable induction cookware on the desired cooking zone.
- Select the cooking zone by touching its corresponding control.
- Adjust the power level using the intuitive slider control for that zone. Slide your finger along the scale to increase or decrease heat.

FlexiCook Technology:

The FlexiCook feature allows you to combine multiple cooking zones into one large zone. This is ideal for accommodating larger pots, griddle pans, or multiple smaller items that require a continuous heating surface.

- To activate FlexiCook, select the FlexiCook option on the control panel for the desired zones.
- Once activated, the combined zone will operate as a single unit, allowing for uniform heat distribution.



Figure 4: Cooktop demonstrating FlexiCook with two pots on combined zones.

Boost Function:

The Boost function provides maximum power to a selected cooking zone for a short period, ideal for rapidly boiling water or searing. Activate it by selecting the Boost option for the desired zone.

Timer Function:

The integrated timer allows you to set a cooking duration for individual zones. Once the set time expires, the zone will automatically turn off.

- Select the cooking zone and then press the timer button.
- Use the +/- controls to set the desired cooking time.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your cooktop.

Cleaning the Ceramic Glass Surface:

- Allow the cooktop to cool completely before cleaning.
- Use a soft cloth or sponge with a non-abrasive cleaner specifically designed for ceramic glass cooktops.
- For stubborn stains or burnt-on food, use a ceramic hob scraper, holding it at a shallow angle.
- Wipe dry with a clean cloth to prevent water spots.

General Care:

- Avoid dropping heavy objects on the cooktop surface.
- Do not use abrasive pads, scouring powders, or harsh chemical cleaners.
- Ensure the ventilation openings are not blocked.

6. Troubleshooting

If you encounter issues with your cooktop, refer to the following common problems and solutions before contacting service.

Cooktop Does Not Turn On:

- Check if the appliance is properly plugged into the electrical outlet.
- Verify that the circuit breaker has not tripped.
- Ensure the main power button on the cooktop is pressed.

Cooking Zone Not Heating:

- Confirm that the cookware is suitable for induction (magnetic base).
- Ensure the cookware is centered on the cooking zone.
- Check if an error code is displayed on the control panel. Refer to the specific error code section in the full manual (if available).

Cooktop Shuts Off Unexpectedly:

- This may be due to overheating. Allow the cooktop to cool down.
- Ensure there is no object covering the control panel.

For persistent issues or error codes not listed, please contact customer support.

7. Specifications

Feature	Specification
Brand	Whirlpool
Model Number	859991662080
Product Dimensions (L x W x H)	51 x 77 x 5.4 cm
Installation Type	Drop-In
Special Features	FlexiCook
Hob Type	Induction

Feature	Specification
Number of Hobs	4
Color	Black
Voltage	230 Volts (AC)
Power Type	Electric
Material	Ceramic Glass
Heating Elements	4
Ignition System Type	Electronic

8. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Whirlpool website for your region. Keep your proof of purchase for warranty claims.

Spare Parts:

Information regarding the availability of spare parts for this model is not provided in the product details. Please contact Whirlpool customer service for inquiries about spare parts.

Customer Support:

If you require technical assistance, service, or have questions not covered in this manual, please contact Whirlpool customer support. Contact details can typically be found on the Whirlpool official website or in the documentation supplied with your appliance.

© 2023 Whirlpool Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CK8FWFPL

More documents and user manuals: **https://manuals.plus/**