Ocina HZ-S06

Ocina Soup Maker and Smoothie Blender HZ-S06 User Manual

Model: HZ-S06

1. Introduction

Thank you for purchasing the Ocina Soup Maker and Smoothie Blender. This appliance is designed to simplify the preparation of delicious soups and refreshing smoothies. Please read this manual carefully before first use to ensure safe and optimal operation. Keep this manual for future reference.

2. Safety Instructions

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury.

- Read all instructions before use.
- Do not immerse the motor unit, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.

- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- The blades are sharp. Handle with care.
- Ensure the lid is securely locked in place before operating.
- Do not overfill the appliance beyond the maximum fill line (1.6L).

3. Product Overview

The Ocina Soup Maker and Smoothie Blender is a versatile kitchen appliance designed for ease of use and efficiency. It features a durable stainless steel body and a powerful 1000W motor.

3.1 Components

- Main Unit (Stainless Steel Jug with Heating Element)
- Motor Unit with Blades (integrated into the lid)
- Control Panel
- Power Cord



Figure 1: Ocina Soup Maker and Smoothie Blender with its packaging. The appliance features a stainless steel jug with a black handle and lid, indicating MAX 1600ml and MIN 1300ml fill lines.

3.2 Features

- **Capacity:** 1.6 Liters (suitable for at least 4 servings).
- **Power:** 1000W motor for efficient blending and heating.
- **Pre-programmed Settings:** 6 distinct programs for various preparations.
- **Keep-Warm Function:** Maintains soup temperature after cooking.
- **Memory Function:** Retains settings if power is briefly interrupted.
- **Cold Blending:** Suitable for smoothies, frozen yogurt, and smoothie bowls.
- **Easy-Pour Spout:** Designed for convenient serving.
- **Material:** Stainless steel jug and blades.



Figure 2: The control panel of the Ocina Soup Maker, showing 6 pre-programmed functions including Smooth Soup, Chunky Soup, Compote, Smoothie, Keep Warm, and Blend.



Figure 3: Detail of the two sharp stainless steel blades located within the lid assembly, alongside a visual representation of the 1.6L capacity.

4. Setup

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or transport.
2. **Clean:** Before first use, wash the jug interior and lid assembly (including blades) with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the soup maker on a stable, flat, heat-resistant surface, away from the edge of the counter. Ensure there is adequate ventilation around the appliance.
4. **Connect Power:** Plug the power cord into a grounded electrical outlet. The appliance will emit a beep and the display will illuminate.



Figure 4: A top-down view of the Ocina Soup Maker's control panel, illustrating the various function icons, with bowls of soup in the background.

5. Operating Instructions

The Ocina Soup Maker offers 6 pre-programmed functions for various culinary tasks.

5.1 General Operation

1. Add ingredients to the stainless steel jug. Ensure ingredients are cut into appropriate sizes (e.g., 2-3 cm pieces for chunky soup).
2. Do not exceed the MAX 1.6L fill line or go below the MIN 1.3L fill line.
3. Securely place the lid with the motor unit onto the jug. Ensure it clicks into place.
4. Plug in the appliance. The power indicator will light up.
5. Press the **Power button** () to activate the control panel.
6. Use the **Mode button** (often represented by a triangle or similar icon) to cycle through the available programs.
7. Once the desired program is selected, the appliance will start automatically after a few seconds, or you may need to press the Power button again to confirm.

5.2 Pre-programmed Functions

- **Smooth Soup:** For creamy, blended soups. The appliance will heat and blend ingredients until smooth.
- **Chunky Soup:** For soups with larger pieces of ingredients. The appliance will heat ingredients with minimal blending.
- **Compote:** For preparing fruit compotes or sauces.
- **Smoothie:** For blending cold ingredients into smoothies. No heating involved.
- **Keep Warm:** Activates the keep-warm function after a cooking cycle, or can be selected independently to warm pre-cooked food.
- **Blend:** A manual blending function for custom blending needs.



Figure 5: The Ocina Soup Maker positioned with various fresh fruits, illustrating its capability as a smoothie maker.



Figure 6: The "Keep Warm" function indicator illuminated on the control panel, signifying that the appliance is maintaining the temperature of its contents.



Figure 7: A user pouring freshly made soup from the Ocina Soup Maker into a serving bowl, demonstrating the convenient pouring spout.

6. Cleaning and Maintenance

Regular cleaning ensures the longevity and hygienic operation of your appliance.

1. **Unplug:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Jug Interior:** Add a small amount of warm water and a drop of dish soap to the jug. You can use the "Blend" function for a few seconds to help dislodge food residue. Then, carefully scrub the interior with a non-abrasive sponge or brush. Rinse thoroughly.
3. **Lid and Blades:** Carefully clean the lid assembly, paying close attention to the blades. Use a brush to remove any food particles. The blades are sharp, so exercise caution. Rinse under running water.
4. **Exterior:** Wipe the exterior of the main unit with a damp cloth. Do not use abrasive cleaners or immerse the main unit in water.
5. **Drying:** Ensure all parts are completely dry before storing or next use.
6. **Storage:** Store the appliance in a clean, dry place.

7. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; lid not properly secured.	Check power connection; try a different outlet; ensure lid is correctly placed and locked.
Blending is ineffective.	Ingredients too large; too little liquid; jug overfilled.	Cut ingredients into smaller pieces; add more liquid; ensure fill level is between MIN and MAX lines.
Soup is not hot enough.	Incorrect program selected; insufficient cooking time.	Ensure a heating program (e.g., Smooth Soup, Chunky Soup) is selected; allow the full cycle to complete.
Appliance stops unexpectedly.	Overheating protection activated; power interruption.	Unplug and let cool for 30 minutes before restarting; check power supply.

8. Specifications

- **Brand:** Ocina
- **Model Number:** HZ-S06
- **Color:** Black
- **Material:** Stainless Steel (jug, blades)
- **Capacity:** 1.6 Liters
- **Power:** 1000W
- **Number of Speeds/Settings:** 6 pre-programmed functions
- **Special Feature:** Pouring Spout, Keep Warm Function
- **Product Dimensions:** 23.5P x 16.4W x 33H centimeters (approx. 9.25D x 6.46W x 13H inches)
- **Blade Material:** Stainless Steel
- **Material Not Used:** BPA-free
- **Power Source:** Corded Electric
- **Recommended Uses:** Soup preparation, smoothies, frozen yogurt, smoothie bowls

9. Warranty and Support

Information regarding warranty coverage and customer support is typically provided with your purchase documentation or on the manufacturer's official website. Please refer to these resources for details on warranty periods, terms, and how to contact customer service for assistance or spare parts.
For further assistance, please contact Ocina customer support through the details provided in your product packaging or on the official Ocina website.

© 2024 Ocina. All rights reserved.