Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

W-KING D10-MIC

W-KING D10-MIC Portable Bluetooth Speaker User Manual

Model: D10-MIC | Brand: W-KING

Introduction

Thank you for choosing the W-KING D10-MIC Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. Please read this manual thoroughly before using the product.



Image: The W-KING D10-MIC speaker, showcasing its robust design and the accompanying wireless microphone.

Package Contents

Ensure all items are present in the package:

- W-KING D10-MIC Portable Bluetooth Speaker
- Wireless Microphone
- USB-C Charging Cable
- 3.5mm AUX Audio Cable
- User Manual (this document)

Setup

1. Initial Charging

Before first use, fully charge the speaker. Connect the provided USB-C charging cable to the speaker's DC 5V port and the other end to a compatible USB power adapter (not included). The charging indicator will show the charging status. A full charge typically takes several hours.



Image: The W-KING D10-MIC speaker connected for charging, illustrating its power bank capability.

2. Powering On/Off

Press and hold the **Power Button** located on the top panel for 2-3 seconds to turn the speaker on or off. A sound prompt will indicate the power status.

Operating Instructions

1. Bluetooth Pairing

1. Turn on the W-KING D10-MIC speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. Enable Bluetooth on your device (smartphone, tablet, etc.).
3. Search for "W-KING D10" in your device's Bluetooth list and select it to connect.
4. Once connected, the LED light will become solid, and you will hear a confirmation sound.

Note: If no device is connected within 10 minutes, the speaker will automatically turn off to save power.



Image: A visual representation of connecting the W-KING D10 speaker via Bluetooth on a mobile device.

2. Microphone Usage (Wireless & Wired)

The D10-MIC comes with a dedicated wireless UHF microphone. It also supports a wired microphone via the 1/4" (6.35mm) input.

- **Wireless Microphone:** The included wireless microphone is pre-paired. Simply turn it on, and it will connect to the speaker.
- **Wired Microphone:** Plug a dynamic microphone (recommended -48~-52dB/600Ω) into the 1/4" (6.35mm) MIC input on the speaker's rear panel. The speaker will automatically switch to Microphone Mode.
- **Microphone Volume & Reverb:** Use the controls on the wireless microphone or the speaker's control panel to adjust microphone volume and reverb/echo effects. Long press the EQ button on the speaker to enter microphone volume adjustment mode, then use the volume buttons.



Image: Detailed view of the wireless microphone, highlighting its volume and echo controls, UHF stable signal, HD LED display, and advanced chipset.



Image: The input/output panel of the speaker, showing the microphone input, USB, AUX, TF card slot, and DC 5V charging port.

3. EQ and Bass Boost

Press the **EQ button** ( ) on the top panel to cycle through different equalization modes, including a dedicated Bass Boost mode for enhanced low-frequency output. The DSP chip optimizes sound quality across all modes.



Image: The speaker highlighting its Bass Boost feature and an illustrative EQ curve, indicating various frequency adjustments.

4. True Wireless Stereo (TWS) Pairing

You can pair two W-KING D10 speakers together for a true wireless stereo experience, delivering 140W of combined output.

1. Ensure both D10 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press and hold the**TWS button** ( ) for 2-3 seconds. You will hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically connect to each other. Once connected, you will hear a confirmation sound, and the LED indicators will change.
4. Now, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.



Image: Two W-KING D10 speakers set up in a living room, demonstrating the True Wireless Stereo pairing feature for an immersive audio experience.

5. RGB Light Modes

The speaker features dynamic RGB lights that can synchronize with the music. Press the**Light Mode button** to cycle through different light patterns or turn the lights off.



Image: The W-KING D10-MIC speaker showcasing its vibrant RGB lighting effects, creating an engaging visual experience.

6. Power Bank Function

The W-KING D10-MIC can act as a power bank to charge your mobile devices. Connect your device's charging cable to the USB-A output port on the speaker's rear panel.

7. Other Playback Modes (AUX, TF Card, USB)

The speaker supports playback from various sources:

- **AUX Input:** Connect an audio device using the provided 3.5mm AUX cable to the AUX port.
- **TF Card:** Insert a TF (microSD) card loaded with audio files into the TF card slot.
- **USB Playback:** Insert a USB flash drive with audio files into the USB-A input port.

The speaker will automatically switch to the corresponding mode when a compatible device or card is inserted.

Maintenance

1. Cleaning

Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

2. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery every 3-6 months to maintain its lifespan.

3. Waterproofing (IPX6)

The W-KING D10-MIC is IPX6 waterproof, meaning it can withstand powerful water jets. It is suitable for outdoor use and can resist splashes and rain. **Do not submerge the speaker in water.**Ensure the rubber flap covering the ports on the rear is securely closed to maintain water resistance.



Image: The W-KING D10-MIC speaker in a water environment, illustrating its IPX6 waterproof and dustproof capabilities.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power button not pressed correctly.	Charge the speaker fully. Press and hold the power button for 2-3 seconds.
No sound.	Volume too low; Incorrect input mode; Device not connected.	Increase volume on speaker and connected device. Ensure correct input mode (Bluetooth, AUX, TF, USB). Reconnect Bluetooth device.
Bluetooth pairing fails.	Speaker already connected; Device Bluetooth off; Speaker too far.	Disconnect speaker from other devices. Ensure Bluetooth is enabled on your device. Move device closer to speaker (within 10m).
Microphone not working.	Microphone off; Low microphone battery; Incorrect input mode; Microphone volume too low.	Ensure microphone is powered on. Charge wireless microphone. Check if speaker is in Microphone Mode. Increase microphone volume.
TWS pairing fails.	Speakers already connected to other devices; Speakers too far apart.	Ensure both speakers are disconnected from other Bluetooth devices. Place speakers close to each other during pairing.

Specifications

Feature	Detail
Brand	W-KING
Model Name	D10-MIC
Speaker Output Power	70W RMS (120W Peak)
Connectivity Technology	Bluetooth
Waterproof Rating	IPX6
Battery Life	Up to 42 hours (at minimum volume)
Product Dimensions	39.6 x 15.4 x 19.4 cm
Item Weight	3 kg
Special Features	Bass Boost, Built-in Microphone, Shockproof, Power Bank Function, RGB Lights, TWS Pairing
Microphone Input	1/4" (6.35mm) for wired dynamic microphone
Other Inputs	AUX, TF Card, USB

Warranty and Support

Warranty Information

This product is covered by a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact the manufacturer directly. The return policy for this product is

30 days for refund/replacement.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact W-KING customer support. Visit the official W-KING website for contact details or refer to your purchase platform for seller support.
Manufacturer: SHENZHEN WEIKING TECHNOLOGY CO.,LTD
For more information, you may visit theW-KING Store on Amazon.

© 2024 W-KING. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKMD8V34

More documents and user manuals: **https://manuals.plus/**