Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Ceihoit DVP-506

Ceihoit DVP-506 DVD Player User Manual

Model: DVP-506

Introduction

Thank you for purchasing the Ceihoit DVP-506 DVD Player. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly before use to ensure proper functionality and to maximize your viewing experience.

The Ceihoit DVP-506 is a versatile multimedia player designed to play DVDs, CDs, and media files from a USB drive. It features 1080p upscaling for enhanced picture quality and supports a wide range of disc and file formats.

Package Contents

Please check the box for the following items:

- Ceihoit DVP-506 DVD Player
- Remote Control (batteries not included)
- HDMI Cable (1.5m)
- AV Cable (RCA, 0.9m)
- User Manual



Image: Contents of the Ceihoit DVP-506 DVD Player package, showing the player, remote control, HDMI cable, AV cable, and user manual.

Image: Detailed view of the Ceihoit DVP-506 DVD Player and its accessories, including the remote, HDMI cable, AV cable, and user manual. The player's dimensions are also indicated: 22.5cm width, 20.5cm depth, 3.5cm height.

Product Overview

Front Panel

The front panel of the DVP-506 features the disc tray, display screen, control buttons, and a USB input port.

- **Disc Door:** For inserting DVDs and CDs.
- **Display:** Shows current time, track number, and other status indicators.
- **Control Buttons:** Play/Pause, Stop, Previous/Next Track.
- **USB Input:** For connecting USB flash drives to play multimedia files.

Rear Panel

The rear panel provides various connection ports for audio and video output.

- **HDMI Output:** Connects to modern TVs or projectors for high-definition video and audio.
- **AV Output (RCA):** Connects to older TVs or audio systems using composite video and stereo audio cables.
- **Coaxial Digital Output:** For connecting to a home theater receiver or amplifier for digital audio.
- **AC Input:** Power connection.



Image: Detailed diagram illustrating the front and rear panels of the Ceihoit DVP-506 DVD Player, with labels for the disc door, USB input, HDMI output, AV outputs (left, right, video), and coaxial digital output.

Remote Control

The remote control allows you to operate all functions of the DVD player from a distance. Insert two AAA batteries (not included) into the remote control before use. Ensure direct line of sight to the player's front panel for optimal performance.

Setup

Connecting to a TV or Display

Choose one of the following connection methods based on your TV's available inputs:

1. HDMI Connection (Recommended for HD Quality)

1. Connect one end of the HDMI cable to the HDMI OUT port on the DVD player.
2. Connect the other end of the HDMI cable to an HDMI IN port on your TV or projector.
3. Select the corresponding HDMI input on your TV using its remote control.



Image: The Ceihoit DVP-506 DVD Player connected via HDMI to a projector, demonstrating its compatibility with various display devices including Smart TVs and 4K TVs.

2. AV Connection (for Older TVs)

1. Connect the yellow plug of the AV cable to the VIDEO OUT port on the DVD player.
2. Connect the white plug to the AUDIO L (Left) OUT port on the DVD player.
3. Connect the red plug to the AUDIO R (Right) OUT port on the DVD player.
4. Connect the other ends of the AV cable to the corresponding VIDEO IN and AUDIO IN (L/R) ports on your TV.
5. Select the AV input on your TV using its remote control.



Image: The Ceihoit DVP-506 DVD Player connected to an older television using AV cables, illustrating its support for legacy display devices.



Image: The Ceihoit DVP-506 DVD Player, highlighting its HDMI and AV output ports, as well as the USB input. The image also indicates that HDMI and RCA cables are included in the package.

Power Connection

Plug the power cord into the AC input on the rear of the DVD player, then plug the other end into a standard wall outlet.

Operating Instructions

Basic Disc Playback

1. Power on the DVD player and your TV.
2. Open the disc tray by pressing the**OPEN/CLOSE** button on the remote or player.
3. Place a DVD or CD disc gently onto the tray with the label side facing up.
4. Press the **OPEN/CLOSE** button again to close the tray.
5. The player will automatically begin playback or display a disc menu. Use the remote control's arrow keys and **ENTER** button to navigate menus.

USB Playback

The DVP-506 supports playback of digital media files from a USB 2.0 flash drive (FAT/FAT32 format, up to 32GB capacity).

1. Insert your USB flash drive into the USB port on the front panel of the DVD player.
2. The player should automatically detect the USB drive and display a menu for selecting media types (e.g., Video, Photo, Music). If not, press the **USB** button on the remote.
3. Navigate through your files using the arrow keys and**ENTER** button on the remote.
4. Select a file to begin playback.

Supported USB Video Formats: AVI, MPG, MPEG4, VOB (720*480/576 resolution).



Image: A USB flash drive inserted into the USB input port on the front panel of the Ceihoit DVP-506 DVD Player, demonstrating its multimedia playback capability.

Special Functions

- **Resume Function:** The player can memorize the last playback position. If you power off the device or stop playback, it will resume from where you left off when powered on again.



Image: Visual representation of the resume function, where the Ceihoit DVP-506 DVD Player remembers the last playback position even after being powered off and then on again.

- **Fast Forward/Rewind:** Use the **FF/REW** buttons on the remote to quickly scan through content.
- **Previous/Next Track:** Use the **PREV/NEXT** buttons to skip between tracks or chapters.
- **OSD Menu:** Access the On-Screen Display menu for various settings (e.g., video, audio, language) by pressing the **SETUP** button on the remote.
- **1080p Upscaling:** The player enhances standard definition DVD content to near 1080p resolution for improved picture quality on compatible displays.



Image: A visual comparison highlighting the 1080p HD display quality achieved by the Ceihoit DVP-506 DVD Player compared to standard definition. The image also confirms support for multiple disc formats (DVD, CD, MP3, VCD) and region-free playback, while noting that Blu-ray discs are not supported.

- **Multi-Region Playback:** This player is designed to play DVDs from all regions.
- **Noise Cancellation:** Features built-in technology to reduce operational noise for a quieter viewing experience.



Image: An illustration depicting the noise cancellation feature of the Ceihoit DVP-506 DVD Player, designed to provide a quieter operation.

- **Anti-Shock:** Provides stable playback even with minor vibrations.



Image: An illustration demonstrating the anti-shock capability of the Ceihoit DVP-506 DVD Player, ensuring stable playback.

- **Smart Correction:** Improves image clarity and reduces blurriness.



Image: A visual comparison of an image "Before" and "After" smart correction, showcasing the Ceihoit DVP-506 DVD Player's ability to enhance image clarity.

Maintenance

- **Cleaning the Player:** Use a soft, dry cloth to wipe the exterior of the player. Do not use liquid cleaners or abrasive materials.
- **Cleaning Discs:** Wipe discs gently from the center outwards with a soft, lint-free cloth. Avoid touching the playback surface.
- **Storage:** Store the player in a cool, dry place away from direct sunlight, heat sources, and excessive dust.
- **Ventilation:** Ensure adequate ventilation around the player. Do not block ventilation openings.

Troubleshooting

Problem	Possible Cause	Solution
No power	Power cord not connected; Power outlet not active.	Ensure the power cord is securely plugged into the player and a working wall outlet.
No picture on TV	Incorrect video input selected on TV; Loose video cable connection; Incorrect cable type.	Select the correct HDMI or AV input on your TV. Check that video cables are securely connected. Ensure you are using the correct cable type (HDMI for HDMI input, AV for AV input).
No sound	Loose audio cable connection; TV/receiver volume too low or muted; Incorrect audio output selected.	Check audio cable connections. Increase TV/receiver volume and ensure it's not muted. Verify audio settings in the player's OSD menu.
Disc not playing	Disc is dirty or scratched; Disc format not supported; Disc inserted incorrectly.	Clean the disc with a soft cloth. Ensure the disc is inserted label-side up. Verify the disc format is supported (DVD, CD, VCD, MP3). Note: Blu-ray discs are not supported.
USB drive not recognized	USB drive format not supported; USB drive capacity too large; Corrupted files.	Ensure USB drive is formatted to FAT or FAT32 and is 32GB or less. Check if files are corrupted. Try a different USB drive.
Remote control not working	Batteries are dead or inserted incorrectly; Obstruction between remote and player; Remote out of range.	Replace batteries, ensuring correct polarity. Remove any obstructions. Point the remote directly at the player's front panel within range.

Specifications

Feature	Detail

Feature	Detail
Model Name	DVP-506
Brand	Ceihoit
Media Type	DVD, CD, VCD, MP3
Special Feature	Upscaling (1080p)
Resolution	1920x1080 (Output)
Connectivity Technology	HDMI, AV (RCA)
Connector Type	HDMI, AV
Color	Black
Audio Output Mode	Stereo
Included Components	AV Cable, HDMI Cable, DVD Player, Remote Control
Supported Audio Formats	MPEG, AC3
Number of Audio Channels	2.0
Total HDMI Ports	1
Video Encoding	MPEG-2
Compatible Devices	Television
Analog Video Standard	PAL/NTSC
Video Output Resolution	1080p
Supported USB File Formats	AVI, MPG, MPEG4, VOB (720*480/576)
USB Drive Format/Capacity	FAT/FAT32, up to 32GB
UPC/GTIN	850053052866

Safety Information

- Do not expose the unit to rain or moisture to prevent fire or electric shock.
- Do not open the casing. There are no user-serviceable parts inside. Refer all servicing to qualified personnel.
- Avoid placing the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Unplug this apparatus during lightning storms or when unused for long periods of time.

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or contact Ceihoit customer service. Details regarding specific warranty periods and support channels are typically provided at the point of sale or on the manufacturer's official website.
If you encounter any issues not covered in this manual, please reach out to our support team for assistance.

© 2024 Ceihoit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKNZNQJC

More documents and user manuals: **https://manuals.plus/**