Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Midea MF10EW90B

Midea MF10EW90B 9 kg 1400 RPM Washing Machine User Manual

Model: MF10EW90B

Important: Please read this manual carefully before using your appliance.

1. Safety Information

For your safety and to ensure correct use, read this manual carefully before installing and first using the appliance. Always keep these instructions with the appliance, even if you move or sell it.

1.1 General Safety

- This appliance is intended for household use only.
- Do not allow children or persons with reduced physical, sensory, or mental capabilities to operate the appliance without supervision.
- Keep packaging materials away from children.
- Ensure all transit bolts are removed before use. Failure to do so can cause serious damage.

1.2 Electrical Safety

- The appliance must be earthed.
- Do not use extension cords or multiple adapters.
- Do not pull the power cord to unplug the appliance. Always grasp the plug firmly.
- If the power cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons to avoid a hazard.

1.3 Water Safety

- Ensure water inlet and drain hoses are correctly installed to prevent leaks.
- Do not open the detergent dispenser during a wash cycle if water is visible.
- The appliance is equipped with AquaStop for enhanced water safety.

2. Product Overview

Familiarize yourself with the components of your Midea MF10EW90B washing machine.

2.1 Main Components



Image 1: Front view of the Midea MF10EW90B washing machine, highlighting its dimensions: 850mm height, 595mm width, and 495mm depth. Key features like 510mm large drum, Steam Care, Add Garment function, Energy Class A, BLDC Inverter Motor, and 10-year motor warranty are also indicated.

- **Detergent Dispenser:** For adding detergent and fabric softener.
- **Control Panel:** For selecting programs and settings.
- **Door:** Front-loading door for loading and unloading laundry.
- **Drum:** Large 510mm diameter stainless steel drum for efficient washing.
- **Service Filter Cover:** Located at the bottom right, for accessing the drain pump filter.

2.2 Control Panel



Image 2: Close-up view of the Midea MF10EW90B washing machine's control panel. It features a central digital display showing remaining time (e.g., 0:50), a program selection dial with various wash cycles (e.g., Schnellwäsche 15', 45', Kalt, Baumwolle, Jeans, Feinwäsche, Spülen und Schleudern, Steam Care), and touch buttons for additional functions like temperature, spin speed, and start/pause.

- **Program Selector Dial:** Turn to select the desired wash program.
- **Digital Display:** Shows remaining time, error codes, and selected options.
- **Temperature Button:** Adjusts the wash temperature (Cold, 20°C, 40°C, 60°C).
- **Spin Speed Button:** Adjusts the spin speed.
- **Start/Pause Button:** To start, pause, or cancel a wash cycle.
- **Function Buttons:** May include options like Pre-wash, Extra Rinse, Delay Start, etc. (refer to specific icons on your machine).

3. Installation and Setup

3.1 Unpacking and Removing Transit Bolts

1. Carefully remove all packaging materials.
2. Locate and remove the transit bolts at the rear of the machine. These bolts secure the drum during transport. Keep

them for future transport.

3. Insert the plastic caps provided into the holes left by the transit bolts.

3.2 Location and Leveling

- Place the washing machine on a firm, level floor.
- Ensure there is adequate ventilation around the appliance.
- Adjust the adjustable feet at the bottom of the machine until it is perfectly level and stable. Use a spirit level to check.

3.3 Water Connection

- Connect the water inlet hose to a cold water tap with a 3/4" thread. Ensure the connection is tight to prevent leaks.
- Place the drain hose into a standpipe or over the edge of a sink, ensuring it is securely fixed to prevent displacement during draining. The height of the drain hose should be between 60 cm and 100 cm from the floor.

3.4 Electrical Connection

- Plug the appliance into a grounded electrical outlet (220V).
- Ensure the socket is easily accessible after installation.

4. Operating the Washing Machine

4.1 Preparing Laundry

1. Sort laundry by fabric type, color, and degree of soiling.
2. Check garment care labels for washing instructions.
3. Empty pockets, close zippers, and fasten hooks.

4.2 Loading Laundry



Image 3: The Midea MF10EW90B washing machine with its door open, revealing the spacious stainless steel drum. This view demonstrates the front-loading design, ready for laundry to be placed inside.

- Open the washing machine door.
- Load laundry loosely into the drum, ensuring not to overload. The maximum capacity is 9 kg.
- Close the door firmly until it clicks shut.

4.3 Adding Detergent and Additives

- Pull out the detergent dispenser drawer.
- Add the recommended amount of detergent to the main wash compartment (usually marked II).
- If using pre-wash, add detergent to the pre-wash compartment (usually marked I).
- Add fabric softener to the softener compartment (usually marked with a flower symbol). Do not exceed the MAX line.
- Gently push the dispenser drawer back in.

4.4 Selecting a Wash Program



Image 4: A visual guide illustrating the temperature options available on the Midea MF10EW90B washing machine. It shows four settings: 60°C for disinfection, 40°C for stain removal, 20°C for gentle care of colors and fabrics, and COLD for energy-saving washes.

1. Turn the Program Selector Dial to choose the appropriate program for your laundry. Common programs include:
    - **Cotton:** For durable cotton items.
    - **Synthetics:** For synthetic or mixed fabrics.

- **Delicates:** For delicate items requiring gentle washing.
- **Quick Wash 15'/45':** For lightly soiled items or small loads needing a fast wash.
- **Steam Care:** Reduces odors and wrinkles, and eliminates bacteria.
- **Jeans:** Specific program for denim.

2. Adjust the temperature (Cold, 20°C, 40°C, 60°C) and spin speed using the respective buttons if needed.
3. Select any additional functions (e.g., Extra Rinse, Delay Start) if desired.

4.5 Starting a Wash Cycle

- Press the Start/Pause button to begin the wash cycle. The display will show the remaining time.
- To pause the cycle, press the Start/Pause button again. Press it once more to resume.
- To cancel a cycle, press and hold the Start/Pause button for a few seconds.

4.6 Special Functions

- **Add Garment Function:** If the "Add Garment" indicator lights up during a cycle, you can pause the machine and add forgotten items. Wait for the door to unlock before opening.
- **Child Lock:** To activate, press and hold the designated buttons (refer to your control panel for specific combination, usually two function buttons) for a few seconds. This prevents accidental changes to settings. Repeat to deactivate.

5. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your washing machine.

5.1 Cleaning the Detergent Dispenser

1. Pull out the dispenser drawer completely.
2. Remove any removable parts (e.g., softener insert).
3. Rinse all parts under running water to remove detergent residue.
4. Clean the dispenser housing with a brush.
5. Reassemble and reinsert the drawer.

5.2 Cleaning the Drum and Door Seal

- Run a maintenance wash (e.g., a hot cycle with no laundry and a descaling agent or washing machine cleaner) periodically to clean the drum.
- Wipe the door seal with a damp cloth after each wash to remove lint and residue. Check for any trapped objects.

5.3 Cleaning the Drain Pump Filter

1. Place a shallow container under the filter cover to catch any residual water.
2. Open the service filter cover (bottom right of the machine).
3. Slowly unscrew the filter counter-clockwise.
4. Remove any lint, coins, or other debris from the filter and its housing.
5. Rinse the filter under running water.
6. Screw the filter back in clockwise until tight, then close the cover.

5.4 Exterior Cleaning

- Wipe the exterior surfaces with a soft, damp cloth.

- Do not use abrasive cleaners or solvents.

6. Troubleshooting

Before contacting service, check the following common issues and solutions:

Problem	Possible Cause	Solution
Machine does not start	No power; Door not closed; Program not selected; Start/Pause not pressed.	Check power supply; Close door firmly; Select program; Press Start/Pause.
Water not filling	Water tap closed; Water inlet hose kinked/blocked; Water pressure too low.	Open water tap; Straighten/clean hose; Check water supply.
Water not draining	Drain hose kinked/blocked; Drain pump filter blocked.	Straighten/clean drain hose; Clean drain pump filter (see Section 5.3).
Excessive vibration/noise	Transit bolts not removed; Machine not level; Load unbalanced.	Remove transit bolts; Level the machine; Redistribute laundry in the drum.
Error code on display	Specific fault detected.	Refer to the full user manual for a list of error codes and their solutions. If the problem persists, contact customer service.

7. Specifications

Brand	Midea
Model Number	MF10EW90B
Capacity	9 Kilograms
Maximum Spin Speed	1400 RPM
Energy Efficiency Class	A
Motor Type	BLDC Inverter Quattro Motor
Special Features	Steam Function, Large Drum (510mm), Add-Load Function, Child Lock, AquaStop
Number of Programs	15
Voltage	220 Volts
Noise Level (Spin)	72 Decibels
Dimensions (H x W x D)	85 cm x 59.5 cm x 49.5 cm
Product Weight	61 Kilograms

8. Warranty and Support

Your Midea washing machine comes with a manufacturer's warranty. Please refer to the warranty card included with your appliance for specific terms and conditions, including the warranty period and coverage details.

For technical assistance, spare parts, or service requests, please contact Midea customer support or visit the official Midea website for your region. Have your model number (MF10EW90B) and serial number ready when contacting support.

Midea Official Website: www.midea.com

© 2023 Midea. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKT9ZY6B

More documents and user manuals: **https://manuals.plus/**