Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Fakir TS 122

Fakir Trend TS 122 Bagged Vacuum Cleaner User Manual

Model: TS 122 | Brand: Fakir

1. Introduction

Thank you for choosing the Fakir Trend TS 122 Bagged Vacuum Cleaner. This appliance is designed to provide efficient and thorough cleaning for your home. Featuring a powerful 700 Watt motor, an advanced EPA filter system, and a generous 2-liter dust bag, the TS 122 ensures a clean and hygienic environment. This manual provides essential information for the safe and effective use, maintenance, and troubleshooting of your new vacuum cleaner. Please read it carefully before first use and keep it for future reference.

2. Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using an electrical appliance. This includes:

- Read all instructions before using the appliance.
- Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with a damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not pick up toxic material (e.g., chlorine bleach, ammonia cleaner, drain cleaner).

- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.

3. Product Overview

The Fakir Trend TS 122 is a powerful and versatile bagged vacuum cleaner designed for effective home cleaning. Key features include:

- **High-Performance Motor:** A 700 Watt motor provides strong suction power, adjustable for various cleaning needs.
- **EPA Filter System:** Captures pollen, spores, germs, and allergens, ensuring cleaner exhaust air.
- **Large Dust Bag:** A 2-liter capacity dust bag reduces the frequency of changes and maintains consistent suction.
- **Compact Design:** Measuring 35.5 x 26.5 x 21.5 cm, it is easy to store and maneuver.
- **Extended Reach:** A 7-meter power cord provides a wide operating radius without frequent outlet changes.
- **Versatile Accessories:** Includes a switchable floor nozzle, a 2-in-1 crevice/furniture brush, and an upholstery nozzle for comprehensive cleaning.


Fakir
HAUSGERÄTE
trend | TS 122
Fakir
HAUSGERÄTE

Figure 1: Fakir Trend TS 122 Vacuum Cleaner with accessories. This image shows the main unit, flexible hose, telescopic tube, and floor nozzle.

4. Setup

Follow these steps to assemble your Fakir Trend TS 122 vacuum cleaner:

1. **Attach the Flexible Hose:** Insert the hose end into the suction inlet on the main unit until it clicks securely into place.
2. **Connect the Telescopic Tube:** Attach the handle end of the flexible hose to the wider end of the telescopic tube.
3. **Attach the Floor Nozzle:** Connect the desired floor nozzle (e.g., the switchable floor nozzle) to the narrower end of the telescopic tube. Ensure it is firmly attached.
4. **Insert Dust Bag (if not pre-installed):** Open the dust bag compartment (usually located at the front or top of the main unit). Carefully insert a new dust bag, ensuring the cardboard collar is properly seated in the holder and the opening aligns with the suction inlet. Close the compartment securely.
5. **Check Filters:** Ensure all filters (motor protection filter, EPA filter) are correctly installed before use. Refer to the Maintenance section for filter locations.



Figure 2: Side view of the Fakir Trend TS 122, illustrating the main unit and handle. This view helps locate the dust bag compartment.

5. Operating Instructions

Using your Fakir Trend TS 122 vacuum cleaner is straightforward:

1. **Power Connection:** Extend the power cord and plug it into a suitable electrical outlet (220 Volt). The cord rewind button allows for automatic retraction.
2. **Power On/Off:** Press the On/Off button (usually marked with 'I/O' or a power symbol) located on the main unit to start or stop the vacuum cleaner.
3. **Adjust Suction Power:** The vacuum cleaner features an electronic power regulator. Turn the dial or slide the control on the main unit to adjust the suction power according to the surface being cleaned. Lower power for delicate fabrics, higher power for carpets and heavily soiled areas.
4. **Using Attachments:**
    - **Switchable Floor Nozzle:** Use for both hard floors and carpets. Switch the brush setting using the foot pedal on the nozzle.
    - **Crevice Nozzle:** Ideal for narrow gaps, corners, and edges.
    - **Furniture Brush:** Use for dusting furniture, curtains, and delicate surfaces.
    - **Upholstery Nozzle:** Designed for cleaning sofas, chairs, and other upholstered items.
5. **Telescopic Tube Adjustment:** Adjust the length of the telescopic tube for comfortable operation.
6. **Parking Position:** When taking a break, you can hook the floor nozzle onto the parking clip on the main unit for convenient storage.



Figure 3: Top view of the Fakir Trend TS 122, highlighting the power and cord rewind buttons for easy access during operation.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

6.1. Replacing the Dust Bag

1. Unplug the vacuum cleaner from the power outlet.
2. Open the dust bag compartment.
3. Carefully remove the full dust bag by pulling the cardboard collar. Dispose of the bag responsibly.
4. Insert a new Fakir original dust bag, ensuring it is correctly seated and sealed.
5. Close the dust bag compartment securely.

6.2. Cleaning/Replacing Filters

Your Fakir Trend TS 122 is equipped with a motor protection filter and an EPA filter. These should be checked regularly.

- **Motor Protection Filter:** This filter protects the motor from dust. It is usually located behind the dust bag. Check it every 3-5 dust bag changes. If it is heavily soiled, tap it clean or rinse it under cold water (if washable) and allow it to dry completely before reinserting. Replace if damaged or excessively dirty.
- **EPA Filter:** The EPA filter is located at the exhaust air outlet. It should be checked every 6-12 months or if you notice a decrease in suction power or an increase in dust in the exhaust air. This filter is typically not washable and should be replaced when dirty.

6.3. General Cleaning

- Wipe the exterior of the vacuum cleaner with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Periodically check the floor nozzle for tangled hair or debris and remove them to ensure effective cleaning.
- Ensure the hose and telescopic tube are free from blockages.

7. Troubleshooting

If you encounter problems with your vacuum cleaner, refer to the following table for common issues and solutions:

Problem	Possible Cause	Solution
Vacuum cleaner does not switch on.	No power supply.	Check if the plug is securely inserted into the outlet. Check the fuse/circuit breaker.
Low suction power.	Dust bag is full. Filters are clogged. Hose/tube/nozzle is blocked.	Replace the dust bag. Clean or replace filters. Check and clear any blockages.
Unusual noise during operation.	Blockage in the hose/nozzle. Dust bag or filter incorrectly installed. Foreign object in the fan.	Check for and remove blockages. Reinstall dust bag and filters correctly. Turn off and unplug, then check for foreign objects (contact service if inaccessible).
Dust escaping from the vacuum cleaner.	Dust bag or filters incorrectly installed or damaged.	Ensure dust bag and filters are correctly installed and not damaged. Replace if necessary.

If the problem persists after checking these points, please contact Fakir customer support.

8. Specifications

Feature	Detail
Brand	Fakir
Model Name	TREND
Model Number	TS 122
Power (Motor)	700 Watt
Dust Bag Capacity	2 Liters
Filter Type	EPA Filter, Motor Protection Filter
Power Source	Corded Electric (220 Volt)

Feature	Detail
Cable Length	7 meters
Hose Length	1.5 meters
Noise Level	75 Decibels
Dimensions (LxWxH)	26.5L x 21.5W x 35.5H cm
Weight	4.8 Kilograms
Recommended Surfaces	All floor types
Included Components	Switchable floor nozzle, crevice nozzle, furniture brush, upholstery nozzle
Special Features	Automatic cable rewind, compact, lightweight, continuous power adjustment

9. Warranty and Support

Fakir products are manufactured to high-quality standards and come with a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, spare parts, or service inquiries, please contact your local Fakir service center or visit the official Fakir website. Keep your purchase receipt as proof of purchase for warranty claims.

Note: Spare parts for this model are available in the EU for a duration of 7 years.

© 2023 Fakir. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKY1ZQQM

More documents and user manuals: **https://manuals.plus/**