Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Candy CSOW 4855TW4/1-S

Candy Smart Pro CSOW 4855TW4/1-S Washer Dryer User Manual

Model: CSOW 4855TW4/1-S | Brand: Candy

1. Introduction

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Candy Smart Pro CSOW 4855TW4/1-S washer dryer. Please read this manual thoroughly before using the appliance and keep it for future reference.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons. This appliance is intended for domestic use only.

- Ensure the appliance is properly grounded.
- Do not allow children to play with or operate the appliance.
- Unplug the appliance before performing any maintenance or cleaning.
- Do not overload the washer dryer. Refer to capacity guidelines.
- Keep flammable materials away from the appliance.
- Do not wash or dry articles that have been soiled with vegetable oil or cooking oil.

3. Setup and Installation

Proper installation is crucial for the performance and safety of your washer dryer.

3.1 Unpacking

Remove all packaging materials and transport bolts from the rear of the appliance. Keep packaging materials out of reach of children.



Image: Rear view of the Candy Smart Pro washer dryer, illustrating the position of the water inlet and drain hoses, and the areas where transport bolts are typically located before installation.

3.2 Positioning

Place the washer dryer on a firm, level floor. Adjust the leveling feet to ensure stability and prevent vibrations during operation.

3.3 Water and Drain Connections

- Connect the water inlet hose to a cold water tap.
- Securely attach the drain hose to a standpipe or laundry tub, ensuring it is not kinked.

3.4 Electrical Connection

Plug the appliance into a grounded electrical outlet. Ensure the voltage and frequency match the specifications listed on the appliance's rating plate.

4. Operating Instructions

This section guides you through the daily use of your Candy Smart Pro washer dryer.



Image: Front view of the Candy Smart Pro washer dryer, displaying the control panel, detergent drawer, and main loading door.

4.1 Loading Laundry

Open the door and load items loosely into the drum. Do not exceed the maximum load capacity of 8 kg for washing and 5 kg for drying.



Image: A person loading laundry into the open drum of the Candy Smart Pro washer dryer, demonstrating the front-loading access.

4.2 Adding Detergent

Pull out the detergent drawer and add the appropriate amount of detergent and fabric softener to the designated compartments.

4.3 Selecting a Program

Turn the program selector dial to choose the desired wash or wash & dry program. The display will show the default settings for the selected program.



Image: A hand turning the program selector dial on the Candy Smart Pro washer dryer, highlighting the user interface for program selection.

4.4 Starting the Cycle

Press the Start/Pause button to begin the cycle. The appliance will automatically proceed through the selected program.

5. Maintenance and Cleaning

Regular maintenance ensures optimal performance and extends the lifespan of your appliance.

5.1 Cleaning the Detergent Drawer

Periodically remove and clean the detergent drawer under running water to prevent residue buildup.

5.2 Cleaning the Drum

Run a maintenance wash cycle (e.g., at 60°C or 90°C) with a descaling agent or a small amount of detergent to clean the drum and internal components.



Image: A detailed view of the stainless steel drum interior, showing the textured surface designed for effective washing and drying.

5.3 Cleaning the Drain Filter

Regularly clean the drain filter to prevent blockages and ensure proper drainage. This is typically located at the bottom front of the appliance.



Image: The drain filter compartment opened, with the filter unit removed and placed beside it, demonstrating access for cleaning.

5.4 Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.

6. Troubleshooting

Before contacting customer service, refer to this section for solutions to common issues.

Problem	Possible Cause	Solution
Appliance does not start	No power supply; Door not closed; Program not selected.	Check power plug; Ensure door is securely latched; Select a program and press Start.
Water not filling	Water tap closed; Inlet hose kinked; Water pressure too low.	Open water tap; Straighten hose; Check household water pressure.
Water not draining	Drain hose kinked; Drain filter blocked.	Straighten drain hose; Clean the drain filter (refer to Section 5.3).
Excessive vibration/noise	Transport bolts not removed; Appliance not level; Uneven load.	Remove transport bolts; Adjust leveling feet; Redistribute laundry in the drum.
Clothes not drying properly	Overloaded; Wrong drying program; Lint filter blocked (if applicable).	Reduce load size; Select appropriate drying program; Clean lint filter.

7. Specifications

Technical details of the Candy Smart Pro CSOW 4855TW4/1-S washer dryer.

- **Model:** CSOW 4855TW4/1-S
- **Manufacturer:** Candy
- **Type:** Freestanding Front-Loading Washer Dryer
- **Washing Capacity:** 8 kg
- **Drying Capacity:** 5 kg
- **Maximum Spin Speed:** 1400 rpm
- **Spin-Drying Efficiency Class:** B
- **Energy Efficiency Class (Washing):** B
- **Energy Efficiency Class (Washing & Drying):** E
- **Water Consumption (Washing):** 44 L per cycle
- **Dimensions (H x W x D):** 85 cm x 60 cm x 54 cm
- **Weight:** 66 kg
- **Voltage:** 230 Volts
- **Power:** 1550 Watts
- **Product Reference:** 31019543

8. Warranty and Support

For warranty information and customer support, please refer to the warranty card provided with your appliance or visit the official Candy website. Keep your proof of purchase for warranty claims.
Manufacturer: Candy
Model Number: 31019543
ASIN: B0CKZ7HXMT

© 2023 Candy. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CKZ7HXMT

More documents and user manuals: **https://manuals.plus/**