ZdalaMit EN2J30H

ZdalaMit EN2J30H Replacement Remote Control User Manual

For Hisense Vidaa Smart TVs

1. Introduction

This manual provides instructions for the ZdalaMit EN2J30H replacement remote control. This remote is designed to be compatible with various Hisense Vidaa Smart TV models, offering a direct replacement without the need for complex programming. Please read this manual carefully to ensure proper use and longevity of your remote control.

2. Product Overview

The ZdalaMit EN2J30H is a dedicated replacement remote control for Hisense Vidaa Smart TVs. It features a standard layout with buttons for power, input selection, channel navigation, volume control, and direct access to popular streaming services. Its ergonomic design ensures comfortable handling.





Figure 2.1: Front view of the ZdalaMit EN2J30H replacement remote control, showcasing its button layout including numerical keys, navigation pad, volume, channel, and dedicated app buttons.

3. Setup

3.1 Battery Installation

The ZdalaMit EN2J30H remote control requires two (2) AAA alkaline batteries (not included) for operation. Follow these steps to install the batteries:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down on the tab and slide the cover downwards to open the compartment.
3. Insert two new 1.5V AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals match the diagrams inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

Once batteries are installed, the remote control is ready for immediate use with compatible Hisense Vidaa Smart TVs. No programming is required.

4. Operating Instructions

This remote control functions identically to the original Hisense EN2J30H remote. Point the remote directly at your Hisense Vidaa Smart TV to ensure proper signal transmission.

4.1 Key Functions

- **Power Button ( )**: Turns the TV on or off.
- **Input Button**: Selects the input source (HDMI, AV, etc.).
- **Number Buttons (0-9)**: Direct channel selection.
- **CH.LIST Button**: Displays the channel list.
- **GUIDE Button**: Accesses the electronic program guide.
- **Navigation Pad (Up, Down, Left, Right, OK)**: Navigates menus and confirms selections.
- **Back Button (↶)**: Returns to the previous screen or menu.
- **Exit Button**: Exits the current menu or application.
- **Volume Up/Down (VOL +/-)**: Adjusts the TV volume.
- **Mute Button ( )**: Mutes or unmutes the TV audio.
- **Channel Up/Down (CH +/-)**: Changes TV channels.
- **Home Button (⌂)**: Accesses the TV's home screen or smart hub.
- **Dedicated App Buttons (e.g., Netflix, YouTube, Prime Video)**: Provides direct access to specified streaming applications.
- **Media Button**: Opens the media player.
- **Browser Button**: Launches the TV's web browser.

4.2 Compatible Hisense Vidaa TV Models

This remote control is compatible with the following Hisense Vidaa Smart TV models:

- 32A45GV, 40H5G, 50V6G, 65A60G, 43A6050GMV, 50H6G, 40A4GV, 50H77G, 50A60G, 55A60GMV, 40A40GV, 65A6030GMV, 40A40GMV, 40H55G, 40A4HV, 65A6010GMV, 50A6030GMV, 65A6050GMV, 40A4070GMV, 43H6G, 43H77G, 43V6G, 43A60G, 65A6090GMV, 43A60H, 43A60GMV, 43A6010GMV, 55A6050GMV, 43A6030GMV, 43A6070GMV, 65A6070GMV, 43A6090GMV, 50A60H, 50A6050GMV, 50A6070GMV, 50A6090GMV, 65A60GMV, 55A6010GMV, 55H6G, 55H77G, 55V6G, 55A60G, 55A60H, 55A6030GMV, 55A6070GMV, 55A6090GMV, 65H6G, 65H77G, 65A60H, 50A6010GMV, 65V6G, 50A60GMV

5. Maintenance

- **Cleaning**: Use a soft, dry cloth to clean the remote control. Do not use liquid cleaners or abrasive materials.
- **Battery Care**:
    - Replace batteries when the remote's response becomes sluggish or stops working.
    - Always replace both batteries at the same time with new ones of the same type (AAA alkaline).
    - Remove batteries if the remote control will not be used for an extended period to prevent leakage.

- Dispose of used batteries according to local regulations.

- **Storage**: Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures.

6. Troubleshooting

Problem	Solution
Remote control is not working.	• Ensure batteries are installed correctly with the correct polarity (+/-). • Replace old batteries with new 1.5V AAA alkaline batteries. • Check for any obstructions between the remote control and the TV's infrared sensor. • Ensure you are within the effective range and pointing the remote directly at the TV.
Some buttons are not responding.	• This remote is a direct replacement for the original EN2J30H. Ensure your TV model is listed as compatible. • Clean the remote control surface, especially around the unresponsive buttons, to remove any dirt or debris. • Try replacing the batteries, even if some functions still work.

7. Specifications

- **Model:** EN2J30H
- **Brand:** ZdalaMit
- **Power Supply:** 2 x 1.5V AAA Alkaline Batteries (not included)
- **Compatible Devices:** Hisense Vidaa Smart Televisions
- **Dimensions:** 5.9 x 1.57 x 0.55 inches (approximately)
- **Item Weight:** 1.41 ounces (without batteries)
- **Color:** Black
- **Special Feature:** Ergonomic design

8. Support

For any queries or assistance regarding your ZdalaMit EN2J30H replacement remote control, please contact the seller or manufacturer's customer support. Refer to your purchase documentation for specific contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question