Pure 252517

Pure Elan One2 Portable DAB+/FM Radio User Manual

Model: 252517

Introduction

The Pure Elan One2 is a versatile and modern portable radio designed for crystal-clear audio enjoyment. It features DAB+ and FM radio reception, Bluetooth 5.1 connectivity, and an easy-to-read LCD display. This manual provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your Elan One2 radio.

What's in the Box

- Pure Elan One2 Radio Unit
- Power Cable
- User Manual (this document)

Note: 4xAA batteries are required for portable use and are not included.

Product Overview



Figure 1: Front View of Elan One2. This image shows the front of the Pure Elan One2 radio, featuring the speaker grille on the left and the LCD display on the right. The Pure logo is visible below the display.



Figure 2: Top Controls. This image displays the top panel of the Elan One2, highlighting the telescopic antenna, five preset buttons (1-5), Source, Menu/Back, Info, Stations, Select, Volume, Snooze, and Power buttons.



Figure 3: Rear Panel. The back of the Elan One2 radio is shown, featuring the battery compartment cover, power switch (On/Off), DC input, and headphone output.

Setup

1. Powering Your Radio

The Elan One2 can be powered by the included power cable or by 4xAA batteries (not included).

1. **Mains Power:** Connect the supplied power cable to the DC input port on the back of the radio and plug the other end into a wall socket.
2. **Battery Power:** Open the battery compartment on the back of the radio. Insert 4xAA batteries, ensuring correct polarity. Close the compartment securely.

2. Initial Setup and First Use

1. Extend the telescopic antenna fully for optimal reception.
2. Switch the power button on the back of the radio to the 'On' position.
3. The radio will power on and may automatically begin scanning for DAB+ stations.
4. Once the scan is complete, the radio will display the first available station.

Operating Instructions

1. Switching Between Modes (DAB+, FM, Bluetooth)

Press the **Source** button repeatedly to cycle through available modes: DAB+, FM, and Bluetooth.

2. DAB+ Radio Operation

- **Station Selection:** Use the **Stations** buttons (*Previous/Next*) to browse through available DAB+ stations. Press the **Select** button (the large rotary knob) to confirm your selection.
- **Full Scan:** If you move the radio to a new location or wish to update the station list, press and hold the **Menu/Back** button, then navigate to 'Full Scan' and press **Select**.
- **Preset Stations:** To save a station, tune to the desired station, then press and hold one of the preset buttons (1-5) until "Preset Saved" appears on the display. To recall a saved station, simply press the corresponding preset button (1-5).

3. FM Radio Operation

- **Tuning:** In FM mode, use the **Stations** buttons (*Previous/Next*) to manually tune the frequency. Press and hold the **Stations** buttons to auto-scan for the next available station.
- **Preset Stations:** Similar to DAB+, press and hold a preset button (1-5) to save the current FM station. Press the button briefly to recall.

4. Bluetooth Operation

- **Pairing:** Switch the radio to Bluetooth mode. The display will show "Pairing". On your Bluetooth-enabled device (smartphone, tablet, laptop), search for "Pure Elan One2" in the Bluetooth settings and select it to pair.
- **Streaming:** Once paired, you can stream audio from your device to the Elan One2. Control playback (play/pause, skip tracks) from your connected device.

5. Volume Control

Rotate the **Volume** knob (the large rotary knob) clockwise to increase volume and counter-clockwise to decrease volume.

6. Alarm and Sleep Timer

- **Alarm:** Press the **Menu/Back** button, navigate to 'Alarm' settings. Follow the on-screen prompts to set alarm time, source (DAB+/FM/Buzzer), and volume.
- **Snooze:** When an alarm sounds, press the **Snooze** button to temporarily silence it.
- **Sleep Timer:** Press the **Menu/Back** button, navigate to 'Sleep Timer'. Select the desired duration (e.g., 15, 30, 60 minutes) after which the radio will automatically turn off.

Maintenance

- **Cleaning:** Wipe the radio with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Antenna Care:** Handle the telescopic antenna with care to prevent bending or damage.
- **Battery Replacement:** If using batteries, replace all four AA batteries simultaneously when the low battery indicator appears or audio quality degrades.
- **Storage:** If storing the radio for an extended period, remove the batteries to prevent leakage.

Troubleshooting

Problem	Possible Cause	Solution
No power / Radio does not turn on.	Power cable not connected, batteries depleted or incorrectly inserted, power switch off.	Ensure power cable is securely connected. Check battery polarity and replace if necessary. Verify power switch is in 'On' position.
Poor DAB+ or FM reception.	Antenna not extended, weak signal area, interference.	Fully extend the telescopic antenna. Try repositioning the radio. Perform a full scan for DAB+ stations.
Bluetooth device cannot pair.	Radio not in Bluetooth mode, device too far, device already paired with another unit.	Ensure radio is in Bluetooth mode. Move device closer to the radio. Disconnect from other Bluetooth devices.
No sound from speaker.	Volume too low, headphones connected, mute activated.	Increase volume. Disconnect headphones. Check if mute function is active (if applicable).

Specifications

Model: Pure Elan One2

Item Model Number: 252517

Tuner Technology: DAB+, FM

Connectivity: Bluetooth 5.1

Display: 2.2-inch LCD (black/white)

Power Source: Corded Electric (via included power cable) or 4xAA Batteries (not included)

Product Dimensions: 16 cm (L) x 5.3 cm (W) x 11 cm (H)

Weight: 350 g

Manufacturer: Pure

Country of Origin: China

Warranty and Support

For warranty information and technical support, please refer to the official Pure website or contact Pure customer service directly. Details can typically be found on the manufacturer's packaging or their official online resources.
You can visit the Pure brand store on Amazon for more information:Pure Store

© 2025 Pure. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question