SOGO FRE-SS-10865

Sogo Digi Fryer Air Fryer (3.5 Liters 1200W) User Manual

Model: FRE-SS-10865

1. Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electric shock, do not immerse cord, plugs, or main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- This appliance is for household use only.

2. Product Overview

The Sogo Digi Fryer Air Fryer is a versatile kitchen appliance designed for frying, baking, roasting, and dehydrating with minimal oil. It features a 3.5-liter capacity and 1200W power, making it suitable for various cooking needs.



Figure 2.1: The Sogo Digi Fryer Air Fryer, a compact and efficient kitchen appliance, shown with a serving of crispy french fries, demonstrating its primary function.



Figure 2.2: This image illustrates key benefits of the Sogo Air Fryer, including its intuitive touch screen for ease of use, non-stick coating for simple cleaning, and a generous 3.5-liter capacity suitable for family meals. It emphasizes healthier cooking with less fat.

3. Setup and First Use

1. **Unpacking:** Carefully remove the air fryer and all packaging materials. Ensure all components are present: main unit, removable basket, and non-stick bowl.
2. **Initial Cleaning:** Before first use, wipe the exterior of the appliance with a damp cloth. Wash the removable basket and non-stick bowl with warm, soapy water. Rinse thoroughly and dry completely. Do not immerse the main unit in water.
3. **Placement:** Place the air fryer on a stable, heat-resistant, and level surface. Ensure there is adequate space (at least 10 cm / 4 inches) around the appliance for proper ventilation. Do not place it directly against a wall or under cabinets.
4. **Power Connection:** Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the specifications of your appliance (220-240V~ 50-60Hz).

5. **Pre-heating (Optional but Recommended):** For the first use, it is recommended to run the air fryer empty for about 10-15 minutes at 180°C (356°F) to eliminate any manufacturing odors. A slight odor may be present during this process; this is normal.

4. Operating Instructions

4.1. Controls and Display

The Sogo Digi Fryer features a user-friendly LED touch screen for easy operation.



Figure 4.1: This image showcases the Sogo Air Fryer's LED touch screen interface, emphasizing its 3.5L capacity and 1200W power. It highlights the 8 preset functions that simplify frying, baking, roasting, and grilling, promoting energy efficiency.

4.2. Basic Operation Steps

1. **Prepare Food:** Place your ingredients into the removable non-stick bowl. Do not overfill the basket to ensure even cooking.
2. **Insert Basket:** Slide the bowl and basket assembly firmly back into the main unit until it clicks into place.

3. **Power On:** Plug the appliance into a power outlet. The display will light up.
4. **Set Temperature and Time:**
    - Use the touch controls to adjust the temperature (from 80°C to 200°C) and cooking time (up to 60 minutes).
    - Alternatively, select one of the 8 preset functions for common dishes.
5. **Start Cooking:** Press the start button to begin the cooking process. The fan and heating element will activate.
6. **Shake Basket (Optional):** For some foods, especially fries or smaller items, it is recommended to shake the basket halfway through the cooking time to ensure even browning. Carefully pull out the basket, shake, and reinsert. The appliance will pause and resume cooking automatically.
7. **Cooking Completion:** The air fryer will beep when the set cooking time has elapsed. Carefully pull out the basket and check if the food is cooked to your preference.
8. **Serve:** Carefully remove the cooked food from the basket. Use non-scratch utensils.

4.3. Cooking Tips

- For crispy results, lightly brush or spray food with oil.
- Smaller food items usually require a shorter cooking time than larger ones.
- Pre-packaged foods designed for oven cooking can also be prepared in the air fryer.
- The air fryer is excellent for reheating leftovers, making them crispy again.



Figure 4.2: This visual highlights the versatility of the Sogo Air Fryer, showcasing a variety of quick and delicious meals that can be prepared, including french fries, fried chicken, and chicken nuggets, emphasizing its multi-functional capabilities.

5. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

1. **Unplug and Cool Down:** Always unplug the air fryer from the power outlet and allow it to cool completely before cleaning.
2. **Clean Removable Parts:** The removable basket and non-stick bowl can be washed in warm, soapy water. Use a non-abrasive sponge. These parts are also dishwasher safe.
3. **Clean Interior:** Wipe the interior of the appliance with a damp cloth. For stubborn residue, use a mild detergent. Avoid abrasive cleaners or scouring pads.
4. **Clean Exterior:** Wipe the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive materials.
5. **Storage:** Ensure all parts are clean and dry before storing the air fryer. Store it in a cool, dry place.

Caution: Never immerse the main unit of the air fryer in water or any other liquid.

6. Troubleshooting

Problem	Possible Cause	Solution
Air fryer does not turn on.	Not plugged in; power outlet malfunction; basket not inserted correctly.	Check power cord connection; try a different outlet; ensure basket is fully pushed in.
Food is not cooked evenly.	Basket is overloaded; food not shaken during cooking.	Reduce food quantity; shake the basket halfway through cooking.
White smoke coming from the appliance.	Grease residue from previous use; cooking fatty foods.	Clean the basket and bowl thoroughly; remove excess oil from food before cooking.
Food is not crispy.	Not enough oil applied; temperature too low; cooking time too short.	Lightly brush or spray food with oil; increase temperature or cooking time.

7. Specifications

- **Model Number:** FRE-SS-10865
- **Capacity:** 3.5 Liters
- **Power:** 1200 Watts
- **Voltage:** 220-240V~
- **Frequency:** 50-60Hz
- **Temperature Range:** 80°C - 200°C
- **Timer:** Up to 60 minutes
- **Control Method:** Touch Screen (LED Display)
- **Construction:** Unique, Freestanding
- **Color:** Black, Silver
- **Product Dimensions (L x W x H):** Approximately 40 x 40 x 40 cm (packaging dimensions, refer to Figure 7.1 for unit dimensions)
- **Product Weight:** Approximately 3.99 kg
- **Features:** Removable non-stick bowl, cool-touch handle, anti-slip feet, integrated on/off button.



Figure 7.1: This image provides a visual representation of the Sogo Air Fryer's approximate unit dimensions, indicating a top length of 35 cm, a top width of 28 cm, and a height of 29 cm. It also highlights adjustable temperature control, time control, and overall safety and efficiency.



Figure 7.2: This image displays the product label for the SOGO Air Fryer, model SS-10865. It confirms the 3.5L capacity, electrical specifications (220-240V~ 50-60Hz, 1200W), serial number, and manufacturer details (Sanysan Appliances S.L., Valencia, Spain, Made in China).

8. Warranty and Support

This Sogo Digi Fryer Air Fryer (Model: FRE-SS-10865) comes with a**3-year warranty** from the date of purchase.
The warranty covers defects in materials and workmanship under normal household use. It does not cover damage resulting from misuse, accident, alteration, neglect, or unauthorized repair.
For warranty claims, technical support, or spare parts inquiries, please contact your local retailer or the Sogo customer service department. Please have your model number (FRE-SS-10865) and proof of purchase ready.
Manufacturer: SOGO Human Technology

© 2024 SOGO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question