Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

CUBOT X70

CUBOT X70 Smartphone User Manual

Model: X70
Brand: CUBOT

1. Introduction

Welcome to the CUBOT X70 user manual. This guide provides comprehensive instructions for setting up, operating, maintaining, and troubleshooting your new CUBOT X70 smartphone. The CUBOT X70 is designed to offer a powerful and versatile mobile experience with its advanced camera system, robust performance, and long-lasting battery.



Image: Front and back view of the CUBOT X70 smartphone, highlighting its sleek design and rear camera module.

2. What's in the Box

Upon opening your CUBOT X70 package, please verify that all the following items are included:

- 1x CUBOT X70 Smartphone
- 1x USB Cable

- 1x Charger (9V2A)
- 1x Cue card
- 1x User Manual
- 1x Protect Case
- 1x Pin (SIM ejector tool)



Image: All items included in the CUBOT X70 retail packaging, neatly laid out.

3. Setup

3.1. Inserting SIM Cards and SD Card

The CUBOT X70 supports dual SIM cards and external SD card expansion up to 1TB. Follow these steps to insert your cards:

1. Locate the SIM tray on the side of the phone.

2. Insert the provided SIM ejector tool into the small hole next to the tray and push gently until the tray pops out.
3. Place your Nano-SIM cards and/or microSD card into the designated slots on the tray, ensuring correct orientation.
4. Carefully push the tray back into the phone until it clicks into place.

3.2. Initial Power On and Setup

To power on your device for the first time:

1. Press and hold the Power button (located on the right side) until the CUBOT logo appears.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and sign in with your Google account.
3. Complete the setup wizard to personalize your device settings.



Image: Close-up of the CUBOT X70's side, illustrating the SIM card tray and the integrated fingerprint scanner.

4. Operating Instructions

4.1. Android 13 Operating System

The CUBOT X70 runs on Android 13, offering a smooth, secure, and intuitive user experience. Key features include enhanced privacy controls, improved notification management, and personalized interface options.



Image: Various screens of the CUBOT X70 displaying the Android 13 operating system interface.

4.2. Display and Navigation

The device features a 6.58-inch HD IPS capacitive touch screen with a resolution of 1080*2408 and a 120Hz refresh rate, providing vivid and fluid visuals for all your content.



Image: Visual representation of the CUBOT X70's 6.58-inch FHD display and its 120Hz refresh rate.

5. Camera Features

Capture stunning photos and videos with the CUBOT X70's versatile camera system:

- **100MP Rear Main Camera:** For high-resolution photos with exceptional detail.
- **32MP Front Camera:** Optimized for clear and vibrant selfies and video calls.
- **5MP Macro Lens:** For detailed close-up shots.

The camera application includes various modes such as portrait beauty, night shot anti-shake, panoramic photography, and time-lapse photography to enhance your creative possibilities.



Image: Detailed breakdown of the CUBOT X70's camera system, including the 100MP main camera, 32MP front camera, and 5MP macro lens, alongside sample images.

6. Storage and Performance

The CUBOT X70 is equipped for robust performance and ample storage:

- **RAM:** 24GB (12GB physical + 12GB virtual memory, configurable in settings).
- **ROM:** 256GB internal storage.
- **Expandable Storage:** Supports up to 1TB external SD card.
- **Processor:** Octa-core Helio G99 (6nm) with 2*A76 2.2GHz + 6*A55 2.0GHz configuration for lightning-fast processing speeds.




Image: Visual representation of the CUBOT X70's 24GB RAM, 256GB ROM, 1TB expansion capability, and Helio G99 Octa-core processor.

6.1. Performance Overview

The powerful processor and ample RAM ensure smooth multitasking, fast app loading, and an excellent gaming experience.

[redacted]

Video: An official product video showcasing the CUBOT X70's design, camera, battery, and performance capabilities.

7. Battery Life

The CUBOT X70 is equipped with a 5200mAh large-capacity battery, designed to provide extended usage throughout the day. It supports 18W fast charging to quickly replenish the battery.



Image: Graphic illustrating the 5200mAh battery capacity of the CUBOT X70 and its long-lasting performance.

8. Connectivity

The CUBOT X70 offers comprehensive connectivity options:

- **Dual SIM:** Supports two SIM cards for flexible network usage (2G, 3G, 4G frequency bands).
- **NFC:** Near Field Communication for contactless payments and data exchange.
- **GPS:** Global Positioning System for navigation and location services.
- **Bluetooth:** Bluetooth 5.2 for wireless accessory connection.
- **Wi-Fi:** For internet access.
- **Fingerprint Unlocking:** For secure and convenient access to your device.

9. Specifications

Key technical specifications for the CUBOT X70 smartphone:

Feature	Specification
Model Name	X70
Operating System	Android 13.0
RAM	24 GB (12GB physical + 12GB virtual)
Memory Storage Capacity	256 GB
Screen Size	6.58 Inches
Resolution	1080 x 2400
Refresh Rate	120 Hz
Rear Camera	100 MP
Front Camera	32 MP
Battery Capacity	5200 Milliamp Hours
Item Weight	1.06 pounds (480 Grams)
Product Dimensions	6.3 x 1.34 x 5.55 inches
Connectivity Technologies	Bluetooth, Wi-Fi, USB, NFC
Wireless Carrier	Unlocked

10. Troubleshooting

If you encounter issues with your CUBOT X70, consider the following general troubleshooting steps:

- **Device Not Responding:** Press and hold the Power button for about 10-15 seconds to force a restart.
- **Network Issues (No Signal/Wi-Fi):** Check if Airplane Mode is off. Ensure SIM cards are correctly inserted. Try restarting the phone. For Wi-Fi, forget the network and reconnect.
- **Battery Draining Quickly:** Reduce screen brightness, close unused apps, disable unnecessary background data, and check for app updates.
- **Apps Crashing/Freezing:** Clear the app's cache and data in Settings > Apps. If the issue persists, uninstall and reinstall the app.
- **Storage Full:** Delete unnecessary files, photos, and videos. Move media to an SD card if installed. Clear app caches.
- **Fingerprint Sensor Not Working:** Ensure your finger is clean and dry. Re-register your fingerprint in Settings > Security > Fingerprint.
- **Factory Reset (Last Resort):** If problems persist, you may need to perform a factory reset. Go to Settings > System > Reset options > Erase all data (factory reset). **Warning: This will erase all data on your phone. Back up important data before proceeding.**

For more specific issues or persistent problems, please refer to the official CUBOT support resources or contact customer service.

11. Warranty and Support

Your CUBOT X70 smartphone comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.

For technical support, service, or warranty claims, please contact CUBOT customer service through their official website or the contact information provided in your product documentation. When contacting support, please have your product model (X70) and purchase details ready.

For additional resources and frequently asked questions, visit the official CUBOT website:www.cubot.net

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLCQZX32

More documents and user manuals: **https://manuals.plus/**