Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ALLIMITY CT-8070

ALLIMITY CT-8070 Replacement Remote Control User Manual

Model: CT-8070

1. Introduction

This manual provides instructions for the ALLIMITY CT-8070 Replacement Remote Control. This remote is designed to function as a direct replacement for original Hitachi 4K OLED LCD HDTV remote models CT-8070 and CT-8066, as well as their variations CT8070 and CT8066.
No programming or setup is required for this remote control. Simply insert the batteries, and it is ready for use with compatible Hitachi televisions.

2. Setup and Battery Installation

The ALLIMITY CT-8070 remote control operates using two AAA batteries (not included). Follow these steps to install the batteries:

1. Locate the battery compartment on the back of the remote control.
2. Press down on the tab and slide the battery compartment cover downwards to open it.
3. Insert two new AAA alkaline batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.





Image: Back of the remote control with the battery compartment open, illustrating the correct orientation for AAA battery insertion.

Once batteries are installed, the remote is ready for immediate use with your compatible Hitachi TV.

3. Operating Instructions

The ALLIMITY CT-8070 remote control features standard buttons for navigating and controlling your Hitachi TV. Below is a general overview of common button functions:





Image: Front view of the ALLIMITY CT-8070 remote control, displaying the layout of all control buttons.

- **Power Button (●):** Turns the TV on or off.
- **Number Buttons (0-9):** Directly select channels.
- **Guide:** Accesses the electronic program guide (EPG).
- **Menu:** Opens the TV's main menu for settings and options.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and confirm selections.
- **Return/Back:** Returns to the previous screen or menu.
- **Exit:** Closes the current menu or application.
- **Volume Up/Down (+/-):** Adjusts the TV volume.
- **Channel Up/Down (P+/P-):** Changes TV channels.
- **Mute:** Silences the TV audio.
- **Source/Input:** Selects the input source (HDMI, AV, etc.).
- **Colored Buttons (Red, Green, Yellow, Blue):** Functionality varies depending on the TV model or specific application.
- **Subtitle:** Toggles subtitles on or off.

Point the remote control directly at the infrared receiver on your Hitachi TV for optimal performance.



Image: A user operating the remote control with a television, demonstrating typical usage.

4. Maintenance

To ensure the longevity and proper functioning of your ALLIMITY CT-8070 remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA alkaline batteries.
- **Storage:** If the remote control will not be used for an extended period, remove the batteries to prevent leakage, which can damage the remote. Store in a cool, dry place.
- **Avoid Damage:** Do not drop the remote control, expose it to extreme temperatures, or immerse it in water.

5. Troubleshooting

If you experience issues with your ALLIMITY CT-8070 remote control, refer to the following common troubleshooting steps:

- **Remote is not responding:**
  - Ensure the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA alkaline batteries.
  - Check for any obstructions between the remote control and the TV's infrared sensor.
  - Confirm that the remote is pointed directly at the TV's sensor.
- **Some buttons are not working:**
  - This may indicate low battery power. Try replacing the batteries.
  - Ensure there is no debris or liquid under the button preventing it from making contact.
- **Remote works intermittently:**
  - This often points to weak batteries. Replace them.
  - Ensure consistent line of sight to the TV's IR sensor.

If the issue persists after trying these steps, please refer to the support section for further assistance.

6. Specifications

Feature	Detail
Brand	ALLIMITY
Model	CT-8070 (Replacement)
Compatible Devices	Hitachi 4K OLED LCD HDTV models CT-8070, CT-8066, CT8070, CT8066
Connectivity Technology	Infrared (IR)
Power Source	2 x AAA Alkaline Batteries (not included)
Product Dimensions	6 x 2 x 0.6 inches (approximately)
Item Weight	2 ounces (approximately)
Color	Black

7. Support and Contact Information

For any questions, concerns, or assistance regarding your ALLIMITY CT-8070 Replacement Remote Control, please contact the seller or manufacturer directly.
Refer to your purchase documentation or the online product listing for specific contact details. The manufacturer, ALLIMITYBAIRUI, is committed to customer satisfaction.
Note: Warranty information is typically provided by the seller at the time of purchase. Please retain your proof of purchase for any warranty claims.

© 2023 ALLIMITY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLH22KG6

More documents and user manuals: **https://manuals.plus/**