JVC XS-N3133PB

JVC Portable Bluetooth Speaker User Manual

Model: XS-N3133PB

Introduction

Thank you for purchasing the JVC Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Please read it thoroughly before use to ensure optimal performance and safety.



Figure 1: JVC Portable Bluetooth Speaker (XS-N3133PB) with LED lights.

This image displays the front of the JVC Portable Bluetooth Speaker, highlighting its integrated rolling LED light feature. The speaker grille is black, and the LED lights form a vibrant, multi-colored ring around the central speaker unit, indicating its party-ready design. The top panel shows a digital display indicating "BLUE" for Bluetooth mode.

Safety Information

- Do not expose the speaker to water or excessive moisture.

- Avoid placing the speaker near heat sources or in direct sunlight.
- Do not attempt to disassemble or modify the speaker. This will void the warranty.
- Use only the specified charging cable and power adapter.
- Keep out of reach of children.
- Clean only with a dry cloth.

Package Contents

Ensure all items are present before proceeding with setup:

- JVC Portable Bluetooth Speaker (XS-N3133PB)
- Type C Charging Cable
- User Manual (this document)

Product Overview

Familiarize yourself with the speaker's components and controls.



Figure 2: Top Panel Controls.

This image shows the top control panel of the JVC Portable Bluetooth Speaker. Key buttons visible include volume controls (+ and -), mode selection (MODE/TWS/FM), play/pause, skip tracks, and a record button. There's also a display screen and an orange handle for portability. Icons for TWS, Record, Bass, and Treble functions are also displayed.

Control Panel Functions:

- **Power Button:** Press and hold to turn on/off.
- **Mode Button:** Short press to switch between Bluetooth, FM Radio, USB, AUX, and TF Card modes. Long press for TWS pairing.
- **Volume +/- Buttons:** Adjust the master volume level.
- **Play/Pause Button:** Play or pause audio playback.
- **Previous/Next Track Buttons:** Skip to the previous or next track.
- **Record Button:** Initiate or stop recording (requires USB or TF card).
- **LED Light Button:** Toggle LED light effects.

Input Ports:

- **USB Port:** For USB drive playback and recording.
- **TF Card Slot:** For TF (Micro SD) card playback and recording.
- **AUX Input:** 3.5mm jack for connecting external audio devices.
- **Microphone Input:** 1/4" jack for connecting a microphone (for karaoke).
- **Guitar Input:** 1/4" jack for connecting a guitar.
- **Type C Charging Port:** For charging the speaker's internal battery.

Setup

Charging the Speaker:

Before first use, fully charge the speaker. Connect the provided Type C charging cable to the speaker's charging port and the other end to a compatible USB power adapter (not included) or a computer USB port.

- The charging indicator light will illuminate during charging.
- The light will turn off or change color when fully charged.
- A full charge provides approximately 3600mAh of battery life.



Figure 3: Charging Indicator.

This icon represents the rechargeable battery feature of the speaker, indicating its portability and ability to be powered without a constant connection to an outlet.

Operating Instructions

Power On/Off:

Press and hold the Power button on the control panel for approximately 3 seconds to turn the speaker on or off.

Bluetooth Mode:

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing "BLUE" on the display.
2. Enable Bluetooth on your device (smartphone, tablet, laptop).
3. Search for "JVC XS-N3133PB" (or similar) in your device's Bluetooth list and select it to pair.
4. Once paired, the speaker will emit a confirmation sound, and "BLUE" will stop flashing.
5. You can now play audio from your device through the speaker.



Figure 4: Connectivity Options.

This image illustrates the multiple connectivity options available on the JVC Portable Bluetooth Speaker, including Bluetooth, USB, SD Card, FM Radio, and Aux In, demonstrating its versatility for playing audio from various sources.

True Wireless Stereo (TWS) Function:

The TWS function allows you to pair two JVC XS-N3133PB speakers for a stereo sound experience.

1. Ensure both speakers are turned on and not connected to any Bluetooth device.
2. On one speaker (this will be the master), long press the "MODE/TWS" button until you hear a pairing tone.
3. The two speakers will automatically connect to each other.
4. Once connected, the master speaker will be ready for Bluetooth pairing with your device. Follow the Bluetooth pairing steps above.



Figure 5: True Wireless Stereo Setup.

This image depicts two JVC Portable Bluetooth Speakers wirelessly connected to each other, demonstrating the True Wireless Stereo (TWS) feature for enhanced audio output and a more immersive sound experience.

FM Radio Mode:

1. Press the "MODE" button repeatedly until "FM" appears on the display.
2. Press the Play/Pause button to auto-scan and save available FM stations.
3. Use the Previous/Next Track buttons to navigate between saved stations.

USB/TF Card Mode:

1. Insert a USB drive or TF (Micro SD) card into the corresponding port.
2. The speaker will automatically switch to USB or TF Card mode and begin playing audio files. If not, press the "MODE" button to select the correct source.
3. Use the Play/Pause and Previous/Next Track buttons to control playback.

AUX Mode:

1. Connect an external audio device (e.g., MP3 player, PC) to the AUX input using a 3.5mm audio cable.
2. Press the "MODE" button repeatedly until "AUX" appears on the display.
3. Control playback from your connected device.

Karaoke and Recording Function:

1. Connect a microphone to the Microphone Input.
2. Ensure a USB drive or TF card is inserted for recording.
3. To record, press the "REC" button. Press again to stop recording. Recordings will be saved to the inserted storage device.



Figure 6: Karaoke and Recording Features.

This image shows individuals enjoying a karaoke session with the JVC Portable Bluetooth Speaker, emphasizing its microphone and guitar input capabilities, along with a record function and auto power saver mode, making it suitable for entertainment and performance.

LED Light Control:

Press the "LED" button on the control panel to cycle through different light modes or turn the LED lights off.



Figure 7: Rolling LED Light Feature.

This image showcases the JVC Portable Bluetooth Speaker's dynamic rolling LED lights, illuminating a party scene with a DJ, demonstrating how the speaker enhances the atmosphere with its visual effects.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the speaker's exterior. Do not use liquid cleaners or aerosols.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker regularly, even if not in use.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not turn on.	Battery is low or depleted.	Charge the speaker fully.
No sound.	Volume is too low; incorrect mode selected; device not connected properly.	Increase volume on speaker and connected device; ensure correct mode (Bluetooth, AUX, USB/TF) is selected; re-pair Bluetooth or re-connect cable.
Bluetooth pairing fails.	Speaker is not in pairing mode; device Bluetooth is off; too far from speaker; interference.	Ensure speaker is in Bluetooth pairing mode (flashing "BLUE"); turn on device Bluetooth; move device closer to speaker; clear previous pairings on device.
TWS pairing fails.	Speakers are too far apart; one speaker is already connected to a device.	Ensure both speakers are close to each other and not connected to any other Bluetooth device before initiating TWS pairing.
Recording not working.	No USB drive or TF card inserted; storage device is full or corrupted.	Insert a compatible USB drive or TF card; ensure sufficient free space; try a different storage device.

Specifications

Feature	Detail
Model Name	XS-N3133PB (AP-G281)
Speaker Unit Size	6.5 inches
Output Power	30W RMS
Connectivity	Bluetooth 5.0, FM Radio, USB, AUX (3.5mm), TF Card, U Disk, MMC Card
Audio Inputs	Microphone (1/4"), Guitar (1/4"), USB, TF Card, AUX
Battery	7.4V, 3600mAh Rechargeable Lithium-Ion
Charging Port	Type C
Dimensions (L x W x H)	24 x 25 x 30 cm
Weight	3.8 kg
Material	Plastic
Special Features	TWS Function, Karaoke Function, Record Function, Rolling LED Lights, Bass & Treble Adjustment, Bass Boost, Auto Power Saver



Figure 8: Product Dimensions.

This image provides a clear diagram of the JVC Portable Bluetooth Speaker's dimensions, indicating its height, width, and depth, along with icons for the 6.5-inch speaker size and 1-year warranty.

Warranty and Support

The JVC Portable Bluetooth Speaker (XS-N3133PB) comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship under normal use.

For warranty claims, technical support, or any inquiries, please contact JVC customer service. Refer to the official JVC website or your purchase documentation for contact details and further support information. JVC offers doorstep support for assured satisfaction and reliability.

© 2024 JVC. All rights reserved.
Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question