Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JVC RV-N120B

JVC RV-N120B Boombox Hiphop Bluetooth Speaker User Manual

Model: RV-N120B

Product Overview

The JVC RV-N120B Boombox Hiphop Bluetooth Speaker is a portable audio system designed for robust sound output and versatile connectivity. It features a powerful speaker system with a built-in woofer for enhanced bass, integrated lighting effects that synchronize with music, and multiple input options including Bluetooth and AUX. Its design incorporates an integrated handle and wheels, facilitating easy transport.



Figure 1: Front view of the JVC RV-N120B Boombox, showcasing its dual speakers with blue LED lighting, central control panel, and integrated carry handle.

Key Features:

- **Powerful Audio Output:** Delivers clear sound with a built-in woofer for deep bass.
- **Dynamic Light Show:** Features integrated lighting that syncs with the music for an immersive experience.
- **Multiple Connectivity Options:** Supports wireless audio streaming via Bluetooth and wired connections through an AUX input.
- **Enhanced Portability:** Equipped with an integrated handle and wheels for convenient transportation.
- **Durable Design:** Constructed from plastic, suitable for outdoor use.

Setup Guide

1. Unpacking and Initial Inspection

Carefully remove the speaker from its packaging. Verify that all included components are present: 1 x JVC RV-N120B Boombox Hiphop Bluetooth Speaker. Inspect the unit for any signs of damage incurred during shipping. If any damage is found, do not proceed with setup and contact customer support.

2. Powering the Device

The JVC RV-N120B is battery-powered. Before first use, it is recommended to fully charge the speaker. Connect the provided power cable to the speaker's charging port and plug it into a standard electrical outlet. The charging indicator light will illuminate. Once fully charged, the indicator light may change color or turn off, depending on the model.

3. Placement

Place the speaker on a stable, flat surface. For optimal sound dispersion, ensure there are no obstructions directly in front of the speaker grilles. While designed for outdoor use, avoid direct exposure to extreme weather conditions.

Operating Instructions

1. Power On/Off

To power on the speaker, press and hold the Power button (usually marked with a circle and a vertical line) located on the control panel until the display illuminates. To power off, press and hold the same button until the display turns off.

2. Bluetooth Connection

1. Ensure the speaker is powered on and in Bluetooth mode. The display should show "BLUE" or a similar indicator. If not, press the Mode button (often labeled 'M') to cycle through available modes until Bluetooth is selected.
2. On your mobile device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "JVC RV-N120B" or a similar name from the list of found devices.
4. Once connected, the speaker will typically emit an audible confirmation tone, and the Bluetooth indicator on the display will stabilize.

3. AUX Input Connection

To connect an external audio device via AUX, insert a 3.5mm audio cable (not included) into the AUX input port on the speaker. Connect the other end of the cable to the headphone jack or audio output of your device. The speaker should automatically switch to AUX mode, or you may need to select it using the Mode button.

4. Music Playback and Controls

- **Volume Control:** Use the dedicated volume knob or buttons on the speaker to adjust the playback volume.
- **Play/Pause:** Press the Play/Pause button to start or pause audio playback.
- **Track Navigation:** Use the Previous/Next track buttons to skip between songs.

5. Light Show Operation

The speaker features a built-in light show that syncs with the music. This feature is typically enabled by default. Refer to the speaker's control panel for a dedicated light mode button, if available, to cycle through different light patterns or to turn the lights off/on.

Maintenance

1. Cleaning

To clean the speaker, use a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the speaker grilles or ports. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

2. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker when the battery level is low. If storing the speaker for an extended period, charge it to approximately 50% and recharge every few months to prevent deep discharge.

3. Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. Protect it from dust and moisture when not in use.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Battery is depleted.	Connect the speaker to a power source and allow it to charge for at least 30 minutes before attempting to power on again.
Bluetooth connection issues (e.g., "can't be found when searching").	Speaker is not in pairing mode or out of range. Interference from other devices.	Ensure the speaker is in Bluetooth pairing mode (display shows "BLUE" and/or indicator is blinking). Move your device closer to the speaker. Turn off other Bluetooth devices nearby. Try restarting both the speaker and your Bluetooth device.
Battery not charging fully (always on a single bar).	Faulty charging cable/adapter. Battery degradation.	Try using a different compatible charging cable and power adapter. If the issue persists, the battery may require service or replacement. Contact customer support.
No sound or low volume.	Volume too low on speaker or connected device. Incorrect input mode selected.	Increase the volume on both the speaker and the connected audio source. Ensure the correct input mode (Bluetooth, AUX) is selected on the speaker.

Problem	Possible Cause	Solution
Light show not working.	Light feature is turned off.	Check if there is a dedicated button to activate or cycle through light modes. Ensure the speaker is playing audio.

Specifications

Feature	Detail
Model Number	RV-N120B
Colour	Black
Product Dimensions	28D x 8W x 13H centimetres
Power Source	Battery Powered
Connectivity Technology	Bluetooth
Audio Output Mode	Stereo
Input Voltage	5 Volts
Material	Plastic
Speaker Type	Outdoor
Included Components	1 x JVC RV-N120B Boombox Hiphop Bluetooth Speaker

Warranty and Support

Manufacturer's Warranty

The JVC RV-N120B Boombox Hiphop Bluetooth Speaker comes with a **1 Year Manufacturer's Warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support

For technical assistance, warranty claims, or further inquiries, please contact JVC customer support. Refer to the official JVC website or your purchase documentation for specific contact information.
When contacting support, please have your product model number (RV-N120B) and proof of purchase readily available.

© 2023 JVC. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLH2NJHY

More documents and user manuals: **https://manuals.plus/**