OVENTE RCS01W

OVENTE RCS01W Electric Rice Cooker and Food Steamer User Manual

Model: RCS01W

Introduction

This manual provides essential instructions for the safe and efficient operation of your OVENTE RCS01W Electric Rice Cooker and Food Steamer. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed, including:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Components

Your OVENTE RCS01W Electric Rice Cooker and Food Steamer includes the following parts:

- Main Unit (Housing with heating element)
- Removable Non-Stick Inner Pot
- Tempered Glass Lid
- Steamer Basket
- Measuring Cup
- Spatula



Image: The OVENTE RCS01W Electric Rice Cooker with its main components, including the base unit, inner pot, steamer basket, and glass lid.



Image: The essential accessories provided with the rice cooker: a spatula for serving, a measuring cup for precise ingredient ratios, and a steamer tray for simultaneous cooking.

Setup

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash the inner pot, steamer basket, measuring cup, spatula, and glass lid in warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
3. **Placement:** Place the rice cooker on a stable, level, heat-resistant surface, away from water and heat sources. Ensure adequate ventilation around the appliance.

Operating Instructions

Cooking Rice

1. **Measure Rice:** Use the provided measuring cup to measure the desired amount of rice. One cup of uncooked rice typically yields two cups of cooked rice. The cooker has a 5-cup uncooked (10-cup cooked) capacity.
2. **Rinse Rice:** Rinse the rice thoroughly under cold water until the water runs clear. This helps remove excess starch.
3. **Add Water:** Place the rinsed rice into the non-stick inner pot. Add the appropriate amount of water. A common ratio is 1:1 for white rice (e.g., 1 measuring cup of rice to 1 measuring cup of water). Adjust water levels based on rice type and desired consistency.
4. **Place Pot:** Insert the inner pot into the main unit, ensuring it sits correctly on the heating element.
5. **Cover:** Place the tempered glass lid securely on the inner pot.
6. **Connect Power:** Plug the power cord into a 120V AC electrical outlet.
7. **Start Cooking:** Press the 'COOK' switch down. The 'COOK' indicator light will illuminate.
8. **Automatic Keep Warm:** Once the rice is cooked, the appliance will automatically switch to 'WARM' mode, and the 'WARM' indicator light will illuminate. For best results, allow rice to rest in 'WARM' mode for 5-10 minutes before serving.
9. **Serve:** Use the provided spatula to fluff and serve the rice.



Image: Visual representation of the rice cooker's 10-cup cooked rice capacity, suitable for multiple servings.



Image: Close-up of the rice cooker's control panel with 'WARM' and 'COOK' indicators, highlighting the automatic function and the non-stick inner pot.

Steaming Food

The steamer basket allows for simultaneous cooking of rice and steaming of vegetables, fish, or other foods.

1. Prepare rice as described above.
2. Place desired food (e.g., chopped vegetables, fish fillets) into the steamer basket.
3. Once the inner pot with rice and water is in place, carefully set the steamer basket on top of the inner pot.
4. Cover with the tempered glass lid.
5. Proceed with cooking as usual. The steam generated from the cooking rice will cook the food in the steamer basket.



Image: The steamer basket in use, demonstrating its capability to prepare various steamed dishes like seafood, eggs, vegetables, and chicken alongside rice.

Keep Warm Function

The rice cooker automatically switches to 'WARM' mode after cooking is complete. This function maintains the temperature of the cooked food without further cooking. Do not leave food in 'WARM' mode for extended periods (more than a few hours) to maintain food quality and safety.



Image: Examples of diverse meals beyond rice, such as quinoa, oatmeal, and various soups, that can be prepared using the OVENTE RCS01W.

Cleaning and Maintenance

1. **Unplug:** Always unplug the rice cooker from the power outlet and allow it to cool completely before cleaning.
2. **Removable Parts:** The inner pot, steamer basket, measuring cup, spatula, and glass lid are dishwasher safe. For manual cleaning, wash with warm, soapy water using a non-abrasive sponge or cloth. Rinse thoroughly and dry completely.
3. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Storage:** Ensure all parts are clean and dry before storing. Store the rice cooker in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Rice is too hard/undercooked	Not enough water; cooking cycle interrupted; lid not sealed properly.	Add more water next time; ensure lid is secure; do not open lid during cooking.
Rice is too soft/mushy	Too much water.	Reduce water amount next time.
Rice sticks to the bottom	Not enough water; rice not rinsed; inner pot not clean.	Ensure proper water ratio; rinse rice thoroughly; ensure inner pot is clean and non-stick coating is intact.
Cooker does not turn on	Not plugged in; power outage; faulty outlet.	Check power cord connection; verify power to outlet; try a different outlet.
Steam escapes from lid	Lid not seated correctly; lid damaged.	Adjust lid to ensure a proper seal; inspect lid for damage.

Specifications

Feature	Detail
Brand	OVENTE
Model Name	RCS01W
Capacity	10 Cups (cooked), 5 Cups (uncooked)
Product Dimensions	9.2"D x 10.3"W x 8.5"H
Power Source	Corded Electric
Voltage	120 Volts
Wattage	400 watts
Material	Aluminum (inner pot), Stainless Steel, Tempered Glass (lid)
Special Features	Automatic Keep Warm, Non-Stick, One-Touch Operation, See-Through Lid
Item Weight	4.1 Pounds



Image: Diagram illustrating the physical dimensions of the OVENTE RCS01W Electric Rice Cooker.

Warranty and Support

Warranty Information

OVENTE warrants that this product shall be free from defects in material and workmanship under normal use and conditions for **1 year from the original purchase date**. This warranty applies only to the original retail purchaser and is not transferable.

Customer Support

For technical assistance, warranty claims, or general inquiries, please contact OVENTE customer service. Refer to the official OVENTE website or your purchase documentation for the most current contact information.

© 2025 OVENTE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

For the 5-cup Ovente rice cooker model RCS01W or RC501W, what are the steps to replace the inner nonstick pot, and do you have replacement pots available for purchase, including their cost?

The provided manual for the OVENTE RCS01W Electric Rice Cooker and Food Steamer lists the "Removable Non-Stick Inner Pot" as a component. However, it does not provide specific instructions on how to replace it,...

Read full answer