MObyat MOBYAT

MObyat 12V Two-Speed Charging Drill Planetary Gear Set Instruction Manual

1. Product Overview

This manual provides essential information for the MObyat 12V Two-Speed Charging Drill Planetary Gear Set. This component is designed for use in 12V charging drills to facilitate speed reduction and torque multiplication, enabling two distinct operating speeds. Understanding its components and proper handling is crucial for optimal performance and longevity.



Image 1.1: A general view of various components included in the MObyat 12V Two-Speed Charging Drill Planetary Gear Set, showcasing different gear types and sizes.

2. Package Contents

The MObyat 12V Two-Speed Charging Drill Planetary Gear Set (1Set) includes the following components:

- 1 x Largest Ring Gear
- 1 x Medium Ring Gear
- 1 x Smallest Ring Gear
- 1 x 12 Teeth Center Gear
- 1 x 15 Teeth Center Gear
- 1 x Without Teeth Center Gear
- 5 x 10 Teeth Planet Gears
- 5 x 11 Teeth Planet Gears
- 3 x 15 Teeth Planet Gears
- 1 x Bearing Sleeve

3. Component Identification and Specifications

Refer to the image below for visual identification and detailed dimensions of each gear component. Accurate identification is essential for correct assembly and replacement.




Image 3.1: A detailed diagram illustrating the various gears and components of the 12V two-speed lithium battery cobalt reduction gear set, complete with their respective dimensions and tooth counts.

Detailed Component Dimensions:

Largest Ring Gear: Outer diameter 34.3mm / Height 7mm / Pitch 5mm

Medium Ring Gear: Outer diameter 34mm / Height 6.8mm / Inner diameter 24.5mm

Smallest Ring Gear: Outer diameter 31.5mm / Height 6.5mm / Pitch 5mm

12 Teeth Center Gear: Teeth outer diameter 9.8mm / Diameter 22mm / Small circle diameter: 2mm

15 Teeth Center Gear: Teeth outer diameter 12mm / Max tooth outer diameter 25mm / Small circle diameter: 2.5mm

Without Teeth Center Gear: Max outer diameter 23.8mm / Inner hole 5*7mm / Small circle diameter: 3mm

10 Teeth Planet Gears (5 pcs): Outer diameter 8.7mm / Inner diameter 3mm / Height 4.5mm

11 Teeth Planet Gears (5 pcs): Outer diameter 9mm / Inner diameter 3mm / Height 6mm

15 Teeth Planet Gears (3 pcs): Outer diameter 10mm / Inner diameter 2mm / Height 4mm

Bearing Sleeve: Outer diameter 17.9mm / Inner diameter 9.9mm / Height 9.9mm

4. Setup and Installation

This gear set is a replacement component for 12V charging drills. Installation typically involves disassembling the drill's gearbox, carefully removing the old gear components, and installing the new set. Due to the precision required and the complexity of drill mechanisms, professional installation or consultation with a qualified technician is highly recommended. Incorrect installation can lead to damage to the drill or the gear set, and may compromise safety.

1. **Preparation:** Ensure the drill's power source is disconnected. Gather necessary tools, such as screwdrivers, pliers, and appropriate lubricants.
2. **Disassembly:** Carefully open the drill casing and gearbox housing. Note the arrangement of existing gears and components. Taking photos during disassembly can be helpful for reassembly.
3. **Component Replacement:** Remove the worn or damaged gears. Install the new MObyat gear components according to the original configuration, ensuring all parts fit securely and move freely. Pay close attention to the orientation of each gear and ring.
4. **Lubrication:** Apply a suitable high-performance grease specifically designed for gears to all moving parts to reduce friction and wear.
5. **Reassembly:** Carefully reassemble the gearbox and drill casing, ensuring all screws are tightened appropriately. Test the drill's functionality at both speeds before full operation.

5. Operating Principles

A planetary gear set, also known as an epicyclic gear train, is a gear system consisting of one or more outer gears, or 'planet' gears, revolving around a central 'sun' gear. The MObyat 12V Two-Speed Charging Drill Planetary Gear Set utilizes this principle to provide two distinct speed and torque outputs from a single input. This allows the drill to operate at a lower speed with higher torque for demanding tasks like driving screws, and a higher speed with lower torque for drilling applications.

- **Speed 1 (High Torque, Low Speed):** Engages a specific gear configuration that maximizes torque output, ideal for heavy-duty drilling or driving large fasteners.
- **Speed 2 (Low Torque, High Speed):** Engages an alternative gear configuration that prioritizes rotational speed, suitable for lighter drilling tasks where speed is more critical than torque.

The selection between these two speeds is typically controlled by a switch on the drill, which mechanically shifts the gear engagement within the planetary system.

6. Maintenance

Regular maintenance of the gear set ensures its longevity and optimal performance. While the gear set is designed for durability, periodic inspection and lubrication are recommended.

- **Lubrication:** Periodically (e.g., annually or based on usage intensity) inspect the gear set for adequate lubrication. Reapply high-quality gear grease as needed. Avoid over-lubrication, which can attract dust and debris.

- **Inspection:** During lubrication, visually inspect all gears for signs of wear, chipping, or damage. Check for any foreign objects or debris within the gearbox.
- **Cleaning:** If the gearbox is opened for maintenance, gently clean any accumulated dust or old, hardened grease using a suitable solvent and a soft brush. Ensure all components are dry before re-lubricating and reassembling.
- **Storage:** Store the drill in a clean, dry environment to prevent corrosion and contamination of internal components.

7. Troubleshooting

If you experience issues after installing the gear set, consider the following common troubleshooting steps:

- **Grinding Noise or Poor Engagement:** This often indicates incorrect assembly or insufficient lubrication. Disassemble the gearbox, re-check all gear placements and orientations against the original configuration or diagrams, and ensure proper lubrication.
- **Drill Not Changing Speeds:** Verify that the speed selector mechanism on the drill is correctly engaging the gear set. This could be a mechanical issue with the selector itself or improper alignment of the gear set components.
- **Excessive Heat:** Overheating can be a sign of excessive friction due to lack of lubrication, incorrect gear mesh, or overloading the drill. Ensure proper lubrication and avoid operating the drill beyond its rated capacity.
- **Reduced Power/Torque:** Check for any binding in the gear train or damage to individual gear teeth. Ensure the motor is functioning correctly and the battery is fully charged.

If problems persist, it is advisable to consult a professional or contact the seller for further assistance.

8. Specifications

Attribute	Value
Product Type	Two-Speed Planetary Gear Set
Application	12V Charging Drills
Material	Metal (as implied by product images)
Product Weight	120 G / 4.23 Ounces
Package Dimensions (L*W*H)	100*80*20 MM / 3.94*3.15*0.79 Inches
Model Number	MOBYAT
ASIN	B0CLJ5MHZJ

9. Warranty and Support

Specific warranty information for the MObyat 12V Two-Speed Charging Drill Planetary Gear Set is not provided in the product details. For any warranty claims, technical support, or inquiries regarding this product, please contact the seller directly through your purchase platform. Retain your proof of purchase for any support requests.

MObyat 12V Two-Speed Charging Drill Planetary Gear Set Instruction Manual

© 2023 MObyat. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question