Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cecotec 08276

Cecotec Readywarm 2000 Max Ceramic Rotate Smart Heater

User Instruction Manual - Model 08276

Brand: Cecotec

Introduction

This manual provides essential information for the safe and efficient operation of your Cecotec Readywarm 2000 Max Ceramic Rotate Smart Heater. Please read these instructions carefully before use and retain them for future reference.

The Cecotec Readywarm 2000 Max is a freestanding ceramic heater designed to provide warmth in rooms up to approximately 20m². It features 2000W power, a digital display, touch control, remote control, oscillation, 3 operating modes, and an adjustable thermostat.

Safety Instructions

- Always place the heater on a firm, level surface.
- Do not cover the heater or block air inlets/outlets.
- Keep flammable materials (curtains, furniture, etc.) at least 1 meter away from the heater.
- Do not use the heater in bathrooms, laundry areas, or similar damp indoor locations.
- Unplug the heater when not in use or before cleaning.
- Do not operate the heater with a damaged cord or plug.
- Keep out of reach of children and pets.
- Do not insert any objects into the ventilation or exhaust openings.

Product Overview

Familiarize yourself with the main components of your heater.

Figure 1: Front view of the Cecotec Readywarm 2000 Max heater, showing its sleek design, digital display, and the remote control. The

image also illustrates the 42-degree oscillation feature.

Figure 2: Detailed view of the heater's touch control panel, featuring power, temperature, mode, and timer icons. The Cecotec logo is visible at the top.

Components:

- **Digital Display:** Shows current settings and temperature.
- **Touch Control Panel:** For manual operation of functions.
- **Air Outlet Grille:** Where warm air is emitted.
- **Air Inlet Grille:** Located at the rear/sides.
- **Base:** Provides stability and houses the oscillation mechanism.
- **Remote Control:** For convenient operation from a distance.
- **Power Cord:** For electrical connection.

Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain the packaging for storage or in case of return.
2. **Placement:** Place the heater on a stable, flat, and heat-resistant surface. Ensure there is at least 1 meter of clear space around the heater from walls, furniture, and other objects to allow for proper air circulation and prevent overheating.
3. **Power Connection:** Ensure the heater is switched off before plugging it into a suitable electrical outlet. The power supply must match the voltage specified on the heater's rating label.
4. **Base Assembly (if required):** The base may require minor assembly. Refer to the diagram on the underside of the heater for proper attachment, typically involving screws.

Figure 3: Image showing the underside of the heater's base, indicating how it might be secured or inspected during setup.

Operating Instructions

Control Panel and Digital Display:

The heater can be operated using the touch control panel on the unit or the provided remote control. The digital display shows the current temperature and selected settings.

Figure 4: A hand operating the remote control, which features buttons for power, mode, oscillation, and timer functions.

- **Power Button ( ):** Press to turn the heater ON or OFF.
- **Mode Button (☀):** Cycle through the 3 operating modes:
  - **Fan Mode:** Circulates air without heating.
  - **Low Heat Mode:** Provides gentle warmth.
  - **High Heat Mode:** Provides maximum warmth (2000W).
- **Temperature Adjustment (°F):** Use the temperature buttons (often +/- or up/down arrows on the remote) to set the desired thermostat temperature. The heater will maintain this temperature.
- **Oscillation Button (↻):** Activates or deactivates the 42° oscillation function, allowing heat to be distributed more widely across the room.
- **Timer Button ( ):** Set a timer for automatic shut-off. Refer to the display for timer duration settings.

When the heater is operating, the digital display will show the current room temperature or the set temperature, depending on the mode and settings.

Maintenance

Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to gently remove dust from the air inlet and outlet grilles.
- Never immerse the heater in water or any other liquid.

Storage:

- If storing the heater for an extended period, clean it thoroughly.
- Store the heater in its original packaging in a cool, dry place, away from direct sunlight and extreme temperatures.
- Ensure the power cord is neatly wrapped and not kinked.

Troubleshooting

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; power switch off; no power at outlet; safety tip-over switch activated.	Ensure plug is fully inserted; check power switch; test outlet with another device; place heater on a flat, stable surface.
No heat output.	Fan mode selected; thermostat set too low.	Select a heat mode (Low or High); increase the thermostat setting.
Heater stops unexpectedly.	Overheat protection activated; tip-over switch activated; timer expired.	Unplug, allow to cool for 30 minutes, then restart; ensure heater is upright; check timer settings.
Oscillation not working.	Oscillation function not activated.	Press the oscillation button on the control panel or remote.

If the problem persists after attempting these solutions, please contact Cecotec customer support.

Specifications

Brand: Cecotec

Model Number: 08276

Type: Ceramic Heater

Power / Wattage: 2000 W

Voltage: 220-240 V (AC)

Product Dimensions: 23 x 22.5 x 50.5 cm (approx.)

Weight: 2.5 kg (approx.)

Special Features: Digital Display, Remote Control, Oscillation (42°), Adjustable Thermostat, 3 Operating Modes

Heating Method: Convection

Form Factor: Tower

Indoor/Outdoor Usage: Indoor

Warranty and Support

Cecotec products are manufactured to high-quality standards. For information regarding warranty terms and conditions, please refer to the warranty card included with your product or visit the official Cecotec website.

For technical support, troubleshooting assistance, or spare parts, please contact Cecotec customer service. Contact details can typically be found on the official website or in the product packaging.

Please note: Unauthorized repairs or modifications will void the product warranty.

© 2025 Cecotec. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLNY1XKY

More documents and user manuals: **https://manuals.plus/**