RUSTOWN CA-PDXD

RUSTOWN Farmhouse Console Table (Model CA-PDXD) - User Manual

Brand: RUSTOWN | Model: CA-PDXD

1. Introduction

Thank you for choosing the RUSTOWN Farmhouse Console Table. This manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Please read these instructions thoroughly before beginning assembly and retain them for future reference.

Important Safety Information

- Always follow the assembly instructions carefully to prevent injury.
- This table has a weight limit. Do not overload it to avoid tipping or damage.
- Ensure the table is stable and properly assembled before placing any items on it or using it.
- Keep small parts and packaging materials away from children.



Image 1.1: RUSTOWN Farmhouse Console Table (Model CA-PDXD)

2. Parts List

Before assembly, verify that all components listed below are present. If any parts are missing or damaged, please contact customer support.

- Tabletop (1)
- Side Frames/Legs (2)
- Bottom Shelf (1)
- Drawers (4)
- Drawer Handles (4)
- Assembly Hardware (screws, bolts, washers, etc.)
- Installation Tool (basic wrench/hex key)



Image 2.1: Detailed view of table components and materials.

3. Assembly Instructions

Assembly is designed to be straightforward. It is recommended to have a hammer and screwdriver in addition to the included installation tool. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches.
2. **Attach Side Frames:** Connect the side frames/legs to the tabletop using the provided hardware. Ensure all connections are secure but do not overtighten initially.
3. **Install Bottom Shelf:** Secure the bottom shelf to the lower section of the side frames/legs. Verify that it is level and stable.
4. **Assemble Drawers:** Construct the four drawers according to the specific instructions provided in the separate hardware packet. Attach the metal handles to the front of each drawer.
5. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots in the tabletop frame.
6. **Final Tightening:** Once all components are in place, gently tighten all screws and bolts. Do not overtighten to avoid

damaging the wood.

7. **Stability Check:** Gently shake the assembled table to ensure it is stable and does not wobble. Adjust connections if necessary.



Image 3.1: Product dimensions for assembly reference.

4. Operating Instructions

The RUSTOWN Farmhouse Console Table is designed for versatile use in various indoor settings.

Usage Guidelines

- **Placement:** Suitable for living rooms, entryways, hallways, bedrooms, or dining rooms as a console table, sofa table, or display unit.
- **Drawers:** The four drawers provide enclosed storage for small items such as keys, remote controls, pens, or receipts.
- **Open Shelf:** The bottom open shelf offers additional storage or display space for larger items like baskets, vases, or books.

- **Weight Distribution:** Distribute weight evenly across the tabletop and shelves. Avoid placing excessively heavy items on one side.



Image 4.1: Drawers providing storage for small objects.



Image 4.2: Drawer storage capacity.

5. Maintenance

Proper care will help maintain the appearance and longevity of your console table.

- **Cleaning:** Wipe surfaces with a soft, dry, or slightly damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean spills immediately to prevent staining. Note that the table is **not stain resistant**.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Humidity:** Maintain a stable humidity level in the room to prevent wood from warping or cracking.
- **Hardware:** Periodically check and tighten all hardware connections to ensure the table remains stable.

6. Troubleshooting

If you encounter any issues with your console table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table wobbles	Loose hardware; uneven floor	Tighten all screws and bolts. Place felt pads under legs to level on uneven surfaces.
Drawers are difficult to open/close	Misalignment; friction	Ensure drawers are inserted correctly. Check for obstructions. Apply a small amount of furniture wax or silicone spray to drawer glides if applicable (check manufacturer guidelines).
Surface scratches	Sharp objects; abrasive cleaning	Use coasters or protective mats under decorative items. Avoid dragging objects across the surface.

7. Specifications

Detailed product specifications for the RUSTOWN Farmhouse Console Table, Model CA-PDXD.

- **Brand:** RUSTOWN
- **Model Number:** CA-PDXD
- **Product Dimensions (D x W x H):** 11" x 60" x 32" (27.94 cm x 152.4 cm x 81.28 cm)
- **Color:** Washed White
- **Style:** Farmhouse
- **Frame Material:** Wood
- **Top Material:** Engineered Wood
- **Base Material:** Engineered Wood
- **Handle Material:** Metal (Black finish)
- **Number of Drawers:** 4
- **Number of Shelves:** 1 (bottom open shelf)
- **Item Weight:** Approximately 11 Kilograms (24.25 lbs)
- **Indoor/Outdoor Usage:** Indoor only
- **Assembly Required:** Yes
- **Tools Recommended for Assembly:** Hammer, Screwdriver (in addition to included tool)

8. Warranty and Support

For any questions, concerns, or assistance with your RUSTOWN Farmhouse Console Table, please contact our customer support team. Refer to your purchase documentation for specific warranty details and contact information.
We are committed to providing quality products and support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question