Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T4TREAM VSC5DRSC-LRO

T4TREAM Farmhouse 5-Drawer Dresser User Manual

Model: VSC5DRSC-LRO

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your T4TREAM Farmhouse 5-Drawer Dresser. Please read all instructions carefully before beginning assembly and retain this manual for future reference.



Image 1.1: The T4TREAM Farmhouse 5-Drawer Dresser in a bedroom setting.

2. Safety Information

- Always assemble the dresser on a soft, clean surface to prevent scratches.
- Ensure all hardware is securely tightened before use. Periodically check and re-tighten as necessary.
- This dresser is designed with an anti-tipping device. It is crucial to install this device to prevent accidental tipping, especially in households with children or pets.
- Do not allow children to climb on or play with the dresser.
- Distribute weight evenly in drawers to maintain stability.



Image 2.1: Dresser dimensions and important safety notice regarding the anti-tipping device.

3. Package Contents

Before beginning assembly, verify that all parts and hardware are present. Refer to the included assembly instructions for a complete list of components. If any parts are missing or damaged, contact customer support immediately.

- Dresser panels (top, bottom, sides, back)
- Drawer components (fronts, sides, backs, bottoms)
- Hardware pack (screws, dowels, cam locks, drawer slides, handles, anti-tipping kit)
- Assembly instructions

4. Setup and Assembly

Assembly of the T4TREAM Farmhouse 5-Drawer Dresser requires careful attention to detail. While one person can assemble it, having a second person is recommended for a smoother and safer process due to the weight and size of components.

1. **Preparation:** Clear a spacious area and lay out all parts on a soft, protective surface to prevent damage. Verify all parts against the included list.
2. **Follow Instructions:** Adhere strictly to the step-by-step assembly instructions provided in the package. All parts are clearly labeled, and diagrams are designed for easy understanding.
3. **Hardware:** Use the provided hardware. Be cautious when tightening cam locks to avoid breakage. If additional wood glue is desired for dowels, ensure it is compatible with the material.
4. **Drawer Assembly:** Assemble each drawer carefully, ensuring all slides are correctly aligned.
5. **Anti-Tipping Device:** Once the dresser is fully assembled and in its final position, securely install the anti-tipping device to a wall stud. This is a critical safety step.



Image 4.1: The assembled dresser, ready for use.

5. Operating Instructions

5.1 Storage Capacity

The T4TREAM Farmhouse 5-Drawer Dresser provides ample storage with five spacious drawers. Each drawer measures approximately 6.3 inches in depth, suitable for organizing clothing, linens, and other personal items. The top surface can be utilized for decorative items, framed photos, or small accessories.



Image 5.1: An open drawer demonstrating storage space and the natural wood texture.

5.2 Drawer Functionality

Drawers are equipped with slides for smooth operation. To ensure longevity and proper function, avoid forcing drawers open or closed. Always use the handles provided. Distribute contents evenly to prevent strain on the drawer slides.



Image 5.2: Details of the dresser's design elements, including drawer handles.

6. Maintenance

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid using abrasive cleaners, harsh chemicals, or excessive moisture, which can damage the finish.
- **Hardware Check:** Periodically inspect all screws and fasteners to ensure they remain tight. Re-tighten as needed to maintain structural integrity.
- **Environmental Conditions:** Avoid placing the dresser in direct sunlight or near heat sources, as this can cause wood to warp or fade. Maintain a stable room temperature and humidity.

7. Troubleshooting

7.1 Common Issues and Solutions

- **Drawers not closing/opening smoothly or fully:**

- Ensure drawer slides are correctly installed and aligned on both the drawer and the dresser frame. Misalignment can cause drawers to stick or not extend/retract properly.
- Verify that no objects are obstructing the drawer's path or interfering with the slides.
- Check that the drawer bottom is securely seated and not bulging, which could cause friction.

- **Drawers wiggling or falling off tracks:**
  - This can occur if the pre-marked pilot holes for the drawer slides are not perfectly aligned or if the slides are not securely fastened. Double-check all screw connections for tightness.
  - Ensure the weight in the drawer is evenly distributed and not excessive.
- **Dresser leaning slightly backward:**
  - The design incorporates plastic feet on the front and sides, but not the back, which may result in a slight backward tilt when placed against a wall. This is part of the design and can enhance stability against a wall.
- **Damaged hardware during assembly (e.g., cam locks):**
  - Exercise caution when tightening hardware. Avoid over-tightening, especially with cam locks, as they can break. Extra hardware pieces are typically included; use these if needed.

8. Specifications

Feature	Detail
Brand	T4TREAM
Model Name	VSC5DRSC-LRO
Product Dimensions	15.5"D x 31.2"W x 48"H
Color	Light Rustic Oak
Furniture Finish	Oak
Item Weight	126 Pounds
Number of Drawers	5
Assembly Required	Yes
Product Care Instructions	Wipe with Dry Cloth
Global Trade Identification Number (GTIN)	00850072934051

9. Customer Support

For any questions, missing parts, or assistance with assembly or product issues, please contact T4TREAM customer support. Refer to your purchase documentation or the T4TREAM website for contact information.

© 2025 T4TREAM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLS2CXZR

More documents and user manuals: **https://manuals.plus/**