Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

WINGBO SYCF7202

WINGBO 72 Inch DC Ceiling Fan User Manual

Model: SYCF7202

1. Safety Information

Please read and understand this entire manual before attempting to assemble, operate, or install the product. Failure to follow the instructions could result in electric shock, fire, or serious personal injury.

- Always turn off the power at the main circuit breaker before beginning any installation or maintenance.
- Ensure all electrical connections comply with local codes and ordinances, as well as the National Electrical Code (NEC).
- This ceiling fan is ETL Listed, ensuring it meets safety standards.
- The fan is suitable for damp locations, including outdoor patios, workshops, breezeways, gazebos, and pergolas.
- Do not operate the fan with damaged wiring or if the motor is making unusual noises.

2. Package Contents

Verify that all components listed below are included in your package:

- Fan Motor Assembly (Brass Finish)
- 5 Reversible Carved Wood Blades (White)
- 3 Downrods (4.5”, 12", and 24" long)
- LED Light Kit (24W, 3000K/4500K/6000K)
- Remote Control with Wall Holder
- Mounting Bracket
- Hardware Pack (screws, wire nuts, safety pin)



Image: The WINGBO 72 Inch DC Ceiling Fan in Brass and White, shown with its remote control.

3. Setup (Installation)

This section provides step-by-step instructions for installing your new ceiling fan. For a visual guide, please refer to the official installation video provided by WINGBO.

Video: Official WINGBO guide on how to replace a ceiling fan, demonstrating the installation process.

3.1 Pre-installation

1. **Turn Off Power:** Before starting, ensure the power supply to the fan location is turned off at the circuit breaker.
2. **Clear Area:** Clear the area around the installation site to prevent accidents.

3.2 Remove Old Fan (if applicable)

1. Unscrew and remove the old fan's canopy.
2. Carefully disconnect all wiring (live, neutral, ground) using wire nuts.
3. Remove the old mounting bracket from the ceiling junction box.

3.3 Install New Mounting Bracket

1. Secure the new mounting bracket to the ceiling junction box using the provided screws. Ensure it is firmly attached and can support the fan's weight.
2. Connect the ground wire from the ceiling to the ground screw on the mounting bracket.

3.4 Assemble Downrod and Fan Motor

1. Select the appropriate downrod length (4.5”, 12", or 24") for your ceiling height.
2. Feed the fan motor wires through the chosen downrod.
3. Insert the downrod into the fan motor housing, aligning the holes. Secure it with the safety pin and tighten the set screws.

3.5 Hang Fan Assembly and Wiring

1. Carefully lift the fan assembly and hang it on the mounting bracket. Ensure the notch on the downrod aligns with the tooth on the bracket for secure hanging.
2. Connect the receiver wires to the household wiring: match neutral (white), live (black/red), and ground (green/yellow) wires using wire nuts.
3. Connect the fan control wires from the receiver to the fan motor.
4. Carefully tuck all wires into the junction box and slide the canopy up to cover the connections. Secure the canopy with screws.

3.6 Attach Blades

1. Attach each of the 5 carved wood blades to the fan motor hub using the provided screws. Ensure they are securely fastened.

3.7 Install LED Light Kit

1. Connect the LED light kit wires to the corresponding wires from the fan motor.
2. Secure the LED light kit to the bottom of the fan motor housing with the provided screws.
3. Attach the light cover by twisting it into place or securing it with screws, depending on the design.

3.8 Power On

1. Restore power at the main circuit breaker.
2. Test the fan and light functions using the remote control.

4. Operating Instructions

Your WINGBO ceiling fan is controlled by a convenient handheld remote. Familiarize yourself with its functions for optimal comfort.



Image: The remote control for the WINGBO ceiling fan, showing buttons for fan speed, light control, and direction.

4.1 Fan Control

- **Power On/Off:** Press the fan power button to turn the fan on or off.
- **Speed Adjustment:** Use the speed buttons (1-6) to select your desired fan speed. The fan features a 6-speed noiseless DC motor.
- **Dual-Direction (Reversible Motor):** The fan has a reversible motor for year-round comfort. Press the 'Follow/Reverse' button to switch between modes.



Image: Diagram illustrating the airflow for Summer Mode (forward direction, air forced down) and Winter Mode (reverse direction, air drawn up).

- *Summer Mode (Forward):* Blades rotate counter-clockwise, forcing air downwards to create a cooling breeze.
- *Winter Mode (Reverse):* Blades rotate clockwise, drawing air upwards to circulate warm air trapped near the ceiling.

4.2 Light Control

- **Light On/Off:** Press the light button to turn the integrated LED light on or off.
- **Color Temperature Adjustment:** The LED light offers three color temperatures: 3000K (Warm Light), 4500K (Natural Light), and 6000K (Day Light). Use the dedicated buttons on the remote to cycle through these options.



Image: Examples of the three available LED light color temperatures: Warm Light (3000K), Natural Light (4500K), and Day Light (6000K).

4.3 Timer Function

- Set a timer (1H, 2H, 4H, 8H) to automatically turn off the fan after a set period. This is useful for energy saving or for use during sleep.



Image: Illustration of the timer function, showing options for 1, 2, 4, or 8 hours before automatic shutdown.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your WINGBO ceiling fan.

- **Cleaning:** Periodically wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Tighten Screws:** Check all screws and connections on the fan and mounting bracket periodically to ensure they are secure. Loose connections can cause noise or wobbling.
- **Blade Balancing:** If the fan wobbles, ensure all blades are securely attached and consider using a blade balancing kit (not included) if necessary.

6. Troubleshooting

If you encounter issues with your WINGBO ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low/dead.	Check circuit breaker; Verify all wire connections are secure; Replace remote control battery.
Light does not work	Loose wire connection to light kit; Faulty LED module.	Check light kit wiring; Contact customer support if LED module is faulty.
Fan wobbles	Loose blade screws; Unbalanced blades; Loose mounting bracket.	Tighten all blade screws; Use a blade balancing kit; Ensure mounting bracket is securely fastened.
Noisy operation	Loose screws; Motor issue.	Check and tighten all screws; If noise persists, contact customer support.
Remote control not responding	Battery low/dead; Receiver not paired; Obstruction.	Replace battery; Refer to remote pairing instructions (if applicable); Ensure no obstructions between remote and fan.

7. Specifications

Feature	Detail
Brand	WINGBO
Model Name	WINGBO 72 Inch DC Ceiling Fan with Lights (SYCF7202)
Color	Brass and White
Design	Ceiling Fan
Power Source	DC
Style	Modern
Product Dimensions	72"D x 72"W x 31"H
Room Type	Bedroom, Living Room, Covered Outdoor (Damp Rated)
Special Feature	Integrated LED Light
LED Wattage	24 watts
LED Color Temperatures	3000K (Warm), 4500K (Natural), 6000K (Daylight)
Finish Type	Painted
Number of Blades	5
Blade Length	72 Inches
Blade Material	Wood (FSC-Certified)
Switch Type	Remote
Included Components	Downrods (4.5”, 12", 24”), LED Light Kit

Feature	Detail
Certification	ETL Listed
Control Method	Remote
Efficiency	High Efficiency DC Motor
Number of Power Levels	6
Item Weight	23.8 pounds

8. Warranty & Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official WINGBO website. You can also visit the WINGBO Store on Amazon for additional product details and contact options.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLS2YP99

More documents and user manuals: **https://manuals.plus/**