Our Place Our Place

Our Place Dream Cooker Instruction Manual

Brand: Our Place | Model: Dream Cooker (6-Quart Multicooker)

1. Introduction and Overview

The Our Place Dream Cooker is a versatile 6-quart multicooker designed to simplify your cooking experience. It combines four essential cooking modes: Pressure Cook, Slow Cook, Sear & Saute, and Keep Warm, allowing for a wide range of culinary preparations. Its intuitive control panel and hands-free steam release feature ensure ease of use, while its toxin-free nonstick ceramic coating makes cleaning effortless. The Dream Cooker is crafted not only for functionality but also to complement your kitchen aesthetic.



Figure 1.1: The Our Place Dream Cooker, showcasing its sleek design.

2. Key Features

- **Fast & Versatile Cooking:** Offers Pressure Cook, Slow Cook, Sear & Saute, and Keep Warm modes. Pressure cooking allows for up to 80% faster cooking times compared to traditional methods.
- **Toxin-Free, Easy to Clean:** The 6-quart inner pot features a non-toxic nonstick ceramic coating, ensuring simpler cooking and effortless cleanup without soaking or scrubbing.
- **Hands-Free Convenience:** Equipped with hands-free steam release and an automatic keep warm mode, along with 9 advanced safety features for worry-free operation.
- **Tailored Control Panel:** A user-friendly control panel allows for easy setting of time, temperature, and mode, eliminating confusing presets.
- **Stylish Countertop Aesthetic:** Designed to be displayed, the Dream Cooker adds both functionality and style to your kitchen decor.



Figure 2.1: Overview of the Dream Cooker's advanced features.



Figure 2.2: The four versatile cooking modes of the Dream Cooker.

3. What's Included

Your Our Place Dream Cooker package includes the following components:

- Dream Cooker™ Base Unit
- 6-Quart Inner Cooking Pot (Toxin-Free Nonstick Ceramic Coated)
- Locking Lid with Hands-Free Steam Release
- Detachable Power Cord
- Condensation Collector



Figure 3.1: All components included with your Dream Cooker.

4. Setup

4.1 Unboxing and Initial Placement

1. Carefully remove all components from the packaging.
2. Place the Dream Cooker base unit on a stable, flat, and heat-resistant surface, such as a kitchen countertop. Ensure adequate clearance around the unit for ventilation.
3. Insert the inner cooking pot into the base unit.
4. Attach the condensation collector to the designated slot at the back of the unit.
5. Connect the detachable power cord to the port at the back of the Dream Cooker base unit and then plug it into a 120V electrical outlet.

5. Operating Instructions

5.1 Control Panel Overview

The Dream Cooker features a streamlined touch control panel for easy operation. The central display shows cooking time and settings. The main functions are clearly labeled:

- **Power Button:** Located at the bottom center, press to turn the unit on/off.
- **Mode Selection:** Touch icons for Slow Cook, Saute/Sear, Pressure Cook, and Keep Warm.
- **Time/Level Adjustment:** Use the '+' and '-' buttons to adjust cooking time or pressure levels (Low, Medium, High) once a mode is selected.
- **Start/Pause Button:** Initiates or pauses the selected cooking program.

5.2 Mode Selection and Operation

1. **Turn On:** Press the power button to activate the control panel.
2. **Select Mode:** Touch the desired cooking mode icon (e.g., "Pressure Cook").
3. **Adjust Settings:**
    - For Pressure Cook, select Low, Medium, or High pressure using the corresponding icons.
    - For Slow Cook, select Low, Medium, or High temperature.
    - For Saute/Sear, select Low, Medium, or High heat.
    - For all modes, use the '+' and '-' buttons to set the desired cooking time.
4. **Start Cooking:** Press the Start/Pause button to begin the cooking cycle. The display will show the remaining time.
5. **Keep Warm:** After most cooking cycles, the Dream Cooker will automatically switch to Keep Warm mode. You can also select Keep Warm directly.

5.3 Hands-Free Steam Release (Pressure Cook Mode)

The Dream Cooker features an automated steam release system for safety and convenience. Once the pressure cooking cycle is complete, the unit will automatically release steam. There is also a manual release button on the lid for controlled steam release when needed. Always ensure the steam release valve is clear before and after use.

6. Cleaning and Maintenance

6.1 Inner Cooking Pot

The 6-quart inner cooking pot has a toxin-free nonstick ceramic coating, making it exceptionally easy to clean. It is dishwasher safe for added convenience. For best results and to prolong the life of the nonstick coating, hand washing with warm, soapy water and a soft sponge is recommended.

6.2 Lid and Gasket

The lid and its silicone gasket should be cleaned after each use. The gasket is simple to remove for thorough cleaning and can be reinstalled easily. Wash with warm, soapy water. Ensure the steam release valve and float valve are clear of any food debris.

6.3 Condensation Collector

The condensation collector, located at the back of the unit, should be emptied and cleaned regularly to prevent water buildup. It is easily detachable for cleaning.

6.4 Exterior Cleaning

Wipe the exterior of the Dream Cooker base unit with a damp cloth. Do not immerse the base unit in water or any other liquid.

7. Troubleshooting

- **Unit Not Powering On:**
  - Ensure the power cord is securely plugged into both the unit and a working electrical outlet.
  - Check if the outlet is functional by plugging in another appliance.
  - If the unit still does not power on after checking connections, contact customer support.
- **Pressure Not Building:**
  - Verify the lid is properly closed and locked.
  - Ensure the silicone gasket is correctly seated and free from damage or debris.
  - Check that the steam release valve is in the sealed position (if applicable for manual models) or functioning correctly for automatic release.
  - Ensure sufficient liquid is added to the inner pot as required by the recipe.
- **Food Sticking to Inner Pot:**
  - Although nonstick, always use a small amount of cooking oil or butter when searing or sauteing to prevent sticking.
  - Avoid using metal utensils that can scratch the nonstick coating. Use silicone or wooden utensils.

8. Specifications

Attribute	Value
Brand	Our Place
Capacity	6 Quarts
Material	Aluminum
Color	Steam
Finish Type	Non Stick
Product Dimensions	13.3"D x 12.4"W x 15.2"H
Special Feature	Manual

Wattage	1200 watts
Control Method	Touch
Controller Type	Integrated Touch Screen Controls
Operation Mode	Manual
Is Dishwasher Safe	Yes (Inner Pot)
Voltage	120 Volts
Closure Type	Locking Lid
UPC	810142480017
Item Weight	18.36 pounds
Country of Origin	China

9. Warranty and Support

The Our Place Dream Cooker comes with a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions. For any product inquiries, technical support, or warranty claims, please visit the official Our Place website or contact their customer service directly.

For additional resources and recipes, you may visit theOur Place Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question