Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

SONGMICS ULCB509B01

SONGMICS Laundry Hamper ULCB509B01 Instruction Manual

Model: ULCB509B01

Introduction

Thank you for choosing the SONGMICS ULCB509B01 Laundry Hamper. This manual provides essential information for the safe and efficient use of your new product. Please read these instructions carefully before assembly and retain them for future reference.



Image: The SONGMICS ULCB509B01 Laundry Hamper in Ink Black, featuring its rectangular shape and lid.

Safety Instructions

- Keep all packaging materials away from children to prevent suffocation hazards.
- Do not overload the hamper beyond its stated capacity to prevent damage or instability.
- Ensure the hamper is placed on a flat, stable surface.
- Avoid placing hot items directly into the hamper.
- This product is intended for indoor use only.
- Do not allow children to climb on or play with the hamper.

Package Contents

Please check to ensure all components are present:

- 1 x SONGMICS Laundry Hamper (ULCB509B01)
- 1 x Lid
- 1 x Handle (pre-attached or assembly required, refer to setup)

Setup Instructions

The SONGMICS ULCB509B01 Laundry Hamper is designed for easy setup. It typically arrives in a foldable state.

1. **Unfold the Hamper Body:** Carefully unfold the main body of the laundry hamper. Ensure the bottom panel is pushed down flat to create a stable base.
2. **Insert Support Rods (if applicable):** Some models may include internal support rods. If present, insert them into the designated sleeves or corners to maintain the hamper's shape.
3. **Attach the Lid:** Place the lid securely on top of the hamper. The lid may have a hook and loop closure or simply rest on the top edge.
4. **Verify Stability:** Gently press down on the top edges to ensure the hamper is fully expanded and stable before use.

Note: No specific assembly video from the seller was available. The general setup involves unfolding and securing the structure.

Operating Instructions

Using your SONGMICS Laundry Hamper is straightforward:

- **Loading Laundry:** Open the lid and place dirty clothes or other items into the hamper. The 114-liter capacity allows for a significant amount of laundry.
- **Using the Lid:** Keep the lid closed to conceal contents and maintain a tidy appearance. The lid also helps contain odors.
- **Portability:** Utilize the integrated handles for easy transport of the hamper to your laundry room or other desired location.
- **Folding for Storage:** When not in use, the hamper can be folded flat for compact storage. Remove the lid, collapse the sides, and secure if necessary.

Maintenance

To ensure the longevity and cleanliness of your laundry hamper:

- **Cleaning:** Wipe the exterior with a damp cloth and mild detergent. Do not use abrasive cleaners or harsh chemicals. Allow to air dry completely.
- **Lining:** If your hamper includes a removable liner, follow the care instructions for the liner material (typically machine washable).
- **Storage:** Store in a dry place when not in use. If folding for storage, ensure it is clean and dry to prevent mildew.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Hamper does not stand upright or is wobbly.	Not fully unfolded; bottom panel not flat; support rods not inserted correctly.	Ensure the hamper is fully expanded and the bottom panel is flat. If applicable, check that all support rods are properly seated.
Lid does not fit securely.	Hamper not fully expanded; lid misaligned.	Ensure the hamper body is fully expanded and the lid is correctly aligned with the top edges.
Unpleasant odor from hamper.	Accumulation of dirty laundry; moisture.	Empty the hamper regularly. Clean the interior and exterior as per maintenance instructions. Ensure laundry is dry before placing it in the hamper.

Specifications

Feature	Detail
Brand	SONGMICS
Model Number	ULCB509B01
Color	Ink Black
Style	Modern
Special Features	Foldable, Handle, Portable
Shape	Rectangular
Included Components	Handle, Lid
Number of Pieces	1
Number of Compartments	1
Pattern	Solid
UPC	194343056319
Item Weight	1.3 kg
Capacity	114 liters
Recommended Uses	Everyday use, Traveling, Dorm living
Room Type	Bathroom, Bedroom, Laundry Room
Closure Type	Hook and loop
Container Type	Basket
Mounting Type	Floor Mount

Warranty and Support

For warranty information and customer support, please refer to the documentation included with your purchase or visit the

official SONGMICS website. Keep your purchase receipt for warranty claims.
If you encounter any issues not covered in this manual, please contact SONGMICS customer service for assistance.

© 2023 SONGMICS. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CLV71BYY

More documents and user manuals: **https://manuals.plus/**