LEXiBOOK LT10EN

LEXiBOOK LAPTAB 10 User Manual

Model: LT10EN

1. Introduction

The LEXiBOOK LAPTAB 10 is a versatile device designed to combine the functionality of a laptop with the interactivity of a tablet. Featuring a 10.1-inch HD touchscreen, a quad-core processor, 4GB RAM, and 128GB storage, it runs on Android and offers a wide range of educational and entertainment possibilities. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your LAPTAB 10.



Image: The LEXiBOOK LAPTAB 10, showcasing its compact design alongside its power adapter and USB-C charging cable.

2. Safety Information

Please read all safety instructions carefully before using the device. Keep this manual for future reference.

- This product is recommended for ages 6 years and up.
- Do not expose the device to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the device to strong impacts.
- Use only the provided charger and USB-C cable.
- Do not attempt to disassemble or repair the device yourself. Refer to qualified service personnel.
- Ensure proper ventilation when using the device to prevent overheating.

3. What's in the Box

Upon opening the packaging, please ensure all the following items are present:

- 1 x LEXiBOOK LAPTAB 10 Educational Laptop
- 1 x USB-C Cable
- 1 x Instruction Manual (this document)

4. Setup

4.1 Initial Charging

Before first use, fully charge your LAPTAB 10. Connect the provided USB-C cable to the device's USB-C port and the other end to the power adapter. Plug the adapter into a wall outlet. The charging indicator light will illuminate. A full charge typically takes several hours.



Image: Side view of the LAPTAB 10, highlighting the USB-C port for charging and other connectivity options.

4.2 Powering On/Off

To power on, press and hold the power button located on the side of the device until the screen illuminates. To power off, press and hold the power button until a power-off menu appears on the screen, then select 'Power off'.

4.3 Initial Configuration

Upon first startup, you will be guided through the initial setup process, which includes:

- Language selection.
- Wi-Fi network connection.
- Google account setup (optional, but recommended for full access to Google Play and services).
- Time and date settings.

5. Operating the LAPTAB 10

5.1 Touchscreen and Keyboard Usage

The LAPTAB 10 features a responsive touchscreen for direct interaction with applications and content. You can tap, swipe, pinch-to-zoom, and long-press just like a tablet. The integrated keyboard allows for comfortable typing, making it suitable for educational tasks and communication.



Image: A hand demonstrating touch interaction on the LAPTAB 10's screen, showing various application icons.

5.2 Android Operating System

Your LAPTAB 10 runs on the Android operating system, providing access to a vast ecosystem of applications and services. The home screen displays various app icons for quick access. You can customize the layout and add widgets as desired.

5.3 Educational and Entertainment Content

The LAPTAB 10 comes pre-loaded with educational and entertainment applications:

- **Power Academy®:** An educational app designed to enhance learning.
- **ReadEra:** Access to 300 Ebooks for reading and learning.
- **15-language translator:** A tool for language learning and translation.
- **Google Play Store™:** Download thousands of additional games and applications.
- **Google Suite:** Includes Google™, Gmail™, Maps™, Drive™, Photos™, Meet™ for productivity and communication.
- **YouTube®:** Access to video content.



Image: A child engaged in learning activities on the LAPTAB 10, demonstrating its use for educational content.

5.4 Parental Controls

The LAPTAB 10 includes comprehensive parental controls to ensure a safe and tailored experience for users. These features allow you to manage screen time, restrict access to certain applications, and monitor usage. The Qwant Junior browser provides a secure browsing environment.



Image: Two children using their LAPTAB 10 devices, illustrating the multi-user and family-friendly design.

5.5 Connectivity

The LAPTAB 10 supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access.
- **Bluetooth 5.0:** Pair with compatible Bluetooth devices such as headphones or speakers.
- **USB Ports:** Includes 2 USB-A ports and 1 USB-C port for connecting peripherals or transferring data.

5.6 Camera Functionality

The 2MP front camera allows for video conferencing and capturing photos. Access the camera application from the home screen to use this feature.

5.7 Product Video Overview

Watch this official product video for a visual overview of the LEXiBOOK LAPTAB 10's features and functionalities.

Your browser does not support the video tag.

Video: Official overview of the Lexibook LAPTAB 10, demonstrating its touchscreen, educational apps, parental controls, and connectivity features.

6. Maintenance

Proper care will extend the life of your LAPTAB 10:

- Clean the screen and exterior with a soft, lint-free cloth. Do not use abrasive cleaners or solvents.
- Keep the device away from liquids and dust.
- Store the device in a cool, dry place when not in use.
- Avoid placing heavy objects on the device.

7. Troubleshooting

If you encounter issues with your LAPTAB 10, refer to the following common solutions:

Problem	Solution
Device does not power on.	Ensure the device is fully charged. Connect the charger and wait a few minutes before attempting to power on again.
Screen is unresponsive.	Perform a soft reset by pressing and holding the power button for approximately 10-15 seconds until the device restarts.
Cannot connect to Wi-Fi.	Check if Wi-Fi is enabled in settings. Ensure you are within range of a Wi-Fi network and have entered the correct password. Restart your router if necessary.
Applications are slow or crashing.	Close unused applications. Clear app cache in settings. Consider uninstalling unnecessary apps to free up storage. Restart the device.
Battery drains quickly.	Reduce screen brightness. Close background applications. Disable Wi-Fi or Bluetooth when not in use.

If the problem persists, please contact LEXiBOOK customer support for further assistance.

8. Specifications

Feature	Detail
Model Name	LT10EN
Screen Size	10.1 Inches
Resolution	1080p
CPU Model	1.2GHz Cortex A8 Processor (Note: Product description mentions Octa-core, but specifications list Cortex A8. Using the specification for accuracy.)
RAM Memory Installed Size	4 GB
Hard Disk Size	128 GB
Operating System	Android™
Connectivity	Wi-Fi, Bluetooth 5.0, 2x USB-A, 1x USB-C
Front Camera	2MP
Battery	4000mAh
Product Dimensions	10.94 x 7.28 x 0.69 inches
Item Weight	2.36 pounds
Manufacturer Recommended Age	6 years and up



Image: The LAPTAB 10 displaying key technical specifications such as processor speed and storage capacity.

9. Warranty and Support

LEXiBOOK products are designed and manufactured to the highest quality standards. For information regarding warranty coverage and customer support, please refer to the warranty card included with your product or visit the official LEXiBOOK website. Keep your proof of purchase for any warranty claims.

For technical assistance or inquiries, please contact LEXiBOOK customer service.

© 2025 LEXiBOOK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I perform a hard reset on the LEXiBOOK LAPTAB 10 (LT10EN) if I have forgotten my password?

Since the LEXiBOOK LAPTAB 10 (LT10EN) runs on the Android operating system, you can typically perform a hard reset using the hardware buttons if you are locked out by a forgotten password. Please note...

Read full answer