Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NIKAI NK-2586

NIKAI NK-2586 Professional Cordless Hair Clipper User Manual

Model: NK-2586 | Brand: NIKAI

1. Introduction

Thank you for choosing the NIKAI NK-2586 Professional Cordless Hair Clipper. This manual provides essential information for the safe and effective use, maintenance, and care of your new hair clipper. Please read it thoroughly before first use and keep it for future reference.



Image 1.1: The NIKAI NK-2586 Professional Cordless Hair Clipper in Gold finish.

2. Product Features

- **Precise & Sharp Blades:** Equipped with self-sharpening stainless-steel T-blades for smooth and efficient cutting and trimming of both dry and wet hair. The blades are designed as R-shaped for safety.
- **Cordless/Corded Operation:** Features a powerful 1400 mAh Li-ion battery, providing up to 150 minutes of cordless runtime after a full 2-hour charge. Can also be used while corded for continuous operation.
- **0mm Close Cutting:** Designed for close cutting, including bald head trimming.
- **Multiple Cutting Lengths:** Includes 3 attachment combs (1mm, 2mm, 3mm) for varying hair lengths. The trimming range is 0mm to 3mm.
- **IPX4 Waterproof:** Unique sealing design ensures the entire body of the clipper is waterproof at an IPX4 level, allowing for easy cleaning.

- **Ergonomic All-Metal Design:** Slim and ergonomic design for comfortable handling and operation. The all-metal body provides durability and a premium feel.
- **Powerful Motor:** Features a silver Pd alloy motor for high rotational speed and consistent performance.
- **Portable Design:** Compact and lightweight, making it suitable for travel, home, or office use.



Image 2.1: Overview of key features including stainless steel blades, metal body, Type-C charging, power indicator, battery, and motor.



Image 2.2: Illustration of the powerful motor.



Image 2.3: Illustration of the lithium battery.

3. Package Contents

The NIKAI NK-2586 Hair Clipper package typically includes:

- 1 x NIKAI NK-2586 Hair Clipper
- 1 x USB Charging Cable
- 3 x Guide Combs (1mm, 2mm, 3mm)
- 1 x Cleaning Brush
- 1 x Lubricating Oil Bottle



Image 3.1: The included 1mm, 2mm, and 3mm guide combs.

4. Setup

4.1 Charging the Clipper

1. Ensure the clipper is turned off before charging.
2. Connect the USB charging cable to the Type-C port at the bottom of the clipper.
3. Plug the other end of the USB cable into a compatible USB power source (e.g., computer, power bank, or wall adapter).
4. The blue indicator light will illuminate when the clipper is charging.
5. A full charge takes approximately 2 hours, providing up to 150 minutes of cordless use.



Image 4.1: USB charging in progress, indicated by the blue light.

4.2 Attaching Guide Combs

1. Select the desired guide comb (1mm, 2mm, or 3mm) for your preferred hair length.
2. Align the comb with the clipper blade and gently push it until it clicks securely into place.
3. To remove, gently pull the comb away from the blade.

5. Operation

5.1 General Trimming

1. Ensure the clipper is fully charged or connected to a power source.

2. Turn on the clipper using the power button.
3. For 0mm close cutting, use the clipper without any guide comb.
4. For longer lengths, attach the appropriate guide comb (1mm, 2mm, or 3mm).
5. Hold the clipper against the hair, moving it slowly and steadily against the direction of hair growth.
6. The clipper can be used on dry or wet hair.
7. This T-shaped trimmer is suitable for various applications including head hair, beard, armpit hair, and body hair.



Image 5.1: Examples of hair and beard trimming with the clipper.

6. Maintenance

6.1 Cleaning

1. Turn off and unplug the clipper before cleaning.
2. Remove any attached guide combs.
3. Use the provided cleaning brush to remove loose hairs from the blades and the clipper body.
4. Due to its IPX4 waterproof rating, the entire body of the clipper can be rinsed under running water for thorough cleaning. Ensure the charging port cover is securely closed if present.
5. Allow the clipper to air dry completely before storing or recharging.



Image 6.1: The clipper is IPX4 waterproof and can be rinsed for cleaning.



Image 6.2: Full body washable design for easier and healthier cleaning.

6.2 Blade Lubrication

After every few uses, or if the blades feel sluggish, apply a small drop of the provided lubricating oil to the blades. Turn on the clipper for a few seconds to distribute the oil evenly, then wipe off any excess.

7. Troubleshooting

Problem	Possible Cause	Solution
Clipper does not turn on.	Low battery or no charge.	Charge the clipper for at least 2 hours. Ensure the USB cable and power source are working correctly.
Blades pull hair or cut poorly.	Blades are dirty, dull, or not lubricated.	Clean the blades thoroughly and apply lubricating oil. If blades are dull, consider professional sharpening or replacement if available.
Clipper makes unusual noise.	Blades are misaligned or internal issue.	Ensure blades are properly aligned. If the issue persists, contact customer support.

8. Specifications

- **Model Name:** NK-2586
- **Power Source:** Battery Powered (1 Lithium Ion battery included)
- **Battery Capacity:** 1400 mAh (approx. 1000mAh mentioned in image)
- **Runtime:** Up to 150 minutes
- **Charging Time:** Approximately 2 hours
- **Waterproof Rating:** IPX4 (Full Body Washable)
- **Blade Material:** Stainless Steel T-Blade
- **Trimming Range:** 0mm to 3mm (with guide combs)

- **Special Features:** Fast Charge, Rechargeable, USB Charging
- **Product Dimensions:** 20 x 10 x 5 cm
- **Item Weight:** 370 g
- **Material:** Metal
- **Country of Origin:** China
- **Manufacturer:** Yiwu Target Appliance Co. LTD



Image 8.1: Battery specifications and cordless use duration.

9. Product Video Overview

Your browser does not support the video tag.

Video 9.1: An overview of the NIKAI NK-2586 Professional Cordless Hair Clipper, highlighting its design, features, and specifications. This video provides a visual demonstration of the product and its capabilities.

10. Warranty and Support

The NIKAI NK-2586 Hair Clipper comes with a **1-year quality warranty** against defects in materials and workmanship from the date of original purchase (invoice required). This warranty does not cover intentional or unintentional damage caused by the user.

To initiate a warranty claim, please contact the seller "SAAS CONSUMER GOODS" or the manufacturer "Yiwu Target Appliance Co. LTD" with a clear description of the problem, associated pictures, and a copy of your original invoice.

Contact for Warranty Claims: WARRANTY@wmarkindia.in
The customer is responsible for the cost of transporting the product to the service center. The company will cover the return shipping cost if a repair or exchange is deemed necessary under warranty.

© 2026 NIKAI. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CM389LX3

More documents and user manuals: **https://manuals.plus/**