Maxxima MCL-713705

Maxxima 7.5-inch LED Flush Mount Ceiling Light Fixture

Model: MCL-713705

Brand: Maxxima

1. Important Safety Information

Please read and understand all instructions before beginning installation. Failure to do so may result in electric shock, fire, or other injuries that could be hazardous or even fatal.

- **WARNING:** Risk of electric shock. Disconnect power at the fuse or circuit breaker before installing or servicing.
- **WARNING:** Risk of fire. Minimum 90°C supply conductors. Consult a qualified electrician to ensure correct branch circuit conductor.
- This product must be installed in accordance with the applicable installation code by a person familiar with the construction and operation of the product and the hazards involved.
- Suitable for damp locations.
- Do not use with dimmers other than those specified by the manufacturer.

2. Package Contents

Verify that all components are present before beginning installation:

- LED Flush Mount Ceiling Light Fixture
- E26 Quick Connect Adapter
- Torsion Clips (for retrofit installation)
- Mounting Hardware (screws, wire nuts)



Image: All components included with the Maxxima 7.5-inch LED Flush Mount Ceiling Light Fixture.

3. Specifications

Brand	Maxxima
Model Name	MCL-713705
Size	7.5 inches
Product Dimensions	7.3"L x 7.3"W x 2.3"H
Light Source Type	LED
Brightness	1200 Lumens
Color Temperature (CCT)	2700K/3000K/3500K/4000K/5000K Selectable

Wattage	13 Watts
Voltage	120 Volts (AC)
Dimmable	Yes
Installation Type	Flush Mount (J-Box or Recessed Can)
Material	Polycarbonate
Suitable for Damp Locations	Yes
Lifespan	50,000 hours
Certifications	ETL Listed

4. Installation Instructions

This fixture supports both retrofit installation into existing 5 or 6-inch recessed cans and direct installation to a standard J-box. Always ensure power is disconnected at the circuit breaker before starting any electrical work.

4.1. CCT (Color Temperature) Selection

Before installation, select your desired color temperature (2700K, 3000K, 3500K, 4000K, or 5000K) using the switch located on the back of the fixture. This switch allows you to customize the light output to match your preference or existing lighting.



Image: CCT selection switch on the back of the fixture.



Image: Visual representation of the 5 CCT options.

4.2. Retrofit Installation (for Recessed Cans)

1. Ensure power is OFF at the circuit breaker.
2. Remove the existing bulb and trim from the recessed can.
3. Attach the provided torsion springs to the mounting brackets on the back of the LED fixture. Secure them by screwing the brackets into place.
4. Screw the E26 Quick Connect adapter into the existing socket in the recessed can.
5. Connect the wires from the fixture to the E26 adapter. The black wire connects to the black wire, the white wire to the white wire, and the green/yellow wire to the ground wire.
6. Carefully push the fixture into the recessed can, ensuring the torsion springs hold it securely in place.
7. Re-attach the lens by aligning it and rotating clockwise until secure.



Image: Maxxima 7.5-inch LED light fixture installed in a ceiling.

4.3. J-Box Installation

1. Ensure power is OFF at the circuit breaker.
2. If necessary, rotate the ground wire on the fixture 90 degrees to align with the J-box mounting holes.
3. Strip approximately 3/8 inch of insulation from the ends of the house wiring (black, white, and ground).
4. Connect the black wire from the fixture to the black wire from the J-box using a wire nut.
5. Connect the white wire from the fixture to the white wire from the J-box using a wire nut.
6. Connect the green/yellow ground wire from the fixture to the house ground wire using a wire nut.
7. Carefully tuck all wires into the J-box.
8. Align the fixture's mounting holes with the J-box screws and secure the fixture to the J-box using the provided screws.
9. Re-attach the lens by aligning it and rotating clockwise until secure.



Image: Slim profile of the Maxxima LED light fixture.

4.4. Installation Video Guide

For a visual guide on the installation process and CCT selection, please watch the official product video below.

Video: Official Maxxima installation guide for the 7.5-inch Round LED Ceiling Light, demonstrating CCT selection and both retrofit and J-box installation methods.

5. Operating Instructions

Once installed and power is restored, the Maxxima 7.5-inch LED Flush Mount Ceiling Light Fixture is ready for use.

- **Power On/Off:** Use your standard wall switch to turn the light fixture on or off.
- **Dimming:** This fixture is dimmable. Use a compatible LED dimmer switch (sold separately) to adjust the brightness level from 10% to 100%.
- **Color Temperature (CCT) Adjustment:** The CCT is set via a switch on the back of the fixture during installation. To change the CCT, you must turn off power, remove the fixture, adjust the switch, and then reinstall.

6. Maintenance

The Maxxima LED Flush Mount Ceiling Light Fixture requires minimal maintenance.

- **Cleaning:** Ensure power is off before cleaning. Wipe the fixture with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electrical components.
- **Bulb Replacement:** This fixture uses integrated LEDs and does not require bulb replacement. The LEDs have a long lifespan of 50,000 hours.

7. Troubleshooting

If your light fixture is not operating correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections.	Check the circuit breaker and wall switch. Ensure power is off, then check all wire connections for tightness.
Light flickers or dims improperly.	Incompatible dimmer switch. Loose wire connections.	Ensure you are using an LED-compatible dimmer switch. Ensure power is off, then check all wire connections.

Incorrect color temperature.	CCT switch set incorrectly.	Turn off power, remove the fixture, and adjust the CCT switch to the desired setting. Reinstall.

8. Warranty and Support

This Maxxima LED Flush Mount Ceiling Light Fixture comes with a **3-Year Warranty**.
For technical support, warranty claims, or further assistance, please contact Maxxima customer service.

- **Brand:** Maxxima
- **Website:** www.maxximastyle.com

© 2026 Maxxima. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question