Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Balsam Hill 2808946

Balsam Hill BH Fraser Fir Artificial Christmas Tree User Manual

Model: 2808946 (7.5ft Clear LED)

Introduction

Welcome to the Balsam Hill BH Fraser Fir Artificial Christmas Tree user manual. This guide provides essential information for the assembly, operation, maintenance, and troubleshooting of your new Christmas tree. Please read these instructions carefully before setup to ensure proper use and longevity of your product.

The Balsam Hill BH Fraser Fir is designed with award-winning True Needle foliage, replicating the appearance of natural Fraser fir branches. It features Easy Plug Technology for simplified lighting setup and offers various lighting options for a festive display.





Image: A fully assembled Balsam Hill BH Fraser Fir Artificial Christmas Tree with clear LED lights, showcasing its realistic appearance.

Safety Information

Please observe the following safety precautions:

- Ensure the tree is placed on a stable, level surface to prevent tipping.
- Keep the tree away from heat sources, open flames, and direct sunlight.
- Do not overload electrical outlets. Use only the provided power cords and adapters.
- Inspect all electrical components for damage before each use. Discontinue use if any damage is found.
- Keep small children and pets away from the tree during assembly and disassembly.
- Unplug the tree from the power source before performing any maintenance or when leaving unattended for extended periods.

Package Contents

Your Balsam Hill BH Fraser Fir Artificial Christmas Tree package includes:

- Tree sections (multiple, depending on height)
- Premium tree stand with scratch-proof rubber feet
- Durable storage bags for off-season storage
- Protective gloves for branch shaping
- Extra bulbs (for models with replaceable bulbs)
- Power adapter/controller

Size Guide

Generally speaking, you want 6 inches between the ceiling and the top of your tree or tree topper, and your space should have 12 inches of clearance beyond the width of your tree.

Choosing the right height

All heights include tree stands.

UNDER 6'
For cozy rooms and secondary spaces (kitchens, dens).

6' - 6.5'
For homes with low to average ceiling height.

7' - 7.5'
For homes with 8' to 9' ceiling heights.

8' - 9'
For rooms with 10' to 11' ceiling heights.

10' - 14'
For 2-story living rooms and other rooms with very high ceiling heights, as well as commercial spaces.

15' - 30'
For churches, malls, office buildings, and other large public spaces.

Choosing the right shape and style

REGULAR (FULL)
Lush profiles and sturdy branches make these our most popular trees.

SLIM
Our most slender profile for tight spaces, corners, and foyers.

WIDE
Fill up a room and have plenty of space for ornaments and presents beneath.

SPARSE
Branches spaced so your ornaments become the star of the show.

FLATBACK
Space-savers that appear full from the front, but rest flat against a wall or corner.

7.5' BH FRASER FIR® TREE: 90" X 60" (INCLUDES TREE STAND) | FULL

Image: The sturdy metal tree stand, a key component for stable tree assembly.

Setup Instructions

Follow these steps to assemble your Balsam Hill BH Fraser Fir Artificial Christmas Tree:

1. **Prepare the Stand:** Unfold the tree stand into an X-shape on a flat, stable surface. Ensure the rubber feet are securely placed.
2. **Insert Bottom Section:** Carefully insert the bottom section of the tree into the stand. Tighten the thumbscrew on the stand to secure the tree section.
3. **Connect Middle Sections:** Continue by inserting the middle tree sections, one by one, into the section below it. The Easy Plug Technology will automatically connect the lights as you stack the sections.
4. **Place Top Section:** Finally, place the top section of the tree.
5. **Fluff Branches:** Wearing the provided protective gloves, gently spread and shape the branches from the trunk outwards, working from the bottom to the top. Ensure each branch tip is fanned out to create a full, natural appearance. First-time shaping may take over an hour for optimal fullness.
6. **Plug In:** Connect the power adapter to the designated port (usually on the bottom section) and plug it into a wall outlet.



Image: Close-up of the realistic True Needle foliage, highlighting the detailed texture of the branches.



Image: Detail of hand-strung lights integrated into the tree branches for a balanced and warm glow.



Image: Hands demonstrating the Easy Plug Technology, where tree sections connect to power the lights automatically.



Image: A fully assembled and fluffed Christmas tree, showcasing its full silhouette and warm lighting after setup.

Operating Instructions

Your Balsam Hill BH Fraser Fir tree features integrated LED lights with various settings. Use the included foot pedal or remote control (if applicable) to manage the lighting functions.

Lighting Options:

- **Clear LED:** Provides a warm, traditional glow.
- **Multi-Color LED:** Displays a vibrant array of colors.
- **Color+Clear LED:** Offers both clear and multi-color options, often with a foot pedal to switch between modes.
- **Twinkly Smart Lights:** (For specific models) Control light patterns and colors via a smartphone app.

Refer to the specific instructions for your model's light controller for detailed operation of modes, brightness, and timer functions.

Maintenance

Proper maintenance ensures the longevity and beauty of your artificial Christmas tree.

Cleaning:

- Dust the tree regularly with a soft cloth or feather duster.
- For deeper cleaning, use a damp cloth with mild soap and water. Ensure the tree is unplugged and completely dry before plugging it back in or storing.
- Do not use harsh chemicals or abrasive cleaners, as these can damage the foliage or lights.

Storage:

- Before storing, remove all ornaments and decorations.
- Dismantle the tree sections from top to bottom.
- Gently compress the branches to reduce their volume, but avoid excessive force.
- Place each section into the provided durable storage bags. Store in a cool, dry location away from direct sunlight and extreme temperatures.

Troubleshooting

If you encounter any issues with your tree, refer to the following common solutions:

Problem	Possible Cause	Solution
Lights not working on a section.	Loose connection between sections or a faulty bulb/fuse.	Ensure all tree sections are securely connected. Check for any loose or broken bulbs and replace them with the provided spares. Inspect fuses in the plug.
Tree appears sparse after assembly.	Branches are not fully fluffed.	Spend additional time shaping each branch and tip, working from the inside out and bottom to top, to fill any gaps.
Tree is unstable.	Stand not fully extended or tree section not secured.	Ensure the tree stand is fully opened and locked into an X-shape. Tighten the thumbscrew on the stand to firmly hold the bottom tree section.

Specifications

Feature	Detail
Brand	Balsam Hill
Model Number	2808946
Product Dimensions	58"D x 58"W x 90"H (7.5ft height)
Color	Clear Led
Material	Polyethylene
Item Weight	58 Pounds
Tree Type	Fir (BH Fraser Fir)
Special Feature	Prelit, Easy Plug Technology

Feature	Detail
Light Color	clear
UPC	196041201893

Warranty Information

Balsam Hill products typically come with a limited warranty covering manufacturing defects. For specific warranty details, including coverage period and terms, please refer to the warranty card included with your product or visit the official Balsam Hill website. Keep your proof of purchase for warranty claims.

Customer Support

For further assistance, product inquiries, or to report any issues, please contact Balsam Hill customer support:

- **Online:** Visit the Balsam Hill Store on Amazon for FAQs and contact options.
- **Returns:** This product is returnable until Jan 31, 2026. Refer to Amazon's return policy for details.

© 2023 Balsam Hill. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMQKXF9H

More documents and user manuals: **https://manuals.plus/**