Ariete 1972

ARIETE 3-in-1 Sandwich Maker Instruction Manual

Model: 1972

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The ARIETE 3-in-1 Sandwich Maker, Model 1972, is a versatile kitchen appliance designed for quick and easy preparation of sandwiches, donuts, and cupcakes. Its 700-watt power ensures efficient heating, while the non-stick coating on the removable plates simplifies both cooking and cleaning. The appliance features an on/off indicator light, a cable stripper for neat storage, and a safety lock for secure operation.



Image: The ARIETE 3-in-1 Sandwich Maker in its closed position, featuring a retro blue and silver design. The top lid displays 'Party Time' and 'Sandwiches & Cookies' branding.

Before First Use (Setup)

1. **Unpack:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Clean Plates:** Before first use, wipe the removable non-stick plates with a damp cloth or sponge. Dry thoroughly. Do not immerse the main unit in water.
3. **Initial Heat-Up:** Insert the desired plates (e.g., sandwich plates) and close the lid. Plug the appliance into a suitable electrical outlet. Allow the appliance to heat up for approximately 5-10 minutes without food. A slight odor or smoke may occur during this initial heating; this is normal and will dissipate. Unplug and allow to cool.
4. **Wipe Down:** Once cooled, wipe the plates again with a clean, damp cloth. The appliance is now ready for use.

Operation

The ARIETE 3-in-1 Sandwich Maker comes with three sets of interchangeable non-stick plates for sandwiches, donuts, and cupcakes. Always ensure the correct plates are securely inserted before operation.

Making Sandwiches

1. Ensure the sandwich plates are correctly installed.
2. Close the lid and plug the appliance into a 120V electrical outlet. The indicator light will illuminate, signaling that the appliance is preheating.
3. Once the appliance reaches the optimal temperature, the indicator light may turn off or change color (refer to specific model behavior).
4. Carefully open the lid and place your bread and fillings onto the bottom plate. Do not overfill.
5. Close the lid and engage the safety lock.
6. Cook for approximately 3-5 minutes, or until the sandwiches are golden brown and the cheese (if any) is melted. Cooking time may vary based on ingredients and desired crispness.
7. Carefully open the lid and remove the cooked sandwiches using a heat-resistant plastic or wooden utensil. Do not use metal utensils, as they can damage the non-stick coating.



Image: The ARIETE 3-in-1 Sandwich Maker open, revealing the sandwich plates. Four triangular sandwiches are being cooked, with various fresh ingredients like tomatoes, cheese, and cold cuts displayed around the appliance.

Making Donuts

1. Ensure the donut plates are correctly installed.
2. Close the lid and plug in the appliance to preheat.
3. Once preheated, carefully open the lid.
4. Pour or pipe your donut batter into each cavity, filling approximately two-thirds full.
5. Close the lid and engage the safety lock.
6. Cook for approximately 5-8 minutes, or until the donuts are golden brown and cooked through. Cooking time may vary based on batter consistency.
7. Carefully open the lid and remove the cooked donuts using a heat-resistant plastic or wooden utensil.



Image: The ARIETE 3-in-1 Sandwich Maker open, displaying the donut plates. Several freshly baked, plain donuts are visible in the cavities, surrounded by plates of colorful, decorated donuts and various toppings.

Making Cupcakes

1. Ensure the cupcake plates are correctly installed.
2. Close the lid and plug in the appliance to preheat.
3. Once preheated, carefully open the lid.
4. Pour or pipe your cupcake batter into each cavity, filling approximately two-thirds full.
5. Close the lid and engage the safety lock.
6. Cook for approximately 8-12 minutes, or until the cupcakes are golden brown and a toothpick inserted into the center comes out clean. Cooking time may vary based on batter consistency.
7. Carefully open the lid and remove the cooked cupcakes using a heat-resistant plastic or wooden utensil.



Image: The ARIETE 3-in-1 Sandwich Maker open, showing the cupcake plates. Several baked cupcakes are in the cavities, with various decorated cupcakes and sprinkles arranged around the appliance.

Note: *The appliance includes a cable stripper for convenient cord management when not in use.*

Care and Maintenance

1. **Unplug and Cool:** Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. **Clean Removable Plates:** The non-stick plates are removable for easy cleaning. Hand wash them with warm, soapy water and a soft sponge. Rinse thoroughly and dry completely before reattaching or storing. Do not use abrasive cleaners, scouring pads, or metal utensils on the non-stick surface, as this can damage the coating.
3. **Clean Exterior:** Wipe the exterior of the appliance with a damp cloth. Do not immerse the main unit in water or any other liquid.
4. **Storage:** Once clean and dry, store the appliance in a cool, dry place. You can use the cable stripper to neatly wrap the power cord.

Troubleshooting

If you encounter issues with your ARIETE 3-in-1 Sandwich Maker, please refer to the following common problems and solutions:

- **Appliance does not heat up:**
    - Ensure the power cord is securely plugged into a working electrical outlet.
    - Check if the outlet is receiving power (test with another appliance).

- **Food sticks to the plates:**
  - Ensure the plates were properly cleaned and dried before use.
  - Apply a light coating of cooking oil or non-stick spray to the plates before adding food, especially for the first few uses or if food continues to stick.
  - Ensure the appliance is fully preheated before adding food.
- **Indicator light does not illuminate:**
  - This may indicate a power issue (see 'Appliance does not heat up' above) or a malfunction. If troubleshooting steps do not resolve the issue, contact customer support.

For issues not listed here, please contact ARIETE customer support.

Technical Specifications

Feature	Specification
Brand	Ariete
Model Number	1972
Power	700 Watts
Voltage	120 Volts
Material	Aluminum
Color	Blue
Item Weight	6.6 pounds (3 Kilograms)
Product Dimensions	10.63 x 4.72 x 4.33 inches
Special Feature	Non Stick Coating
Included Components	3 removable non-stick plates, cable stripper

Warranty and Support

Specific warranty information for the ARIETE 3-in-1 Sandwich Maker, Model 1972, is not provided in this manual. For detailed warranty terms, conditions, and customer support, please refer to the documentation included with your product packaging or visit the official Ariete website.

For technical assistance or service inquiries, please contact Ariete customer support through their official channels.

© 2023 Ariete. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question