Acer A315-58-74KE

Acer Aspire 3 A315-58-74KE Laptop User Manual

Model: A315-58-74KE

1. Introduction

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your Acer Aspire 3 A315-58-74KE laptop. Please read this manual thoroughly to ensure proper use and to maximize the lifespan of your device.

The Acer Aspire 3 A315-58-74KE is a slim laptop designed for everyday productivity. It features a 15.6-inch Full HD display, an Intel Core i7-1165G7 processor with Intel Iris Xe Graphics, 8GB DDR4 RAM, and a 512GB PCIe Gen4 SSD. It operates on Windows 11 Home and supports Wi-Fi 6 for fast wireless connectivity.



Image 1.1: Front view of the Acer Aspire 3 A315-58-74KE laptop displaying the Windows 11 operating system interface.

2. Setup

2.1 Unboxing and Initial Inspection

Carefully remove the laptop and all accessories from the packaging. Verify that all components are present:

- Acer Aspire 3 Laptop
- AC Adapter
- Power Cord

Inspect the laptop for any physical damage. If any damage is found or components are missing, contact your retailer or Acer support immediately.

2.2 Connecting to Power

1. Connect the AC adapter to the power jack on the side of the laptop.
2. Plug the power cord into the AC adapter.
3. Plug the other end of the power cord into a grounded electrical outlet.

The battery will begin charging. It is recommended to fully charge the battery before the first use.

2.3 First Boot and Windows 11 Setup

1. Open the laptop lid and press the power button, typically located on the top-right of the keyboard.
2. Follow the on-screen instructions to complete the Windows 11 Home setup process. This includes selecting your

region, keyboard layout, connecting to a Wi-Fi network, and creating a user account.

3. Operating Your Laptop

3.1 Keyboard and Touchpad

The laptop features a full-size keyboard and a precision touchpad. Familiarize yourself with the key layout and touchpad gestures for efficient navigation.



Image 3.1: Top-down view of the Acer Aspire 3 keyboard and touchpad, highlighting the layout of input devices.

3.2 Display

The 15.6-inch Full HD (1920x1080) display provides clear visuals. Adjust brightness using the function keys (Fn + F3/F4) or through Windows display settings.



Image 3.2: The laptop screen displaying 'Full HD 1920x1080', indicating the display resolution.

3.3 Connectivity

The laptop supports Wi-Fi 6 (802.11ax) for high-speed wireless internet access and Bluetooth for connecting peripherals.



Image 3.3: The Acer Aspire 3 laptop with a Wi-Fi 6 Wireless Connection icon, indicating its advanced wireless capabilities.

3.4 Ports and Connectors

The Acer Aspire 3 A315-58-74KE includes various ports for connecting external devices:

- USB 3.0 Ports (x2)
- USB 2.0 Port (x1)
- HDMI Port
- Ethernet (RJ-45) Port
- Headphone/Microphone Combo Jack
- Power Connector



Image 3.4: Right side view of the Acer Aspire 3 laptop, showing the power input, HDMI port, and two USB ports.



Image 3.5: Left side view of the Acer Aspire 3 laptop, showing the Kensington lock slot, USB port, and audio jack.

4. Maintenance

4.1 Cleaning

- Use a soft, lint-free cloth to clean the screen. For stubborn marks, dampen the cloth with water or a screen-cleaning solution.
- Wipe the keyboard and chassis with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Periodically clean the ventilation grilles to prevent dust buildup, which can affect cooling performance.

4.2 Software Updates

Regularly update your Windows operating system and device drivers to ensure optimal performance, security, and compatibility. Windows Update can be accessed via Settings > Windows Update.

4.3 Battery Care

To prolong battery life:

- Avoid extreme temperatures.
- Do not leave the laptop plugged in at 100% charge for extended periods if not in use.
- Calibrate the battery occasionally by fully discharging and recharging it.

5. Troubleshooting

This section addresses common issues you might encounter with your laptop.

5.1 Power Issues

- **Laptop does not turn on:** Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Check if the power indicator light is on. If the battery is completely drained, it may take a few minutes of charging before the laptop can power on.
- **Battery not charging:** Verify the AC adapter and power cord connections. Try a different power outlet. If the issue persists, the AC adapter or battery may require service.

5.2 Display Issues

- **Screen is blank:** Press Fn + F6 to toggle the display output. Ensure the brightness is not set to minimum. If an external monitor is connected, try disconnecting it.
- **Flickering or distorted display:** Update your graphics drivers. If the issue persists, it may indicate a hardware problem.

5.3 Connectivity Issues

- **Cannot connect to Wi-Fi:** Ensure Wi-Fi is enabled in Windows settings. Restart your router and modem. Check if other devices can connect to the same network. Update your wireless network adapter drivers.
- **Bluetooth device not connecting:** Ensure Bluetooth is enabled on both the laptop and the device. Make sure the device is in pairing mode and within range.

5.4 Performance Issues

- **Laptop is slow:** Close unnecessary applications. Check Task Manager for processes consuming high CPU or memory. Ensure sufficient free space on the SSD. Run a virus scan.
- **Overheating:** Ensure ventilation grilles are clear of obstructions. Use the laptop on a hard, flat surface to allow for proper airflow.

6. Specifications

Key technical specifications for the Acer Aspire 3 A315-58-74KE laptop:

Feature	Specification
Model Name	Aspire 3 A315-58-74KE
Display Size	15.6 Inches
Screen Resolution	1920 x 1080 (Full HD)
Processor	Intel Core i7-1165G7 (2.8 GHz)
RAM	8 GB DDR4
Storage	512 GB PCIe Gen4 SSD
Graphics	Intel Iris Xe Graphics (Integrated)
Operating System	Windows 11 Home
Wireless Connectivity	802.11ax (Wi-Fi 6), Bluetooth
USB Ports	2x USB 3.0, 1x USB 2.0
Battery Life	Up to 8.5 Hours
Weight	3.75 pounds
Dimensions (LxWxH)	14.31 x 0.78 x 9.39 inches

7. Warranty and Support

For detailed warranty information, technical support, and service inquiries, please refer to the official Acer website or the warranty card included with your product. You can typically find support resources, driver downloads, and contact information on the Acer support portal.
Visit the official Acer support website for assistance:www.acer.com/support

© 2023 Acer Inc. All rights reserved. Information in this document is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question