SUPERLEX 6-in-1 Sandwich Maker

SUPERLEX 6-IN-1 Sandwich Maker Instruction Manual

Model: 6-in-1 Sandwich Maker

Introduction

Thank you for choosing the SUPERLEX 6-IN-1 Sandwich Maker. This versatile appliance is designed to simplify your cooking experience, allowing you to prepare a variety of delicious meals and snacks with ease. With its interchangeable non-stick plates, you can effortlessly switch between making sandwiches, grilling, baking waffles, donuts, nut cakes, and regular cakes. Please read this manual thoroughly before first use to ensure safe and optimal operation.

Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before operating the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off”, then remove plug from wall outlet.

- Do not use appliance for other than intended use.
- The appliance has an automatic temperature adjustment function. The red light indicates heating, and the green light indicates readiness for use.
- The handle features a scald-resistant design and a safety lock to prevent accidental opening during cooking or storage.

Product Overview

The SUPERLEX 6-IN-1 Sandwich Maker comes with a main unit and six sets of interchangeable non-stick plates, allowing for diverse culinary creations.



The SUPERLEX 6-IN-1 Sandwich Maker shown open with grill plates installed, and the other five sets of interchangeable plates fanned out behind it. A plate of waffles with fruit and ice cream is visible on the right.



This diagram illustrates the 6-in-1 functionality of the sandwich maker. It shows the main unit with waffle plates, and examples of food that can be made with each plate type: Waffles, Paninis, Toasties, Nut cakes, regular Cakes, and Donuts. A finger is shown pressing the plate release button.



This image displays all six types of interchangeable plates that come with the SUPERLEX sandwich maker. From left to right, top to bottom, they are: Waffle Plates, Grill Plates, Sandwich Plates, Donut Plates, Cake Plates, and Nut Plates. Each plate type is shown installed in the open appliance, with an example of the food it produces.



This image provides the dimensions of the SUPERLEX 6-IN-1 Sandwich Maker. It shows the closed appliance from a top-down perspective, and an open appliance with donut plates, along with measurements in centimeters and inches for height, width, and plate size.

Setup

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, wipe the exterior of the main unit with a damp cloth. The non-stick plates should be washed with warm, soapy water, rinsed, and thoroughly dried.
3. **Plate Installation:** To install a baking plate, align the plate with the grooves on the upper and lower heating elements. Gently press down until it clicks securely into place. Ensure both plates are correctly installed before use.
4. **Power Connection:** Place the appliance on a stable, heat-resistant surface. Unwind the power cord completely and plug it into a suitable 220V electrical outlet.



A hand is shown using tongs to remove a golden-brown waffle from the non-stick waffle plate of the open sandwich maker. A magnified inset shows the non-stick texture of the plate surface.

Operating Instructions

1. **Preheating:** Close the lid of the sandwich maker. Plug the appliance into the power outlet. The red indicator light will illuminate, indicating that the unit is preheating.
2. **Ready Indicator:** Once the appliance reaches the optimal cooking temperature, the green indicator light will illuminate. This typically takes about 30 seconds. The appliance is now ready for use.
3. **Adding Ingredients:** Carefully open the lid using the cool-touch handle. Place your ingredients (e.g., bread, batter, dough) onto the lower baking plate. Do not overfill.
4. **Cooking:** Close the lid and engage the safety lock on the handle. The red light may cycle on and off during cooking to maintain temperature. Cook for approximately 5 minutes, or until your food is golden brown and cooked to your preference. Cooking times may vary based on ingredients and desired crispness.
5. **Removing Food:** Once cooking is complete, carefully open the lid. Use a heat-resistant plastic or wooden utensil to remove the cooked food. Avoid using metal utensils, as they can damage the non-stick coating.

6. **Repeat or Unplug:** If making more batches, repeat steps 3-5. When finished, unplug the appliance from the power outlet and allow it to cool completely before cleaning.



The SUPERLEX sandwich maker is shown open with two sandwiches cooking on the grill plates. The internal heating element is glowing orange, indicating it is actively heating. A timer icon with '5min' suggests the typical cooking time.

Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your SUPERLEX Sandwich Maker.

- **Always unplug the appliance** and allow it to cool completely before cleaning.
- **Removing Plates:** Press the plate release button to detach the baking plates.
- **Cleaning Plates:** The non-stick baking plates are dishwasher safe or can be washed by hand with warm, soapy water and a soft sponge. Do not use abrasive cleaners or scouring pads, as they can damage the non-stick coating. Rinse thoroughly and dry completely before reattaching or storing.
- **Cleaning Main Unit:** Wipe the exterior of the appliance with a damp cloth. Do not immerse the main unit in water or

any other liquid.

- **Storage:** Once clean and dry, store the appliance in a cool, dry place. The safety lock on the handle helps keep the unit closed for compact storage.

Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet malfunction; internal fault.	Ensure plug is securely in outlet. Test outlet with another appliance. If still no power, contact customer support.
Food not cooking evenly.	Plates not properly installed; uneven distribution of ingredients; insufficient preheating.	Ensure plates are clicked into place. Distribute ingredients evenly. Allow full preheating until green light illuminates.
Appliance trips circuit breaker.	Overloaded circuit; internal electrical fault.	Ensure appliance is on a dedicated circuit or not sharing with other high-wattage appliances. If problem persists, discontinue use and contact customer support.
Food sticks to plates.	Non-stick coating damaged; plates not properly seasoned (first use); insufficient oil/butter.	Ensure non-stick coating is intact. For first use, lightly grease plates. Always use a small amount of oil or butter if needed.

Specifications

Brand	SUPERLEX
Model	6-in-1 Sandwich Maker
Power / Wattage	850 watts
Voltage	220 Volts
Material	Stainless Steel
Colour	Black
Product Dimensions	37 x 38 x 17 cm
Item Weight	3.2 kg
Special Features	Temperature Control, Lightweight, Non Stick Coating, Removable Surface, Cool Touch
Included Components	Waffle Plates, Sandwich Plates, Donut Plates, Grill Plates, Cake Plates, Nut Plates

Warranty and Support

SUPERLEX products are manufactured to high-quality standards. For any issues, questions, or support needs, please refer to your purchase documentation or contact the retailer where the product was purchased. Keep your proof of

purchase for warranty claims.

© 2025 SUPERLEX. All rights reserved.