Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Noma CTI1517198

Noma Pre-Lit 9-Foot Christmas Garland with Battery-Operated LED Lights User Manual

Model: CTI1517198

Introduction

This manual provides detailed instructions for the safe and effective use of your Noma Pre-Lit 9-Foot Christmas Garland. This product is designed to enhance your indoor or covered outdoor seasonal decorations with its realistic foliage and warm white LED lights. Please read all instructions carefully before assembly and operation.



Image: A full view of the Noma Pre-Lit 9-Foot Christmas Garland, showcasing its frosted fir tips and integrated warm white LED lights.

Safety Information

WARNING:

- For indoor and covered outdoor use only.
- Keep out of reach of children.
- Do not expose to water or direct heat sources.
- Ensure batteries are inserted correctly according to polarity markings.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the product is not used for an extended period.

Package Contents

Verify that all components are present before proceeding with setup.

- 2 x Noma Pre-Lit 9-Foot Christmas Garland strands (each with 35 warm white LED lights and 290 fir tips)
- Battery boxes (integrated into each garland)

Note: 3 AA batteries are required per garland and are not included.

Setup Instructions

1. **Unpack the Garland:** Carefully remove the garland strands from their packaging. Gently fluff and shape the fir tips to achieve the desired fullness.
2. **Install Batteries:** Locate the battery box on each garland. Open the battery compartment and insert 3 AA batteries, ensuring correct polarity (+/-). Close the compartment securely.
3. **Placement:** Position the garland in your desired location. This product is suitable for mantels, railings, banisters, entryways, and windows. Ensure the location is protected if used outdoors (covered area).
4. **Secure the Garland:** Use appropriate fasteners (not included) such as floral wire, zip ties, or garland hangers to secure the garland in place, especially if hanging vertically or in high-traffic areas.





Image: A close-up of the garland with text highlighting key features: "Hassle-Free Set-Up" due to battery operation, "Indoor & Outdoor" suitability, and "290 Pine Tips" for a full appearance.



Image: The Noma garland elegantly draped over a white fireplace mantel, showcasing its frosted appearance and warm glow.

Operating Instructions

Each garland is equipped with a battery box that includes an ON/OFF switch.

1. **Power On:** Locate the battery box and slide the switch to the "ON" position. The LED lights will illuminate.
2. **Power Off:** To turn off the lights, slide the switch to the "OFF" position.

Battery life will vary depending on the quality of batteries used and continuous operation. Replace batteries when lights dim or cease to function.

Maintenance

- **Cleaning:** To clean the garland, gently wipe with a soft, dry cloth. Do not use liquid cleaners or immerse in water.
- **Storage:** When not in use, remove the batteries from the battery box. Store the garland in its original packaging or a

suitable storage container in a cool, dry place, away from direct sunlight and extreme temperatures. This helps preserve the shape and appearance of the fir tips and extends the life of the LED lights.

- **Shaping:** Over time, the fir tips may become compressed. Gently reshape them as needed to restore the garland's full appearance.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	◦ Batteries are dead or low. ◦ Batteries are inserted incorrectly. ◦ ON/OFF switch is in the "OFF" position.	◦ Replace with fresh AA batteries. ◦ Check battery polarity and reinsert correctly. ◦ Slide the switch to the "ON" position.
Lights are dim.	Batteries are low.	Replace with fresh AA batteries.
Garland appears sparse.	Fir tips are compressed from packaging or storage.	Gently fluff and reshape the individual fir tips to achieve desired fullness.

Specifications

- **Model:** CTI1517198
- **Brand:** Noma
- **Length:** 9 feet (108 inches) per garland
- **Fir Tips:** 290 PE and PVC glitter-flocked frosted fir needles per garland
- **Lights:** 35 Warm White LED bulbs per garland
- **Power Source:** 3 x AA batteries per garland (not included)
- **Material:** Artificial Pine (PE and PVC)
- **Usage:** Indoor and Covered Outdoor
- **UPC:** 193802348255

Warranty and Support

Noma products are manufactured to high-quality standards. For specific warranty information or technical support, please refer to the product packaging or contact Noma customer service directly. Contact details can typically be found on the manufacturer's website or product documentation.
For further assistance, please visit the Noma brand store:Noma Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0CMXYB9CM

More documents and user manuals: **https://manuals.plus/**