Noma 3 x CTI1513696

Noma Quick Clip C9 LED Light Set User Manual

Model: 3 x CTI1513696

Product Overview

The Noma Quick Clip 100 LED C9 Light Set offers a convenient and brilliant lighting solution for both indoor and outdoor festive decorations. Each set features integrated spring-loaded clips for easy attachment to various surfaces, and adjustable light positions for optimal display. These energy-efficient LED lights remain cool to the touch, enhancing safety. This product is a 3-pack, providing extensive coverage for your decorating needs.



Image: Three Noma Quick Clip C9 LED Light Set boxes, highlighting the 3-pack configuration and multicolor lights.

Safety Information

Always read and follow all safety instructions before using this product to reduce the risk of fire, electric shock, and personal injury.

- Do not overload circuits. Connect a maximum of 45 strands end-to-end.
- Ensure all connections are secure and protected from moisture when used outdoors.
- Inspect lights for damage before each use. Do not use if wires are frayed or bulbs are broken.
- Unplug the light set from the power source when not in use or before performing any maintenance.
- Keep away from flammable materials.
- Do not secure wiring with staples or nails.

Package Contents

Verify that all components are present before beginning installation.

- 3 x Noma Quick Clip 100 LED C9 Light Strands
- Integrated Quick Clip system on each bulb

- Spare fuses (may be included)

Setup and Installation

The Noma Quick Clip system simplifies installation. Follow these steps for optimal setup:

1. **Unpack and Inspect:** Carefully remove the light strands from the packaging. Uncoil each strand and inspect for any damage to the bulbs, wires, or clips. Do not use if any damage is found.



Image: A single Noma Quick Clip C9 LED Light Set box, illustrating the product packaging.

2. **Plan Your Display:** Determine where you want to install the lights. The integrated clips are designed for easy attachment to eaves, shingles, trees, bushes, or railings.



Image: Multicolor C9 LED lights clipped along a snowy roofline, showcasing an outdoor installation example.

3. **Attach Lights:** Use the built-in spring-loaded clips on each C9 bulb to secure the lights to your desired surface. The clips allow for quick and easy attachment.



Image: A hand demonstrating the use of the built-in spring-loaded clip to attach a C9 LED light.

4. **Adjust Light Position:** Each light can be adjusted up to 180 degrees. Rotate the bulb to achieve your preferred angle and direction of light.



Image: Illustration of the 180-degree adjustable light position and the built-in spring-loaded clip.

5. **Connect Multiple Strands:** For larger areas, connect up to 45 strands end-to-end using the plugs located at both ends of each strand. Ensure connections are secure.
6. **Power On:** Once all lights are securely installed and connected, plug the first strand into a suitable power outlet.

Operating Instructions

The Noma Quick Clip C9 LED Light Set operates simply once plugged in. There are no complex controls.

- **Power On/Off:** The lights will illuminate when plugged into a live power outlet. To turn off, simply unplug the light set from the power source.
- **Light Modes:** This model provides a consistent multicolor illumination. There are no selectable light modes.
- **Indoor/Outdoor Use:** These lights are designed for both indoor and outdoor environments. Ensure outdoor connections are protected from direct water exposure.



Image: Red and green C9 LED lights clipped to a tree branch, illustrating typical outdoor operation.

Maintenance

Proper maintenance ensures the longevity and safe operation of your Noma Quick Clip C9 LED Light Set.

- **Cleaning:** Disconnect from power before cleaning. Wipe bulbs and wires with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the light set in a cool, dry place, away from direct sunlight and extreme temperatures. Coil the strands neatly to prevent tangling and damage to wires or bulbs.
- **Bulb Replacement:** LED bulbs are designed for long life and are generally not user-replaceable. If a bulb fails, the entire strand may need to be replaced or checked for fuse issues.
- **Fuse Replacement:** If the entire strand does not light up, check the fuse in the plug. Refer to the diagram on the plug for fuse location and replacement instructions. Use only the specified type and rating of fuse.

Troubleshooting

Problem	Possible Cause	Solution
Lights do not turn on.	Not plugged in securely. Power outlet is not active. Blown fuse in the plug. Damaged wire or bulb.	Ensure the plug is fully inserted into a working outlet. Test the outlet with another device. Check and replace the fuse in the plug if necessary. Inspect the entire strand for visible damage. If damaged, discontinue use.
Only part of the strand is lit.	Loose connection between strands. Damaged section of wiring.	Ensure all end-to-end connections are tight. Inspect the unlit section for any visible damage to wires or bulbs.

Specifications

- **Model:** 3 x CTI1513696
- **Brand:** Noma
- **Light Type:** LED C9
- **Number of Lights per Strand:** 100
- **Total Strands:** 3 (in this pack)
- **Strand Length:** 66.8 feet (20.3 meters) per strand
- **Bulb Spacing:** 8 inches
- **Color:** Multicolor
- **Power Source:** Corded Electric
- **Indoor/Outdoor Usage:** Suitable for both
- **Max Connectable Strands:** Up to 45 strands end-to-end
- **UPC:** 193802348286
- **Dimensions (L x W x H):** 801.6 x 1.25 x 1.25 inches (per strand)
- **Weight:** 8.1 pounds (for the 3-pack)

Warranty and Support

This Noma Quick Clip C9 LED Light Set comes with a**Limited 3-Year Warranty**, as indicated on the product packaging. For warranty claims, technical support, or any product-related inquiries, please contact Noma customer service. Refer to the official Noma website or product packaging for the most current contact information.

© 2024 Noma. All rights reserved.
This manual is for informational purposes only. Specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question